### **Navigating NETRA for Reliability Dashboard**


#### STEP 2

#### PRELIMINARY STEPS FOR THE GRAPH TO BE VISIBLE

- 1. Add the monthly utilization data for the Selected Equipment In Data Manager Module
- 2. Insert Defet Data From Data Manager Module inside View OR Update Data
- 3. Click on RESTIMATE BUTTON to set the alpha beta for the Selected Equipment in the Data Manager Module
- 4. After the above steps follow the below guide


STEP 3

Click on RELIABILITY DASHBOARD




#### STEP 4

## Fill the required Options




# STEP 5 Enter Mission duration in hours ex. 250



STEP 6

#### **Click on SUBMIT**



STEP 7

NOTE: Multiple ships can be selected along with equipment from those ships, and the reliability of those equipments can be compared.

