
Mission Reliability Dashboard

PRELIMINARY STEPS FOR COMPARING SAME... 11 Steps 🖸

- 1. Go To Mission Configuration and Create a Same Task For Both the Ships to compare.
- 2. After that follow the guide.


STEP 2

Click on MISSION RELIABILITY DASHBOARD




STEP 3

Select the Ship & Task to be compared




STEP 4

Click on ADD ROW




STEP 5

Select the Desired Phases for the selected Task




STEP 6 Add duration for each respective Phase in hours




STEP 7

Click on RECOMMEND SOLUTION



STEP 8
Select the Desired Components for each respecitive phase




STEP 9
Click on Add This Task For Comparison

STEP 10

Do The same Steps For Ship 2 & For Same Task, Add This Task For Comparison

STEP 11

Click on CALCULATE RELIABILITY



STEP 12

Below Table Shows same Task Compared For Both of the ships

