



SX side

## STM32 NUCLEO CONNECTORS

4

Я

10 PD8

12

14

16

18

20

22 PB2 PB1

24

26

28

30

32

34

36

38

U5V

PA11

PB12

GND

PB15


PB14


PB13


AGND PC4 NC/PF5

NC/PF4


PB11/NC









DX side







- ST1S14 is inhibited

- VDD is provided by +3V3 of the main board

1-2 and 3-4

- Take care! Refer to the UM of the main board about external power supply

- ST1S14 is enabled

- VDD is provided by +3V3 of the ST1S14 of the expansion board - The main board is supplied by ST1S14 of the expansion board

