

Osmose Bench Build Guide

Table of Contents:

- [Osmose Bench Build Guide](#)
 - [BOM](#)
 - [Preperation](#)
 - [Assembly](#)
 - [Fitting and Final Touches](#)

BOM

- Wood
- Wood glue
- Felt paper
- 2x 1/4" screws

Preperation

Assembly

Fitting and Final Touches

NOTE: When fitting, it is recommended to apply painters tape to the surface of the osmose where the bench interfaces with the keybord chasis. This prevents potential damage to the keyboard.