MIDIbox SEQV4L MIDI Remote Functions

0x24 C2-36	סמו	Bar 2	Bar 3			Sequence 1	0x30 C3-48 Sequence 2			Bec Arm			Hec Live	0x3c C4-60 Stop		Flay	load		Save	Copy	0x48 C5-72	asic	Clear			Waster	lap lempo	0x54 C6-84	900	Play			Тар Тетро	ote Kev. Ox60 CZ-96	TO DOVO KAN
GP #1	GP #2	GP #3	GP #4	GP #5	GP #6	GP #7	GP #8	GP #9	GP #10	GP #11	GP #12	GP #13	GP #14	GP #15	GP #16		Trigger	Length	Progression	Groove	Echo	Humanize	LFO	Scale	Mute	Midi Chn	Rec Arm	RecStep	RecLive	Poly	In->Out	Transpose		MID! Remo	