

MOAI 130



- 1) Cut the above shape out.
- 2) Place on FEP vat with the DOOR label facing the MOAI 130 door.
- 3) Set your Z Reset position at -1 point from its proper value.
- 4) Double click on value to lower Build Plate into vat.
- 5) Trace outline of build plate onto paper.
- 6) Using a ruler, square the edges and find the corners. From corner to corner find the center.
- 7) Using the Cross calibration, center your galvos to intercept the center of your Build Plate.

Using this method to center your galvos will allow you to be able to use 100% of your build volume on the MOAI 130. A similar process can be used for the 200, dimensions pending.