


MAINTENANCE PROCEDURES

For JSK 37U Air Release Fifth Wheels w/Internal Adjustment & Auxiliary Handle



Item	Description	Part No.	Item	Description	Part No.
1	Cushion ring bolt	SK 73121-55	20	Cable spring	SK 71005-04
2	Retainer	SK 3105-93	21	Lock jaw	SK 1489LZ
3	Cushion ring insert	SK 3105-92	22	Lock jaw spring	SK 847
4	Lock jaw pivot pin	SK 72106-67	23	Eye bolt	SK 2106-69
5	Collar	SK 3105-95	24	Ring	SK 2106-70
6	Bushing	SK 2905-94	25	Air cylinder	SK 79020-04
7	Bracket pin	SK 79011-03	26	3/8 SAE flat washer	SK 70302-01
8	Tab washer	SK 73104-47	27	Low head socket cap screw	SK 70209-00
9	1/2-13 x 3/4 lg. Hex bolt	SK 70202-15	28	Ring	SK 2106-70
10	Lock/unlock plate weldment	SK 79016-22	29	Cylinder mount weldment	SK 79020-20
11	5/16-18 x 1" socket head cap screw	SK 70204-08	30	3/8 dia x 1-3/4" long clevis pin	SK 70102-11
12	3/8" dia x 3/4" long clevis pin	SK 70102-00	31	Jam Nut	NT 0000201
13	3/8 SAE flat washer	SK 70302-05	32	Lock washer	SK 70303-63
14	1/8 dia x 1-1/2 long cotter pin	SK 70101-04	33	Guide piece	SK 73205-07
15	Pull cable assembly	SK 79016-46	34	Internal adjusting screw	SK 79010-02
16	T-handle weldment	SK 79009-78	35	Double tension spring	SK 3105-20
17	Locking bar bolt assembly	SK 73221-01	36	Lubricating kit	SK 3108-02
18	Lever with bushing	SK 79016-37	37	Info Pack	SK 75020-38
19	Locking Bar	SK 3205-06			

Minor Rebuild Kit					
Cushion and Lock Jaw - L.H. Only Includes Items 1-4, 21-24, & 36 above					
Order Number	Weight				
SK 73221-50Z	6 lbs.				

The right to alter specifications is reserved.



Page 1 of 1