EERI423 ST2 Flash Cards

Describe and compare different types of multiplexing

- 1)Broadly define Multiplexing
- 2)Name 2 basic methods of multiplexing
- 3)Briefly describe each of these methods
- 4)In words, describe the black diagram for a FDM multiplexer

5)Draw the block diagram for a FDM multiplexer

 $_{\rm 6)} \rm Explain$ the block diagram for an FDM demuxer in words


1) Multiplexing is the process of simultaneously transmitting two or more individual signals over a single communication channel, cable or wireless.

2)

- Frequency Division Multiplexing
- Time division Multiplexing

3)


- FDM divides a channel's bandwidth into several narrower bands, and assigns each multiplexed signal one of these bands
- TDM Allows each signal to occupy the entire channel bandwidth for a brief time.
- 4) Each channel is modulated by its own modulator, using a unique carrier. These modulated signals are then summed and transmitted



5)

6) The first demodulator recovers the composite signal as output by the summer. For each output, the signal is passed through a bandpass filter centered aroun the unique carrier, before demodulating the signal to Recover each original input 7)Draw the block diagram for an FDM demuxer

Figure 10-4 The receiving end of an FDM system.



7) 8)

- 8)List 3 applications for FDM
- 9)In TDM, what is produced by simply sampling each input for a short time
- 10) How was PAM achieved in early telemetry systems
- 11) What is a commutator switch
- 12) Which two constraints dictated the design of such a switch
- 13) briefly explain the operation of a TDM demuxer
- 14) what is the most popular form of TDM

 Telemetry • Cable TV

- FM Stereo Broadcasting
- 9) PAM
- 10) By making use of a commutator switch
- 11) A basic mechanical switch that rotates an arm to touch different contacts one after the other
- 12) The speed of rotation and duration of contact
- 13) The signals are recovered using synchronized clocks and low pass filters
- 14) PCM

PCM IGNORE, DELETED

- 1)Define PCM
- 2) What is the main constraint of PCM
- 3)In words, describe the block diagram of a PCM muxer
- 1) Pulse code Modulation
- 2) It cannot transmit Analog data, so ADC's have to be used

3)

- ADC's are used, if the input is analog
- A Digital MUX circuit receives the digital inputs, as well as decoded clock pulses
- This signal is transmitted

4)Draw the block diagram of the Digital Muxer in the above block diagram

Figure 10-22 PCM multiplexer.

Parallel data in

Serial data i

4)

5)

- Reliable
- Inexpensive
- Resistant to noise

All pulses have the same amplitude Frequency, phase shape, etc. do not effect the demuxing, since only a pulse needs to be identified

5)List x advantages of PCM

Explain the relationship between bandwidth and bit rate

- 1)What are the 2 most common media used for electronic communication
- 2) What constrains the bandwidth of a cable
- 3) How does this limitation work
- 4) What is the typical bandwidth of a coaxial cable
- 5) What is the typical bandwidth of a Twisted pair cable
- 6) What constrains the bandwidth in free space
- 7)What Law relates the information capacity of a channel to the bandwidth
- 8) State this law, in its most basic form
- 9) What is the limitation of the law in this form
- 10)State the law so that it allows for more encoding levels
- 11) What is the implication of this form of the law

- 1) Radio and Wire Cable
- 2) The physical charachteristics of the cable
- 3) All cables act as low pass filters because they have inductance, capacitance and resistance
- 4) 200-300MHz for smaller cables and 500 MHz to 50 GHz for larger cables
- 5) from a few Kilohertz to over 800Mhz
- 6) The amount of bandwidth allocated by the governing body(ICASA) in south africa
- 7) Hartley's law
- 8) C = 2B Where C is the capacity in bps and B is the bandwidth in Hertz
- 9) It assumes only 2 encoding levels are used, i.e. High=1 and low=0
- 10) $C = 2Blog_2N$ Where N is the number of encoding levels
- 11) That More encoding levels enable a higher bit rate over the same bandwidth

- 12) What is the limitation of this second form of this law
- 13)State the law in a form that takes noise into account
- 12) It ignores noise, implying that more encoding levels are always better
- 13) $C = Blog_2 \left(1 + \frac{S}{N}\right)$ Where $\frac{S}{N}$ is the SNR As~a ratio, not as DB

Explain the operation and benefits of spread spectrum

- 1)Define wideband Modulation
- 2)What are the 2 most widely used methods to achieve wideband modulation
- 3)Briefly discuss the development of spread spectrum
- 4)Name 3 common applications of SS, and state which is the most common
- 5) Name the 2 basic methods to apply spread spectrum
- 6)List 5 advantages of Spread spectrum
- 7)Briefly explain the operation of a frequency hopping SS transmitter
- 8)What is meant by pseudorandom

- 1) To occupy more bandwidth than the information signal with the modulating signal
- 2) Spread spectrum and Orthogonal Frequency division multiplexing
- 3) After WW2, it was developed by the military for security and immunity to jamming
- 4)
- LAN and PC modems
- A class of cordless telephones
- Cellular telephones(Most common)
- 5) Direct Sequence and Frequency hopping

6)

- Security
- Resistance to jamming and interference
- Band Sharing
- Resistance to fading and multipath propagation
- Precise timing]i
- 7) The serial binary input is mixed with a frequency that is dictated by a Pseudorandom code generator
- 8) A binary sequence that repeats after many bit changes, which is random enough to prevent someone accidentally duplicating the code, but predictable enough to be duplicated at the receiver.

Define the Characteristic of radio Waves

- 1)Which 3 attributes of radio waves describe the way the waves interact with obstacles
- COME BACK TO THIS ONE

1) Reflection, refraction and diffraction

Calculate the signal strength of a radio wave at a given point

It is important to do several examples here 1)State the formula for power density at a given distance from a poins source

- 2) What is the limitation with this formula
- 3)State the formula that overcomes this
- 4) question

- 1) $P_d = \frac{P_t}{4\pi d^2}$ Where: P_d = Power density; P_t = power transmitted; and d = distance
- 2) Power density is not as usable a figure as power received
- 3) $P_r = \frac{P_t G_t G_r \lambda^2}{16\pi^2 d^2}$ Where: λ : Signal Wavelength

 - d: Distance from Transmitter
 - P_r, P_t : Received and transmitted power, respectively
 - G_r, G_T : receiver and transmitter antenna gains expressed as a power ratio and referenced to an isotropic source
- 4) answer

use various channel models, and propagation equations to determine the communication range

- 1)State the formula for calculating the maximum communication distance for line of sight propagation
- 1) $d = \sqrt{17h_t} + \sqrt{17h_r}$ where:
 - \bullet d is the maximum communication distance
 - h_t, h_r are the heights of the TX and RX antennae

Name and describe the components of conventional electrical telephones

- 1)Name the 5 basic components that connect a long distance phone call
- 1)
- The first telephone set
- Local loop 1
- Long distance system
- local loop 2
- Second telephone set

2)Name and describe the 5 parts of a basic telephone set

2)

Ringer Bell or oscillator that rings

Hybrid Transformer that converts signals from the four TX and RX lines to a signal suitable for a single twisted pair. The hybrid performs the full duplex comms on the twisted pair

Hook Switch Switch usually actuated by the handset that isolates the telephone from the central office loop


Dialing circuits Circuits that enable the telephone to dial specific numbers

Handset Contains a mic and speaker for the user

Describe the hierarchy of telephone signals using a block diagram

- 1)To what is a residential line connected
- 2) And to what is this entity connected
- 3)If the call is long distance, what is the next step, and where is this connection
- 1) A central office
- 2) A local exchange carrier
- 3) The LEC connects to in IXC(interexchange carrier) at a POP (Point of persistence)

4)draw the diagram that illustrates the heirarchy of telephone signals



4)

Describe a common second generation cell phone

- 1) How did the very first cell phone communicate
- 2) What name is given to the first Digital cell phones?
- 3) Which 2 classes of 2g phones are in use today
- 4) Which multipexing technique do these systems empoy
- 1) Using analogue FM techniques
- 2) Second generation, or 2G phones
- 3) GSM and CDMA

4)

GSM Time division multiplexing **CDMA** Spread Spectrum

5) State and describe the 3 basic parts of a typical 2G hand set 5)

RF section Modulates and demodulates the digital baseband signal

Baseband section Performs DSP in the base band and performs A/D and D/A conversions

Control Houses HMI, RAM etc and controls other 2 sections.

Describe the block diagram architecture of a 3G cell phone

Describe the architecture and operation of a GSM cellular network.

1) Why is a GSM network called a "Cell network"

2)

- 1) Because base stations form the heart of the network, and are configured in a cellular fashion
- 2) answer