


Autoscan instructions


Instructions on how to use Auto-Scan

Onboard Scene


1. Click on Stripe number. The Auto scan toggle switch is showed. Slide to activate



2. Click on “+ ADD A POINT FOR AUTO SCAN”



3. Mouse over to the beginning of the stripe (Luff) and click




4. Mouse over to the end of the stripe (Leach) and click




NOTE: IF YOU MAKE A MISTAKE CLICK THE TRASH CAN TO DELETE AND START AGAIN

5. Click "RUN SCANNER"



6. The scanner will execute and the results will show on the stripe.



7. To adjust points click on the move button and adjust as before



8. Move onto the next stripe and repeat