## Máquina de la secuencia de inicio

Estado	actual	Entrada	Estado Futuro		Salida
S1	S0	Q	S1'	S0'	Е
0	0	0	0	0	0
0	0	1	0	1	0
0	1	0	0	0	0
0	1	1	1	0	0
1	0	0	1	1	0
1	0	1	0	0	0
1	1	0	0	0	0
1	1	1	1	1	1

	s1	s0
Estado 1	0	0
Estado 2	0	1
Estado 3	1	0
Estado 4	1	1

## Ecuaciones

S[1]' = S[0] & Q)   (S[1] & (~S[0]) & (~Q)
S[0]' = S[1] & S[0] & Q)   ( (~S[1]) & (~S[0]) & (Q) )   (S[1] & (~S[0]) & (~Q)
E = (S[1] & S[0] & Q)