MAINTENANCE TECHNICAL SUPPORT CENTER HEADQUARTERS MAINTENANCE OPERATIONS LINITED STATES POSTAL SERVICE

Maintenance Management Order UNITED STATES POSTAL SERVICE

SUBJECT: Induction Station Novasort Preventive **DATE:** December 18, 2013

Maintenance

NO: MMO-114-13

TO: All Novasort TMS Sites FILE CODE: TM

tpor:mm13048ad

This Maintenance Management Order (MMO) provides Operational and Preventive Maintenance Guidelines for the Induction Station Novasort System. This bulletin applies to Acronym IDUCT, Class Code CA.

The workhours indicated in the workload estimate (Attachment 1) reflect the *maximum* annual workhours required to maintain each system. Management may modify task frequencies to address local conditions.

The minimum maintenance skill level required to perform each task is included in the Minimum Skill Level column of each checklist. This does not preclude higher level employees from performing any of this work.

WARNING

Various products requiring Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available to all employees. When reordering such a product, it is suggested that current MSDS be requested. Refer to MSDS for appropriate personal protective equipment.

WARNING

The use of compressed or blown air is prohibited. An alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush must be used in place of compressed or blown air.

Web Access: https://www1.mtsc.usps.gov

WARNING

Steps contained in this bulletin may require the use of Personal Protective Equipment (PPE). Refer to the current Electrical Work Plan (EWP) MMO for appropriate PPE requirements.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Robert E. Albert

Manager

Maintenance Technical Support Center

HQ Maintenance Operations

- Attachments 1. Summary of Workload Estimate For Siemens TMS Induction Unit
 - 2. Siemens TMS Induction Unit Master Checklist 03-INDUCT-CA-001-M – Monthly PM
 - 3. Siemens TMS Induction Unit Master Checklist 03-INDUCT-CA-002-M – Quarterly PM
 - 4. Siemens TMS Induction Unit Master Checklist 03-INDUCT-CA-003-M -BI-Annual PM

ATTACHMENT 1

SUMMARY

WORKLOAD ESTIMATE

FOR SIEMENS TMS INDUCTION UNIT

Attachment 1 i

THIS PAGE BLANK

ii Attachment 1

SUMMARY WORKLOAD ESTIMATE FOR SIEMENS TMS INDUCTION UNIT

Operation	Routine Servicing (hrs/yr)	Repair* (hrs/yr)	Routine Servicing + Repair Time (hrs/yr)	Non- productive Time** (hrs/yr)	Total Servicing Per Machine (hrs/yr)
Monthly	11.80	3.54	15.34	1.53	16.87
Quarterly	2.67	0.80	3.47	0.35	3.82
Bi-Annual	1.13	0.34	1.47	0.14	1.62
Totals	15.60	4.68	20.28	2.03	22.31

NOTES:

^{*}Repair estimates based on 30% of servicing.

^{**}Based on 10% of total servicing and repair.

THIS PAGE BLANK

ATTACHMENT 2

SIEMENS TMS INDUCTION UNIT

MASTER CHECKLIST

03-INDUCT-CA-001-M

MONTHLY

Time Total: 59 minutes

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WC	RK DE			_		MENT NYM				CL/ CO		N	UMBE	₽R	TYPE
	0	3	I D U C T								С	Α	0	0	1	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGEMENT SYSTEM	Equ	pmer IN)N L	INIT		Ві			name 048ad		Occurr	ence MOI	NTH	LY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
Component		(Gomply with all carrent carety procedure)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.

SAFETY	1.	COMPLY WITH ALL SAFETY PRECAUTIONS.	3	All		
STATEMENT		Disconnect power and apply lockouts when				
		required by this instruction. Refer to current				
		local lockout procedures to properly shutdown and lockout this machine. Open				
		equipment and inspect dust conditions.				
		Check for suspicious dust or unusual debris.				
		If any unusual substance is found notify				
		supervisor prior to proceeding with any				
		further action on the equipment.				
		THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED.				
		When cleaning is required, an alternative cleaning method such as a HEPA filtered				
		vacuum cleaner or a damp rag must be used				
		in place of compressed or blown air. A lint-				
		free cloth or brush may be used on optical				
		equipment only when other cleaning methods cannot be used. Report safety deficiencies to				
		your supervisor immediately upon detection.				
		WARNING FOR EWP/PPE:				
		Steps contained in this bulletin may require				
		the use of Personal Protective Equipment				
		(PPE). Refer to the current Electrical Work Plan (EWP) MMO for appropriate PPE				
		requirements.				
	2.	Lockout Power.	2	All		
		Place appropriate PLC control panel				
		"AUTO/MANUAL" switch in the "MANUAL"				
		position. Lockout electrical power by placing the PLC disconnect lever in the "OFF" position and				
		install a LOCKOUT/TAGOUT device.				
		1				

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WORK EQUIPMENT CODE ACRONYM						•			CL/ CO	1	IUMB	ER	TYPE		
	0	3	B I D U C T								С	Α		0	1	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGMENT SYSTEM	Equi	Equipment Model INDUCTION UNIT						В	ulletin m ı		name 048ad		Occu		NTH	_Y

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	110	(comply with all outlette safety productions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
ACCESS PANELS	3.	Remove Conveyor Access Panels. Remove the conveyor side access panels / covers using a RITTAL key if necessary.	3	7			
BELT CONVEYOR	4.	Clean Belt Conveyor. 1. Check the transfer belt and wearing plates for dirt build up and clean if necessary. WARNING Discard or dispose of chemical soaked materials in accordance with MSDS and local procedures. 2. Using a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush, clean the belt conveyor framework and associated drive belt, idler rollers (pulleys), gear motor and drive pulleys. 3. Wipe off any excess oil / grime from the gear motor case.	8	7			
ROLLER CONVEYOR	5.	Clean Roller Conveyor. 1. Check the conveyor rollers for dirt build up and clean if necessary. WARNING Discard or dispose of chemical soaked materials in accordance with MSDS and local procedures. 2. Using a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush, clean the roller conveyor framework and associated drive belt, idler rollers (pulleys), gear motor and drive pulleys. 3. Wipe off any excess oil / grime from the gear motor case.	8	7			

U.S. Postal Service							IDE	ENTIFIC	ATI	ION						
Maintenance Checklist	WORK CODE			_		MENT NYM					ASS DE		N	JMBI	ΞR	TYPE
	0 3	I	D	U	C	T				С	A		0	0	1	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGEMENT SYSTEM	Equipmer IN	nt Mod IDU(N U	INIT		В	Bulletin I mm		name 048ad		Oc		ence MOI	NTH	_Y

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	NO	(Comply with all current salety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
INDUCITON BELT 2	6.	Clean Induction Belt 2. 1. Check the transfer belt and wearing plates for dirt build up and clean if necessary. WARNING Discard or dispose of chemical soaked materials in accordance with MSDS and local procedures. 2. Using a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush, clean the induction belt framework and associated drive belt, idler rollers (pulleys), gear motor and drive pulleys. 3. Wipe off any excess oil / grime from the gear motor case.	8	7			
INDUCTION BELT 1	6.	Clean Induction Belt 1. 1. Check the transfer belt and wearing plates for dirt build up and clean if necessary. WARNING Discard or dispose of chemical soaked materials in accordance with MSDS and local procedures. 2. Using a vacuum and/or low-pressure compressed air, clean the induction belt framework and associated drive belt, idler rollers (pulleys), gear motor and drive pulleys. 3. Wipe off any excess oil / grime from the gear motor case.	8	7			
PHOTO SENSOR AND REFLECTORS	8.	 Check Photo Sensors And Reflectors. Check the sensor exterior for physical damage. Check the mounting connections for tightness. If loose, align the photo sensor/reflector. Check the electrical connections for tightness. Report discrepancies to supervisor. 	3	7			

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WORK EQUIF						MENT NYM	•			CLASS CODE		1	IUMB	ER	TYPE
	0 3 I D U C				Т				C	Α	0	0	1	М		
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGMENT SYSTEM	Equ	Equipment Model INDUCTION UNIT						В	ulletin mr		name 048ad		Occu	rence MO	NTH	LY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
Сотронен	NO	(Comply with all current salety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
	9.	Clean Photo Sensors And Reflectors	3	7		T	
	0.	 Wipe the photo sensor window with a damp rag to remove dust and dirt. Wipe the reflector with a damp rag to remove dust and dirt. 	Ü	,			
ACCESS PANELS	10.	Replace Conveyor Access Panels. Replace the conveyor side access panels / covers.	3	7			
		WARNING Be cautious when working around or on equipment when power has been applied.					
	11.	Restore Equipment To Service.	2	All			
		Restore electrical power by removing your LOCKOUT/TAGOUT device and placing the PLC disconnect lever in the "ON" position. Place the PLC control panel "AUTO/MANUAL" switch in the "AUTO" position.					
INDUCITON	12.	Run Induction Unit.	5	7			
UNIT		WARNING					
		Do not wear loose fitting clothing, jewelry, ties, or other articles that could get caught in the machine. Keep hair away from all moving parts and belts.					
		 Start induction unit and visually check all induction belts for proper belt tracking. 					
		Check all four sections of the induction unit for drive and/or transfer belt slippage due to improper belt tension.					
		Listen for any unusual noise generated by conveyor operation.					
		4. Report discrepancies to supervisor.					
CLEAN-UP	13.	Clean-Up.	3	All			
		Ensure all tools, lubricants, rags, ect., are removed from the work area. Report all deficiencies to your supervisor.					

MMO-114-13 Maintenance Technical Support Center

U.S. Postal Service								IDE	NTIF	ICATI	ON					
	WC	RK			Е	QUIF	MENT	•			CLA	SS	N	JMBE	R	TYPE
Maintenance Checklist	CODE ACRONYM									CO	DE					
	0	3	3 I D U C T								С	Α	0	0	1	M
Equipment Nomenclature	Equipment Model Bulletin Filen								name	C	Occurrence					
SIEMENS (PHASE IIIA) TRAY	INDUCTION UNIT mm13048ad										MONTHLY			LY		
MANANGEMENT SYSTEM																

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Сотронот		(Comply war an outlon carety productions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.

Maintenance Technical Support Center MMO-114-13

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist	_	RK DE			_		MENT NYM	•			CLA CO		N	JMBE	R	TYPE
	0	3	ı	D	U	C	T				С	A	0	0	1	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGMENT SYSTEM	Equ	ipmer IN		del CTIC	DN L	INIT		В	ulletin m ı		name 048ad	1 -	Occurr	ence MON	NTHI	_Y

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	110	(Comply war an our on our or, productions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.

THIS PAGE BLANK

ATTACHMENT 3

SIEMENS TMS INDUCTION UNIT

MASTER CHECKLIST

03-INDUCT-CA-002-M QUARTERLY

Time Total: 40 minutes

U.S. Postal Service							IDE	ENTIFIC	CATI	ON						
Maintenance Checklist	WORK CODE					MEN ⁻				CLA CC	ASS DE		NUI	MBE	R	TYPE
	0 3	ı	D	U	С	Т				C	Α	()	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANAGEMENT SYSTEM	Equipmer IN		del CTIC)N L	JNIT		E	Bulletin mn		name 048ad		Occi			RTEF	RLY

		_					
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	NO	(Comply with all current safety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
SAFETY	1.	COMPLY WITH ALL SAFETY PRECAUTIONS.	3	All			
STATEMENT		Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.					
		THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED.					
		When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.					
		WARNING FOR EWP/PPE:					
		Steps contained in this bulletin may require the use of Personal Protective Equipment (PPE). Refer to the current Electrical Work Plan (EWP) MMO for appropriate PPE requirements.					
	2.	Lockout Power.	2	All			
		Place appropriate PLC control panel "AUTO/MANUAL" switch in the "MANUAL" position. Lockout electrical power by placing the PLC disconnect lever in the "OFF" position and install a LOCKOUT/TAGOUT device.					

U.S. Postal Service								IDE	NTIFI	CATI	ON					
Maintenance Checklist	CO	RK DE					MENT NYM	•			_	ASS DE	١	IUMB	ER	TYPE
	0	3	I	D	J	С	Т				С	Α	0	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGEMENT SYSTEM	Equi	ipmer IN)N L	JNIT		В	ulletin Mr		name 048ad		Occui (rence QUAI		RLY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Сотранен		(comply min an earlow calculation)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
BELT TENSIONS	3.	Check Belt Tensions. 1. Remove the appropriate access panels / covers.	10	7			
		 Visually check all transfer belts and drive belts for proper tensioning. Check for signs of slippage. 					
		3. Tension the belts, if necessary, by referring to the appropriate maintenance documentation.					
		Report discrepancies to supervisor.					
TRANSFER BELTS	4.	Inspect Condition Of Transfer Belts. 1. Inspect the following belts for cuts, frays, tears, and signs of excessive wear: a. Belt conveyor transfer belt. b. Induction belt 2 transfer belt. c. Induction belt 1 transfer belts. d. Replace if necessary, by referring to the appropriate maintenance documentation. 2. Reinstall the access panels / covers.	15	7			
		WARNING Be cautious when working around or on equipment when power has been applied.					
		Restore Equipment To Service. Restore electrical power by removing your LOCKOUT/TAGOUT device and placing the PLC disconnect lever in the "ON" position. Place the PLC control panel "AUTO/MANUAL" switch in the "AUTO" position.	2	All			

U.S. Postal Service								IDE	NTIFI	CAT	ON					
Maintenance Checklist	_	RK DE					MENT NYM	•			_	ASS DE	1	IUMB	ER	TYPE
	0	3	I	D	U	С	Т				C	Α	0	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANAGEMENT SYSTEM	Equ	ipmer IN)N L	JNIT		В	ulletin Mr		name 048ad		Occu		RTE	RLY

Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	s
Component	No	(Comply with all current safety precautions)	Time Req (min)	Skill Lev	Run Hours	Pieces Fed (000)	Freq.
INDUCTION	6.	Run Induction Unit.	5	7			
UNIT		WARNING					
		Do not wear loose fitting clothing, jewelry, ties, or other articles that could get caught in the machine. Keep hair away from all moving parts and belts.					
		Start induction unit and visually check all induction belts for proper belt tracking.					
		Check all four sections of the induction unit for drive and/or transfer belt slippage due to improper belt tension.					
		Listen for any unusual noise generated by conveyor operation.					
		4. Report discrepancies to supervisor.					
CLEAN-UP	7.	Clean-Up.	3	All			
		Ensure all tools, lubricants, rags, ect., are removed from the work area. Report all deficiencies to your supervisor.					

Maintenance Technical Support Center MMO-114-13

U.S. Postal Service								IDE	NTIF	CATI	ON					
Maintenance Checklist		RK DE			_		MENT NYM	•			CLA CO		N	UMBE	ER	TYPE
	0	3	I	D	U	С	Т				С	Α	0	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGEMENT SYSTEM	Equ	ipmer IN)N L	INIT		В	ulletin Mı		name 048ad		Occurr Q		RTEF	RLY

Ī	Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
	·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.

THIS PAGE BLANK

ATTACHMENT 4

SIEMENS TMS INDUCITON UNIT

MASTER CHECKLIST

03-INDUCT-CA-003-M BI-ANNUAL

Time Total: 135 minutes

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WORK EQUIPMENT CODE ACRONYM							CLASS CODE				NUMBER				TYPE
	0 3	I	D	U	С	Т				C	Α		0	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANAGEMENT SYSTEM	Equipment Model INDUCTION UNIT					E	Bulletin Filename mm13048ad						ence 3I-AI	NNU	AL	

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	NO	(Comply with all current safety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
SAFETY STATEMENT	1.	COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment. THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection. WARNING FOR EWP/PPE: Steps contained in this bulletin may require the use of Personal Protective Equipment (PPE). Refer to the current Electrical Work Plan (EWP) MMO for appropriate PPE requirements.	3	All			
	2.	Lockout Power. Place appropriate PLC control panel "AUTO/MANUAL" switch in the "MANUAL" position. Lockout electrical power by placing the PLC disconnect lever in the "OFF" position and install a LOCKOUT/TAGOUT device.	2	All			

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WORK EQUIF						•			CLASS CODE		NUMBER			TYPE	
	0	3	I	D	J	С	Т				С	Α	0	0	3	M
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANANGEMENT SYSTEM	Equ	Equipment Model INDUCTION UNIT				JNIT		В	ulletin Mr		name 048ad		Occu		NNL	AL

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Thresholds	S
отпропени	INU	(Johnsy William Guirent Salety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
INDUCTION UNIT GEAR MOTOR OIL	3.	Change Induction Unit Gear Motor Oil For All Motors. WARNING Handling of oil and waste oil should be in accordance with the MSDS (Material Safety Data Sheet) for that specific product. In addition all local, state, and federal regulations should be observed when storing and disposing of oil and associated waste. Supplies needed: Mobil Gear 630 (mineral oil), or equivalent Mobil Glygoyle 30 (synthetic oil), or equivalent CAUTION Do not mix synthetic lubricant with mineral based lubricant. Remove the appropriate access panels / covers. Remove the top vent plug on top of the gear box. Remove the bottom drain plug and drain the gear oil into an approved container. Replace the bottom drain plug. Remove the fill level plug. Fill gear box with Mobil Gear 630 (mineral oil), Mobil Glygoyle 30 (synthetic oil), or equivalent. Replace the fill level plug. Replace the top vent plug. Replace the bovent plug. Replace the top vent plug.	120	7			

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	WORK EQUIPMENT CODE ACRONYM							CLASS CODE				NUMBER				TYPE
	0 3	I	D	U	С	Т				C	Α		0	0	3	М
Equipment Nomenclature SIEMENS (PHASE IIIA) TRAY MANAGEMENT SYSTEM	Equipment Model INDUCTION UNIT					E	Bulletin Filename mm13048ad						ence 3I-AI	NNU	AL	

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	NO	(Comply with all current salety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
		WARNING Be cautious when working around or on equipment when power has been applied.					
	4.	Restore Equipment To Service. Restore electrical power by removing your LOCKOUT/TAGOUT device and placing the PLC disconnect lever in the "ON" position. Place the PLC control panel "AUTO/MANUAL" switch in the "AUTO" position.	2	All			
INDUCTION UNIT	5.	Run Induction Unit. WARNING Do not wear loose fitting clothing, jewelry, ties, or other articles that could get caught in the machine. Keep hair away from all moving parts and belts. Start induction unit and visually check all induction belts for proper belt tracking. Check all four sections of the induction unit for drive and/or transfer belt slippage due to improper belt tension. Listen for any unusual noise generated by conveyor operation. Report discrepancies to supervisor.	5	7			
CLEAN-UP	6.	Clean-Up. Ensure all tools, lubricants, rags, ect., are removed from the work area. Report all deficiencies to your supervisor.	3	All			