MAINTENANCE TECHNICAL SUPPORT CENTER / MAINTENANCE POLICIES & PROGRAMS ENGINEERING / UNITED STATES POSTAL SERVICE



Maintenance Management Order UNITED STATES POSTAL SERVICETM

SUBJECT: Preventive Maintenance Guidelines for

Enhanced Airline Assignment (EAA_AA)

NO: MMO-124-06

F3A

DATE:

TO: Maintenance Managers, All EAA Sites FILE CODE:

dgay:mm06105ad

MAINTENANCE MANAGEMENT ORDER

November 17, 2006

Daily Checklist, Item 6, substep 11 & 12 and Item 7, substep 5 & 6 have added information for checking the D&R label and Scale check.

This Maintenance Management Order (MMO) provides Preventive Maintenance (PM) Guidelines for the Enhanced Airline Assignment System (EAA_AA).

The workhours indicated in the workload estimate (Attachment 1) are based on a 16-hour operations window and reflect the *maximum* annual workhours required to maintain each system. Actual workhour requirements and the frequency of tasks are dependent on run time and pieces processed. Therefore, PM work hour requirements will vary day-to-day based on site specific machine utilization. Management may modify task frequencies to address local conditions.

The minimum maintenance skill level required to perform each task is included in the Minimum Skill Level column of each checklist. This does not preclude higher level employees from performing any of this work.

WARNING

Various products requiring Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available to all employees. When reordering such a product, it is suggested that current MSDS be requested. Refer to MSDS for appropriate personal protective equipment.

WARNING

The use of compressed or blown air is prohibited. An alternative cleaning method such as a HEPA filtered vacuum cleaner, a damp rag, lint-free cloth, or brush must be used in place of compressed or blown air.

Maintenance Managers are to use these Preventive Maintenance guidelines when preparing the route sheets for local maintenance personnel.

Web Access: http://mtsc.usps.gov/pdf/mmo/2006/mmo12406.doc

Direct any questions or comments concerning this bulletin to the HelpDesk, Maintenance Technical Support Center, P.O. Box 1600, Norman OK 73070-1600; telephone FTS 2000 (405) 573-2123 or toll free (800) 366-4123.

Earl J. Jones Manager Maintenance Technical Support Center Maintenance Policies and Programs

Attachments: 1. Summary Workload Estimate for Enhanced Airline Assignment

- 2. Enhanced Airline Assignment Daily Master Checklist 03-EAA-AA-001-M
- 3. Enhanced Airline Assignment Weekly Master Checklist 03-EAA-AA-002-M
- 4. Enhanced Airline Assignment Monthly Master Checklist 03-EAA-AA-003-M
- 5. Enhanced Airline Assignment Quarterly Master Checklist 03-EAA-AA-004-M

MAINTENANCE MANAGEMENT ORDER

ATTACHMENT 1

SUMMARY

WORKLOAD ESTIMATE

FOR

ENHANCED AIRLINE ASSIGNMENT SYSTEM

SUMMARY WORKLOAD ESTIMATE FOR ENHANCED AIRLINE ASSIGNMENT

	Routine		Routine Servicing +	Non-	Total Servicing		onal Mainte otal Servicii	
Operation	Servicing	Repair*	Repair Time	productive	Per Machine	1 Tour	2 Tours	3 Tours
	(hrs/yr)	(hrs/yr)	(hrs/yr)	Time**	(hrs/yr)	(hrs/yr)	(hrs/yr)	(hrs/yr)
				(hrs/yr)		00	00	00
5	135	41	176	18	194	194	194	194
6	156	47	203	20	223	223	223	223
7	177	53	230	23	253	253	253	253

NOTES:

MAINTENANCE MANAGEMENT ORDER

- *Repair estimates based on 30% of servicing.
- **Based on 10% of total servicing and repair.

ATTACHMENT 2

ENHANCED AIRLINE ASSIGNMENT DAILY MASTER CHECKLIST

03-EAA-AA-001-M

TIME TOTALS: (24) minutes

Refer to MS-242 if additional information is required.

U.S. Postal Service							IDE	NTIF	CAT	ON					
Maintenance Checklist	WC	RK DE			_	 MENT NYM	•			CLA CO	ASS DE	N	UMBE	ΞR	TYPE
	0	3	Е	Α	Α					Α	Α	0	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del			В	ulletin	Filer	name	I	reque	ency		
Enhanced Airline Assignment			Е	AA_	_AA			Λ	/M0	6105			D	AILY	•

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

SAFETY STATEMENT

1. COMPLY WITH ALL SAFETY PRECAUTIONS - 5 All

Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED -

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.

Machine

MAINTENANCE MANAGEMENT ORDER

2. POWER DOWN AND LOCK OUT POWER - 2 All

Power down the machine and lock out its Min electrical power as prescribed by the current local lockout instructions providing lockout/restore procedures.

Scanners

3. **CLEAN THE THREE SCANNER WINDOWS -** 3 6 Spray a lint free cloth with glass cleaner and Min

gently wipe the scanner window.

Machine 4. **CLEANING AND MAIL SEARCH** - 5 6

Vacuum each module of the EAA. Complete a Min mail search and return any found mail to the appropriate mail stream.

WARNING

Be cautious when working around or on equipment when power has been applied.

5. RESTORE EQUIPMENT TO SERVICE -

Restore equipment to service as prescribed by current local procedure providing lockout/restore

3

6

procedures.

U.S. Postal Service								IDE	NTIF	ICATI	ON					
Maintenance Checklist	_	DRK DDE					MENT NYM	•			CLA CO		N	JMBI	ĒR	TYPE
	0	3	Е	Α	Α						Α	Α	0	0	1	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				В	ulletir	n Filer	name		reque	ncy		
Enhanced Airline Assignment		EAA_AA							Ν	ИΜО	6105			D	AILY	

Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	s
Component	No	(Comply with all current safety precautions)	Time	Skill			
			Req	Lev	Run	Pieces	Weeks
			(min)		Hours	Fed	
						(000)	

Printer Applicator

5. TEST PRINTER LABEL APPLICATOR -

1 Min 8

1. Power off the printer.

- 2. Press and hold the Feed/Pause pushbutton while turning the printer on.
- Continue holding the Feed/Pause pushbutton until the Alert LED turns off (approximately 5 seconds).
- 4. Press the Apply pushbutton. A blank label will fall off the applicator arm as the printer tries to apply the label.
- 5. Press the Apply pushbutton again. A 4420 Hardware Configuration label will fall off the applicator arm as the printer tries to apply the label.
- 6. Inspect the ten lines running horizontally across the label for any white gaps.
- 7. Report all deficiencies to your supervisor.
- 8. Cycle the printer power.
- Wait five seconds and press the Apply pushbutton to remove any labels on the applicator arm.
- 10. Press the Online pushbutton.

NOTE

If discrepancies are found place the equipment out of service.

- 11. Place a calibrated known weight on the scale.
- 12. Ensure the scale is reading the correct weight± .05 pounds of calibrated weight.

Machine

MAINTENANCE MANAGEMENT ORDER

7. START EAA AND VERIFY OPERATION-

2 6 Min

3

. Start the EAA by pressing the Start System pushbutton.

- Check system for unusual noises and vibrations. Verify that system startup warning lamps and horns are functioning.
- 3. Verify the startup amber lamp turns off and the green lamp turns on.
- 4. Run a few trays or tubs to verify system operation.

MMO-124-06							M	1air	ntena	ance	e Tech	nnica	l Sup	por	t Ce	nter
U.S. Postal Service								IDE	NTIFIC	CATI	ON					
Maintenance Checklist	_	RK DE					MENT MYMC				_	ASS DE	N	UMBI	ĒR	TYPE
	0	3	Е	Α	Α						Α	Α	0	0	1	М
Equipment Nomenclature Enhanced Airline Assignment	Equ	Equipment Model EAA_AA						В	Bulletin M		name 6105	1	Freque	,	AILY	

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

NOTE

If discrepancies are found place the equipment out of service.

- Print a test label.
- Check the label quality to ensure it does not have any defects as described in MMO-012-09.

CLEAN-UP-

3 ΑII Min

NOTE

If problems are found and can be corrected on this tour generate a Reactive workorder and correct the problem. If the problem cannot be corrected on this tour generate a Corrective workorder so that the work can be scheduled.

Ensure all tools, lubricants, rags, etc., are removed from the work area. Report all deficiencies to your supervisor.

ATTACHMENT 3

ENHANCED AIRLINE ASSIGNMENT WEEKLY MASTER CHECKLIST

03-EAA-AA-002-M

TIME TOTALS: (27) minutes

Refer to MS-242 if additional information is required.

ΑII

U.S. Postal Service								I	DENTI	FICA	TION					
Matata and Oliver Had		PK			_	QUIF					CLA		N	UMBI	₽R	TYPE
Maintenance Checklist	CO	DE				ACR(NYNC	1			COI	DE				
	0	3	Е	Α	Α						Α	Α	0	0	2	M
Equipment Nomenclature	Equ	ipme	nt Mo	del					Bulletir	File	name	Fre	quenc	у		
Enhanced Airline Assignment			Е	AA_	AA				Λ	ИΜО	6105		1	WEE	KLY	′

ľ	Part or	Item	Task Statement and Instruction	Est.	Min		Thresholds	6
ı	Component	No	(Comply with all current safety precautions)	Time				
ı				Req	Skill	Run	Pieces	Weeks
ı				(min)	Lev	Hours	Fed	
							(000)	

SAFETY STATEMENT

1. COMPLY WITH ALL SAFETY PRECAUTIONS - 5

Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED -

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.

Machine

MAINTENANCE MANAGEMENT ORDER

- POWER DOWN AND LOCK OUT POWER -Power down the machine and lock out its electrical power source as prescribed by the current local lockout/restore procedures.

ΑII

6

2

Min

3

Min

Printer Applicator

- CLEAN PRINTHEAD AND LABEL MARK
 SENSOR A cleaning kit is available. For more
 information refer to MMO-004-03 or the most
 current MMO for cleaning kits for the thermo
 printers.
 - 1. Rotate the printhead lever clockwise (CW) until the printhead releases.
 - 2. Remove label stock.
 - 3. Remove dirt, adhesive, or debris from the bottom printhead print surface with a cotton swab and appropriate solution
 - Moisten a lint free cloth with an approved cleaning solution and clean roller surface to remove any adhesive and/or debris.
 - Moisten a cotton swab with appropriate cleaning solution and clean the Label Mark Sensor.

U.S. Postal Service								IDE	NTIF	ICATI	ON					
Maintenance Checklist	_	DRK DDE			_		MENT NYM	'			CLA CO		N	UMBI	ĒR	TYPE
	0	3	Е	Α	Α						Α	Α	0	0	2	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				В	ulletir	Filer	name	F	reque	ency		
Enhanced Airline Assignment		EAA_AA							Ν	/M0	6105			WE	EKL	Υ.

Ī	Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
	·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

Printer Applicator

MAINTENANCE MANAGEMENT ORDER

4. CLEAN PRINTER LABEL PATH AND LABEL 4 6
GAP SENSOR – Min

NOTE

The lower label guide is spring loaded and must be held open during cleaning process. Pull down lower label guide to access label path.

- 1. Pull down lower label guide to access label gap sensor.
- Moisten a cotton swab with an appropriate cleaning solution and clean label gap sensor.
- 3. Moisten a lint free cloth with appropriate cleaning solution. Clean lower label path.
- 4. Remove all traces of dust, paper, and adhesive from the material path with a soft bristle brush or vacuum cleaner.
- 5. Moisten a lint free cloth with appropriate cleaner and clean all flat surfaces in the label path, including the edge guide.
- 6. Release the lower label guide.
- 7. Reinstall the labels.
- 8. Rotate printhead lever counterclockwise (CCW) until it locks in place.

WARNING

Be cautious when working around or on equipment when power has been applied.

Machine 5. RESTORE EQUIPMENT TO SERVICE -

3 6 Min

Restore equipment to service as prescribed by current local procedure providing lockout/restore procedures.

Printer Applicator

TEST PRINTER LABEL APPLICATOR -

1 Min 8

- 1. Power off the printer
- 2. Press and Hold the Feed/Pause pushbutton while turning the printer on.
- Continue holding the Feed/Pause pushbutton until the Alert LED turns off approximately 5 seconds.
- 4. Press the Apply pushbutton. A blank label will fall off the applicator arm as the printer tries to apply the label.
- 5. Press the Apply pushbutton again. A 4420

U.S. Postal Service									IDENTIF	FICA [*]	TION					
	WC	PK			E	QUIF	MEN	Т			CLA	SS	N	JMBI	ĒR	TYPE
Maintenance Checklist	CO	DE				ACRO	NYNC	1			COI	DE				
	0	3	Е	Α	Α						Α	Α	0	0	2	М
Equipment Nomenclature	Equ	ipmeı	nt Mo	del					Bulletin	File	name	Fre	quenc	y		
Enhanced Airline Assignment			Е	AA_	ΔA				Ν	1M0	6105		'	WEE	KLY	′

Part or	Item	Task Statement and Instruction	Est.	Min		Thresholds	3
Component	No	(Comply with all current safety precautions)	Time				
			Req	Skill	Run	Pieces	Weeks
			(min)	Lev	Hours	Fed	
						(000)	

Hardware Configuration label will fall off the applicator arm as the printer tries to apply the label.

- Inspect the ten lines running horizontally across the label for any white gaps.
- 7. Report all deficiencies to your supervisor.
- 8. Cycle the printer power.
- 9. Wait five seconds and press the Apply pushbutton to remove any labels on the applicator arm.
- 10. Press the Online pushbutton.

Machine

- **CHECK E-STOPS -**
 - 2 6 1. Press the Start System pushbutton. Min
 - 2. Run a few trays.
 - 3. While the trays are processing, stop the system by pressing the E-Stop above the right angle transfer unit.
 - 4. Verify the red stack lamp illuminates.
 - Verify an E-Stop message displays on the LCD and the system stops immediately.
 - 6. Press the Start button. Verify the machine does not start.
 - 7. Reset E-Stop.
- **CHECK E-STOP AT INPUT -**

2 6

6

MAINTENANCE MANAGEMENT ORDER

Repeat step 7 for the E-Stop located at the input Min of the machine.

START EAA AND VERIFY OPERATION-

2 Min

- 1. Start the EAA by pressing the Start System pushbutton.
- Check system for unusual noises and vibrations. Verify that system startup warning lamps and horns are functioning.
- 3. Verify the startup amber lamp turns off and the green lamp turns on.
- 4. Run a few trays or tubs to verify system operation.
- 10. **CLEAN-UP -**

3 ΑII

Ensure all tools, lubricants, rags, etc., are Min removed from the work area. Report all deficiencies to your supervisor.

ATTACHMENT 4

ENHANCED AIRLINE ASSIGNMENT MONTHLY MASTER CHECKLIST

03-EAA-AA-003-M

TIME TOTAL: (25) minutes

Refer to MS-242 if additional information is required.

ΑII

								o		0 . 00.			о.		
U.S. Postal Service								IDENTIF	FICAT	ION					
Maintenance Checklist	_	RK DE					MENT DNYM			_	ASS DE	N	UMB	ER	TYPE
	0	3	Е	Α	Α					Α	Α	0	0	3	М
Equipment Nomenclature	Equipment Model							Bulleti	n File	name		Freque	ency		
Enhanced Airline Assignment	EAA_AA				_AA				MMC	6105			MOI	HTV	LY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
·		, ,	Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

SAFETY STATEMENT

1. COMPLY WITH ALL SAFETY PRECAUTIONS - 5

Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED -

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.

Machine

MAINTENANCE MANAGEMENT ORDER

2. POWER DOWN AND LOCK OUT POWER -

Power down the machine and lock out its electrical power as prescribed by the current local lockout instructions providing lockout/restore procedures.

Conveyors

CLEAN ROLLER AND O-RINGS -

Moisten a lint free cloth with appropriate cleaning solution and clean conveyor O-rings, rollers, and photo sensors. Visually check all rollers, belts, and photo sensors for worn or defective parts.

WARNING

Be cautious when working around or on equipment when power has been applied.

Machine

4. RESTORE EQUIPMENT TO SERVICE -

Restore equipment to service as prescribed by current local procedure providing lockout/restore procedures.

3 Min 6

2

Min

5

Min

ΑII

8

U.S. Postal Service							IDE	NTIFI	CATI	ON					
Maintenance Checklist	_	RK DE				QUIF ACRO				CLA CO		N	UMBE	ĒR	TYPE
	0	3	Е	Α	Α					Α	Α	0	0	3	М
Equipment Nomenclature	Equ	ipmeı	nt Mo	del			В	ulletir	Filer	name		reque	ency		
Enhanced Airline Assignment			Е	AA_	AA			N	ИΜО	6105		1	NON	ITHL	Υ.

Part or	Item	Task Statement and Instruction	Est.	Min.	-	Thresholds	3
Component	No	(Comply with all current safety precautions)	Time	Skill			
			Req	Lev	Run	Pieces	Week
			(min)		Hours	Fed	s
						(000)	

Scale 5. **CHECK SCALE –** 5 8
1. Press an E-Stop to prevent the conveyors Min

- 1. Press an E-Stop to prevent the conveyors from starting.
- 2. Change user to Maintenance and select Devices.
- Place the 50 pound weight in the center of the scale.
- 4. Press get weight and record weight.
- Place the weight at each corner of the scale above the load cells.
- Press get weight and record the weight at each corner.
- 7. Verify weight recordings are 50 pounds +/- 0.05.
- 8. If the weights are not within +/- 0.05, inform Supervisor.
- 9. Reset E-Stop and change user to Operator.

Machine 6. START EAA AND VERIFY OPERATION- 2 6

Start the EAA by pressing the Start System pushbutton.

Min

- 2. Check system for unusual noises and vibrations. Verify that system startup warning lamps and horns are functioning.
- 3. Verify the startup amber lamp turns off and the green lamp turns on.
- 4. Run a few trays or tubs to verify system operation.

7. **CLEAN-UP -** 3 All Ensure all tools, lubricants, rags, etc., are Min

removed from the work area. Report all

deficiencies to your supervisor.

U.S. Postal Service								IDEI	NTIF	ICATI	ION					
Maintenanae Chaoldiat	_	DRK					MENT	•				ASS	۸	IUMB	ER	TYPE
Maintenance Checklist	CC	DE				ACRO	MYNC				CO	DE				
	0	3	Е	Α	Α						Α	Α	0	0	3	М
Equipment Nomenclature	Equ	ipmer	nt Mo	del				Βι	ulletir	Filer	name		Frequ	ency		
Enhanced Airline Assignment			E	AA_	AA				N	/M0	6105			MOI	NTH	LY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

THIS PAGE BLANK

ATTACHMENT 5

ENHANCED AIRLINE ASSIGNMENT QUARTERLY MASTER CHECKLIST

03-EAA-AA-004-M

TIME TOTAL: (41) minutes

Refer to MS-242 if additional information is required.

ΑII

ΑII

6

8

2

Min

5

Min

Min

											A			• •		• • • • • • • • • • • • • • • • • • • •
U.S. Postal Service									IDE	NTIFICATIO	N					
Maintenance Checklist		RK DE					QUIPI CRO				_	LASS		NUM	BER	TYPE
maniteriarios oriconios	0	3	Е	Α	Α		CICO	INII	71		Α	A	0	0	4	М
Equipment Nomenclature Enhanced Airline Assignment	Equ	Equipment Model EAA_AA						E	Bulleti	n Filename MM061	05	1	Fr	equen QU	cy ARTEI	RLY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	٦	Threshold	ls
			Req (min)	Lev	Run Hours	Pieces Fed	Weeks
						(000)	

SAFETY STATEMENT

1. COMPLY WITH ALL SAFETY PRECAUTIONS -

Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shutdown and lockout this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.

THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED -

When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods cannot be used. Report safety deficiencies to your supervisor immediately upon detection.

Machine

MAINTENANCE MANAGEMENT ORDER

Power down the machine and lock out its electrical power as prescribed by the current local lockout instructions providing lockout/restore procedures.

Printer Applicator

- B. CLEAN INSIDE PRINTER APPLICATOR HOUSING -
 - Loosen latches on back panel and open
 - Clean all dust and debris using a soft bristle brush and vacuum cleaner.
 - 3. Close back panel and latch.

Machine

2

4. CLEAN INSIDE MACHINE CABINETS -

Open Main Power Cabinet, Computer cabinet and Cross Transfer Box. Clean all dust and debris using a soft bristle brush and vacuum cleaner. Close Main Power Cabinet, Computer Cabinet and Cross Transfer Box.

U.S. Postal Service								IDE	NTIF	CAT	ION					
Martin Committee		RK					MENT					ASS	N	UMBI	ĒR	TYPE
Maintenance Checklist	CO	DE				ACRO	MYNC				CC	DDE				
	0	3	Е	Α	Α						Α	Α	0	0	4	М
Equipment Nomenclature	Equipment Model							Е	Bulletin	Filer	name		Freque	ency		
Enhanced Airline Assignment	EAA_AA						Λ	/M0	6105		C	UAF	RTE	RLY		

I	Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
	·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

Machine

5. CLEAN COMPUTER CABINET FILTER -

3 8

- Remove metal filter screen from side of Min computer cabinet.
- 2. Wash metal filter screen with soap and water.
- Gently shake excess water from metal filter screen.
- Install metal filter screen on side of computer cabinet.

WARNING

Be cautious when working around or on equipment when power has been applied.

6. RESTORE EQUIPMENT TO SERVICE -

3 6 Min

Restore equipment to service as prescribed by current local procedure providing

lockout/restore procedures.

Conveyors

CHECK CONVEYORS' SPEEDS -Log on as Maintenance.

16 8

Min

- 2. Lock out the Input conveyor to the EAA.
- From Main screen select: CONVEYOR for the scale, staging, and processing zones and CROSS TRANSFER for the transfer zone.
- From CONVEYOR or CROSS TRANSFER press run to start conveyor to be checked.
- Measure roller speed by placing the tachometer wheel firmly against the roller near the center of the conveyor zone to be measured.
- 6. Verify the roller speed is 150 FPM +/- 5 FPM.
- Select STOP from the CONVEYOR or CROSS TRANSFER screen to stop the conveyors.
- 8. Measure each zone and verify roller speeds are 150 FPM +/- 5 FPM for every zone.
- 9. Return the EAA to normal operating condition.

Machine

3. START EAA AND VERIFY OPERATION-

2 6

Min

1. Start EAA by pressing Start System pushbutton.

- Check system for unusual noises and vibrations. Verify that system startup warning lamps and horns are functioning.
- 3. Verify the startup amber lamp turns off and

Attachment 5

MAINTENANCE MANAGEMENT ORDER

U.S. Postal Service									IDE	NTIFICATIO	N					
		RK					QUIPI		-			_ASS		NUM	BER	TYPE
Maintenance Checklist	CC	DE				Α	CRO	NYN	1		С	ODE				
	0	3	Е	Α	Α						Α	Α	0	0	4	M
Equipment Nomenclature	Equ	iipme	nt M	odel				Е	Bulleti	n Filename			Fre	equen	су	
Enhanced Airline Assignment			Е	AA_	AA					MM061	05			QU	ARTE	RLY

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Thresholds		
			Req (min)	Lev	Run Hours	Pieces Fed (000)	Weeks

the green lamp turns on.

- 4. Run a few trays or tubs to verify system operation.
- CLEAN-UP 3 All Ensure all tools, lubricants, rags, etc., are Min removed from the work area. Report all deficiencies to your supervisor.