Model Documentation of the:

Modular Multilevel Converter (MMC)

1 Nomenclature

1.1 Nomenclature for Model Equations

```
total stored energy (scaled by \frac{2}{3})
e_{s0}
        (vertical) difference between all upper and all lower arms (scaled by \frac{2}{3})
e_{d0}
        complex energy sum
\underline{e}_s
        complex energy difference
\underline{e}_d
        angle of rotating reference frame of \underline{e}_s and \underline{e}_d
        angular speed of the rotating reference frame
\omega
        DC voltage of the MMC
v_{DC}
        common-mode voltage
v_{y0}
        complex output voltage
\underline{v}_y
        voltage which drives the DC currents
v_{x0}
        voltage which drives the internal currents
\underline{v}_x
        grid voltage
        complex output current
        scaled version of DC current
        complex circulating current
        arm inductance
M_z
        mutual inductance
R
        resistance of the load
L
        inductance of the load
```

1.2 Nomenclature for Derivation

```
\begin{array}{lll} e_{z1}, \ \dots, \ e_{z6} & \text{arm energies} \\ i_{z1}, \ \dots, \ i_{z6} & \text{arm currents} \\ g_0, \ g_\alpha, \ g_\beta & \text{clark transform constants} \\ \underline{g}_{\alpha\beta} & \text{complex constant using } g_\alpha, \ g_\beta \ \text{and} \ \theta \end{array}
```

2 Model Equations

$$\dot{e}_{s0} = v_{DC} i_{s0} - \text{Re}(\underline{i} \, \underline{v}_{u}^{*}) \tag{1a}$$

$$\dot{e}_{d0} = -2v_{y0}\,i_{s0} - \operatorname{Re}(\underline{i}_s^*\,\underline{v}_{y\Delta}) \tag{1b}$$

$$\underline{\dot{e}}_s = v_{DC} \,\underline{i}_s - e^{-3j\theta} \,\underline{v}_y^* \,\underline{i}^* - 2\underline{i} \,v_{y0} - j\omega \,\underline{e}_s \tag{1c}$$

$$\underline{\dot{e}}_d = v_{DC} \underline{i} - e^{-3j\theta} \underline{i}_s^* \underline{v}_{y\Delta}^* - 2\underline{i}_s v_{y0} - 2i_{s0} \underline{v}_{y\Delta} - j\omega \underline{e}_d$$
 (1d)

$$\frac{d}{dt}\dot{i}_s = \frac{1}{L_z + M_z}(\underline{v}_x - j\omega(L_z + M_z)\,\underline{i}_s) \tag{1e}$$

$$\frac{d}{dt}i_{s0} = \frac{1}{L_z + M_z}v_{x0} \tag{1f}$$

$$\frac{d}{dt}\underline{i} = \frac{1}{L}(\underline{v}_y - (R + j\omega L)\underline{i} - \underline{v}_g)$$
(1g)

$$\dot{\theta} = \omega \tag{1h}$$

with

$$\underline{v}_{y\Delta} = \underline{v}_y - M_z(j\omega\underline{i} + \frac{d}{dt}\underline{i})$$
 (2)

Inputs: $\underline{v}_y, v_{y0}, \underline{v}_x, v_{x0}$

Parameters: $v_{DC}, \underline{v}_g, \omega, L_z, M_z, R, L$

Outputs: \underline{e}_s , e_{s0} , \underline{e}_d , e_{d0}

2.1 Assumptions

- 1. The cells of the arm k=1,2,...,6 are represented by one equivalent cell with the duty cycle $q_k \in [0,1]$ and a voltage $v_C k$ that accords the sum of the individual cells in the arm. This implies that the underlying problem of balancing the voltages within each arm has already been solved.
- 2. The load currents are assumed to be continuous, matched to the initial currents of the arm inductors, and satisfy the constraint $i_1 + i_2 + i_3 = 0$ caused by junction N.

2.2 Exemplary parameter values

Parameter Name	Symbol	Value	Unit
DC voltage	v_{DC}	300	V
grid voltage	v_g	235	V
angular speed	ω	100π	$_{\mathrm{Hz}}$
arm inductance	L_z	1.5	mH
mutual inductance	M_z	0.94	mH
load resistance	R	26	Ω
load inductance	L	3	mH

3 Derivation and Explanation

The six arm energies e_{z1} , ..., e_{z6} transformed into

$$e_{s0} = 2g_0 \left[(e_{z1}, e_{z3}, e_{z5})^T + (e_{z2}, e_{z4}, e_{z6})^T \right]$$
 (3a)

$$e_{d0} = 2g_0 \left[(e_{z1}, e_{z3}, e_{z5})^T - (e_{z2}, e_{z4}, e_{z6})^T \right]$$
 (3b)

$$\underline{e}_s = 2g_{\alpha\beta} \left[(e_{z1}, e_{z3}, e_{z5})^T + (e_{z2}, e_{z4}, e_{z6})^T \right]$$
(3c)

$$\underline{e}_d = 2\underline{g}_{\alpha\beta} \left[(e_{z1}, e_{z3}, e_{z5})^T - (e_{z2}, e_{z4}, e_{z6})^T \right]$$
(3d)

with use of the Clark Transform

$$T_{0\alpha\beta} = \frac{1}{3} \begin{pmatrix} 1 & 1 & 1 \\ 2 & -1 & -1 \\ 0 & \sqrt{3} & -\sqrt{3} \end{pmatrix} = \begin{pmatrix} g_0 \\ g_\alpha \\ g_\beta \end{pmatrix}$$
(4)

and $\underline{g}_{\alpha\beta} = e^{-j\theta}(g_{\alpha} + jg_{\beta}).$

The currents can be transformed as

$$i_{s0} = 2g_0 \left[(i_{z1}, i_{z3}, i_{z5})^T + (i_{z2}, i_{z4}, i_{z6})^T \right]$$
 (5a)

$$0 = g_0(i_1, i_2, i_3)^T (5b)$$

$$\underline{i}_s = \underline{g}_{\alpha\beta} \left[(i_{z1}, i_{z3}, i_{z5})^T + (i_{z2}, i_{z4}, i_{z6})^T \right]$$
 (5c)

$$\underline{i} = \underline{g}_{\alpha\beta} (i_1, i_2, i_3)^T. \tag{5d}$$

The voltages are transformed as

$$v_{x0} = g_0 \left[v_{DC}(1, 1, 1)^T - (v_{q1}, v_{q3}, v_{q5})^T - (v_{q2}, v_4, v_{q6})^T \right]$$
(6a)

$$v_{y0} = g_0 (v_{y1}, v_{y2}, v_{y3})^T \tag{6b}$$

$$\underline{v}_x = \underline{g}_{\alpha\beta} \left[v_{DC}(1, 1, 1)^T - (v_{q1}, v_{q3}, v_{q5})^T - (v_{q2}, v_4, v_{q6})^T \right]$$
(6c)

$$\underline{v}_y = \underline{g}_{\alpha\beta} (v_{y1}, v_{y2}, v_{y3})^T \tag{6d}$$

$$= \underline{g}_{\alpha\beta} \left[(v_{q2}, v_4, v_{q6})^T - (v_{q1}, v_{q3}, v_{q5})^T - (L_z - M_z) \frac{d}{dt} (i_1, i_2, i_3)^T \right].$$
 (6e)

References

[1] Fehr, H.; Gensior, A.: Improved Energy Balancing of Grid-Side Modular Multilevel Converters by Optimized Feedforward Circulating Currents and Common-Mode Voltage, IEEE 2018