

OPTION REMOCON

Delete Procedure for Option Remote Control Settings 1

Delete Procedure for Option Remote Control Settings 1

Delete the remote control settings registered to the Option Remote Control.

1. When the Option Remote Control is in standby mode (operation indicator LED is off),  press and hold the button for 4 seconds or more until the operation indicator LED turns blue.
2. Then, press and hold the "STOP" button  for 2 seconds or more until the operation indicator LED turns red.
3. After returning to standby mode (operation indicator LED is off), the deletion procedure is complete.

OPTION REMOCON

Delete Procedure for Option Remote Control Settings 2

Delete Procedure for Option Remote Control Settings 2

