

Turbo Timer Setup

Turbo Mode: (This feature requires door and e-brake input) This feature allows the user to activate Turbo Timer Mode with their Firstech remote or accessory. This will keep the engine running after removing the key for the specified time selected below. (Please check specific remote or accessory userâ€™s manual for steps to activate Turbo Timer Mode)

Step 1 - Controller Option Table Settings

Option 2-02 Turbo timer run times.

- **Setting 1** Off: (default)
- **Setting 2** 2 Minutes: This option allows for a 2 minute run time after Turbo Mode has been engaged.
- **Setting 3** 1 minute: This option allows for a 1 minute run time after Turbo Mode has been engaged.
- **Setting 4** 4 minutes: This option allows for a 4 minute run time after Turbo Mode has been engaged.

Parking brake input wire required

Door trigger required (drivers door as a minimum for proper operation)

Step 2 - User Operation

Once the controller has been programmed with run time the feature then can be turn on and off. To cycle this feature on or off:

- Press and release "trunk" + "key" buttons or press and release "III" + "IV" buttons
- One parking light flash for on
- Two parking light flashes for off

To engage, set the e-brake, remove key, exit vehicle, and lock with the Firstech remote or accessory.

Note: when using Turbo Mode with a manual transmission, the CM7 will not lock the doors automatically. Before the turbo timer expires, the system must be locked using the Firstech remote or accessory.