Details





VSA Modulator-Control Unit 46P Connector (Female) | Engine Compartment Wire Harness | PARK_LAMP



Below is the terminal side of the connector(s).

1	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	2	
	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38		
3	5	6]	3	9 4	0 4	1 4	2 4	3 4	4 4	5 4	6		7	8	4	
						<u> </u>				- 							1

No.	Color	Name						
1	WHT	+B_ABS/VSA_FSR(BLDN)						
3	RED	+B_ABS/VSA_MTR(BLDN)						
4	BLK	GND						
5	RED	EPB_R_ACT+						
6	BLK	EPB_R_ACT-						
7	GRN	EPB_L_ACT-						
8	YEL	EPB_L_ACT+						
13	BLU	IG1_VSA/ABS(BLDN)						
14	BRN	PARK_BUSY						
16	PNK	PARK_LAMP						
18	RED	CSS_SIG1						
20	WHT	F-CAN_H						
21	RED	F-CAN_L						
22	YEL	CSS_SIG2						
23	GRN	CSS_GND						
24	YEL	(NOT USED)						
25	GRN	(NOT USED)						
26	PUR	SW1						
27	LT_BLU	SW3						
28	GRN	SW4						
29	LT_GRN	SW6						
30	RED	BRK_DIAG						
33	WHT	CSS_5V						
34	PNK	BRK_LAMP						
36	PNK	REVERSE_SW						
38	WHT	REVERSE_SW_GND						
39	PNK	FR_R_ABS_SNSR-						
40	GRN	FR_R_ABS_SNSR+						
41	YEL	RR_L_ABS_SNSR-						
42	GRY	RR_L_ABS_SNSR+						
43	BLU	FR_L_ABS_SNSR-						
44	BRN	FR_L_ABS_SNSR+						
45	WHT	RR_R_ABS_SNSR-						
46	LT_GRN	RR_R_ABS_SNSR+						