

VAC Control Setup

VAC: determines the temperature at which the control unit will provide an output on any POC programmed with setting 22(VAC: Ventilation-Air Conditioning) which can be used to vent widows, activate AC controls, or cooling seats.

Step 1 - Controller Option Table Settings

Option 3-12: Activation temperature settings

- **Setting 1** 100°F: This option will provide a .5 second pulsed output
- **Setting 2** 90°F: This option will provide a .5 second pulsed output
- **Setting 3** 80°F: This option will provide a .5 second pulsed output
- **Setting 4** 90°F: This option will provide a latched output for the selected runtime (2-07)

Step 2 - User Operation

No action required from user to activate VAC control.