

Turbocharger Bypass Control Valve Inspection

Special Tool Required

Image	Description/Tool Number
	Vacuum Pump/Gauge, 0-30 inHg Snap-on YA4000B* or equivalent, commercially available

*Available through the Acura Tool and Equipment Program 888-424-6857

Inspection

1. Turbocharger Bypass Control Valve - Inspect

1. Disconnect the vacuum hose (A).
2. Connect the vacuum pump/gauge, 0–30 inHg to the vacuum hose. Apply vacuum to the turbocharger bypass control valve. Make sure the turbocharger bypass control valve moves. If the valve does not move, [replace the turbocharger](#).

