2017 Civic Type R

SHHFK8G7XHU202216

Keyless/Power Door Locks/Security System

Com	ponents
D CAN lunction	
B-CAN Junction	
Body Control Module	
Cable Reel	. 0 . 0
Driver's Door Lock Actu	lator & Key Cylinder
Driver's Door Switch	
Driver's Junction C	
Front Passenger's Doo	r Lock Actuator
Front Passenger's Doo	r Switch
Front Passenger's Pow	er Window Switch
Fuel Fill Door Lock Actu	uator
Gauge Control Module	1
Hood Latch Switch	
Horn (High)	
Horn (Low)	
Horn Switch	
IG1A Relay Circuit	
IG1B Relay Circuit	
IG2 Relay Circuit	
Keyless Buzzer	
Left Headlight	
Left Headlight	
Left Rear Door Lock Ac	tuator/Knob Switch
Left Rear Door Switch	,
Left Rear Turn Signal Li	ght
Power Door Lock Relay	Circuit (DR UNLOCK)
Power Door Lock Relay	· · · · · · · · · · · · · · · · · · ·
Power Door Lock Relay	, ,
Power Window Master	, ,
Right Headlight	
Right Headlight	
Right Rear Door Lock A	ctuator/Knob Switch
Right Rear Door Switch	· · · · · · · · · · · · · · · · · · ·
Di Li D. T. C.	

Right Rear Turn Signal Light

Tailgate Release Actuator Relay Circuit

Tailgate Latch

Fuses				
Fuses	Amp	Circuit	Component	Terminals
A1-5	30	+B IG Main2	IG1B; IG2 Relay	1; 1
A1-7	125	UH F/Box: Main Fuse	Fuses:	A: 18, 20, 24
A2-2	30	+B G Main1 (SMART)	IG1A Relay	1
A2-4	60	+B F/Box Main2	Fuses:	B : 15, 16, 28
A2-6	30	+B H/L Lo Main	Low Beam Relay x2	1, 3
A18	10	+B Back Up	BCM; Junc C;	C27; D2, E1, E2
GaugeCM; Pwr Win A1; 37				A1; 37
A20	10	+B Small (38250-TBA-ZY00-)	
A24	10	+B Horn	Bat Snsr; Horn Rly x2	1; 1, 3
В7	10	IG1 Meter (Smart)	Junc C; Gauge CM	A1, B2; A17
B8	20	IG1 Fuel Pump (Smart)	BCM; El. Steer Lock	E1; 12
В9	10	IG2 A/C	Junc C; Pwr Win	E4; 18
B12	10	R Side Door Lock	RF; RR Door Lock Act	4; 4
B13	10	L Side Door Lock	LR Door Lock Act	1
B15	20	+B AS P/W	RF Pwr Win Switch	1
B16	20	+B Door Lock	LF Unlock; Lock;	3 ,4; 3, 4;
Unlock; Hatch Rel Act 3, 4; 3, 4				
B25	10	LF Door Lock	LF Lock Act/Key Cycl	4
B26	10	L Side Door Unlock	RF & RR Lock Act	1; 1
B28	20	+B DR P/W	Pwr Win Mstr Sw	4
B38	10	L Side Door Lock	Fuel Lock Act; LR Lock Act	1; 4
B39	10	LF Door Unlock	LF Lock Act; Fuel Fill Act	1; 3
C26	10	L H/L LO Fuse	Left Hlight	4
C27	10	R H/L LO Fuse	Right Hlight	4

GND
G301
G302
G303
G304
G305
G401
G501
G502
G505
G601
G602
G603
G604

Relays Low Beam Horn Taillight