



Tx: jmp to 3V

Rx: jmp diode cathode 5V 1N5819

use thin version 1N5819, otherwise backside
column D6-D8 free for Bat

Tx potmeter/chan1 wired

RX servo connectors at bottom or wired

R(T)x (V)bat wired JST 2 pin red

Rx: C6-bat, vbat-jst

fritzing