

Installation of Muller Panda 2 DC

(all creases facing the same direction)

Code QC-MU/PA-FP-6-01-DC

30mm shafts with 80mm outer diameter creasing unit

Top shaft



Bottom shaft



Top shaft




Uses 2 x single wedge shaped crease ribs

Bottom shaft

Uses a 2 female channels





2 x Top Shaft Support Collars

Used to grip the sheets as the creases are applied

Aligning the Creasing units

With the crease ribs locked into the top crease units, align the **BOTTOM SHAFT** female channel units to the correct creasing position (left side being aligned with the edge of the clamp) and then tighten the fixing screws

Slowly lower the top shaft crease units making sure the top crease ribs locate into the female channel on the bottom crease unit.

DO NOT TIGHTEN TOP SHAFT FIXING SCREWS

Slowly run a sheet of cover stock through the Spine & Hinge units.

As the cover travels through the crease units the loose top crease units automatically centralise to the optimum creasing position.

With the cover stock still gripped between the crease units tighten the fixing screws.

The machine is now ready to test.