

| | | |
|---|---|---|
| [PARE] 1.5k R23 | [PARE] 100k (x2) R11-R12 | [PARE] 100n (x5) C2-C5, C11 |
| [PARE] 100p (x3) C1, C14, C20 | [PARE] 100u C100 | [PARE] 10k (x8) R4, R9-R10, R15, R18-R19, R25, R30 |
| [PARE] 10u (x2) C12, C22 | [PARE] 1M (x5) R1, R3, R16, R24, R26 | [PARE] 1N4148 (x4) D3, D5-D7 |
| [PARE] 1N5817 D100 | [PARE] 1k (x4) R2, R17, R22, R27 | [PARE] 1n C10 |
| [PARE] 1u (x4) C6-C7, C19, C21 | [PARE] 2.2k R8 | [PARE] 2.2u C13 |
| [PARE] 22k R7 | [PARE] 22n (x2) C8, C18 | [PARE] 2N5087 Q3 |
| [PARE] 2N5089 (x2) Q2, Q4 | [PARE] 2P4T SW1 | [PARE] 3.3n C17 |
| [PARE] 30p C15 | [PARE] 3mm D4 | [PARE] 4.7k (x3) R100-R102 |
| [PARE] 4.7u (x2) C9, C16 | [PARE] 47 R21 | [PARE] 470 R31 |
| [PARE] 470k (x3) R5, R28-R29 | [PARE] 47k (x3) R6, R13-R14 | [PARE] 560 R20 |

| | | |
|---|--|---------------------------------------|
| [PARE] A100K (x4) AMPLITUDE, BOOST, DISTORTION, FILTER | [PARE] B50K OCTAVE | [PARE] BS170 Q6 |
| [PARE] DIP Socket IC1 | [PARE] GE (x4) D1-D2, D8-D9 | [PARE] LM308 IC1 |
| [PARE] PF5102 (x2) Q1, Q5 | [PARE] Parentheses Fuzz P PCB | |