

ARMABOT


Low Profile Drive Installation Instructions



1. Assemble plates and bearings.


Observe plate differences: Front half of back plate as pictured has large holes at corners. Back half has tapped holes around bearing.






Observe plate differences: back half of front plate as pictured has large holes at corners.


2. Assemble Shafts.




3. Attach motors to back plate




4. Place pinions on motor shafts






5. Place shafts in back plate




6. Attach shifter cylinders




-See VEX/WCP instructions for details of shifter assembly. Not all components pictured.


7. Place motor shaft support plate



8. Place drive belt and pulleys



9. Place spacers and front plate, bolt together



Assembly bolts can also be used to mount gearbox.

