


ARMABOT Differential Swerve Drive P/N A0067 Installation Instructions


All screws with out a locking element need loctite.




All screws with out a locking element need loctite.









Module and pulleys hidden for clarity.



All screws with out a locking element need loctite.





All screws with out a locking element need loctite.