


Construction Manual



Welcome to the FABI

Construction Manual

This manual covers detailed step-by-step instructions for building the FABI alternative input system.

As additional tools you will need:

- a soldering iron with a fine tip
- sharp side-cutting pliers
- a PH/PZ screwdriver
- optionally a PCB holder

The required materials are:

- tin-solder (small diameter)

Legend



Solder



Clip with pliers



Attention: orientation of this part is important!





This part is done in this step




Part number for this step (see part overview on page 3)


Part Overview










































optional





















Copyright 2023, AsTeRICS Foundation, CC-BY-SA 3.0 office@asterics-foundation.org

Acknowledgements:

Futura fonts by www.onlinewebfonts.com (CC BY 3.0) Exclamation mark icon made by Pixel Buddha from www.flaticon.com
Parts of illustrations based on work of Moritz Schwarzl (moritz.schwarzl@gmx.at) and Fritzing parts.