

VALTRIX Diaphragm Valve Selection & Installation

VALTRIX diaphragm valves use a metal diaphragm to isolate the process medium from the actuator, providing leak-tight, particle-free flow control for UHP gas systems.

Series: DV12A manual diaphragm valve (FMR4 body, 1/4" VCR), DV22A and KF flange variants, pneumatic NC (normally closed) and NO configurations.

Installation: 1) Inspect packaging and cleanliness. 2) Connect with clean, torque-controlled VCR nuts using a new metal gasket. 3) For pneumatic valves, connect actuation air at the rated supply pressure. 4) Perform a helium leak test after installation.

Operating conditions: Max inlet 3500 psig (reducer series), media temperature -20 to 100 C. Always consult the product drawing before installation.

Parameter	Specification
Body material	316L SS (EP optional)
Connection	1/4" VCR face seal
Max inlet	3500 psig (manual series)
Leak rate	$\leq 4 \times 10^{-9}$ scc/s He
Cv	0.4 (DV12A series)