
SGL-T5 Flow Chart (REV01 - 2025_03_19)


Rev.	Date	Change Description	Approved by
00	シロントーロンーオロ	Redraw from "T1 Gas - Flow Chart (REV05 - 2024_08_18)" - The yellow boxes are edited or added.	Mohsen Saadatfard
01		Cover not Up Error is added on Water Fill Process - Some digital feedbacks and alarms have been added. The yellow boxes are edited or added.	Mohsen Saadatfard
	_		-

Notes


⁻Errors are not self-clear and need to be cleared by UI after the processed


⁻PID registers need to be set by UI according to the selected process -RTD sensor reading values lower than 32F and Higher than 500F will trigger sensor error





- During Pan moving Up/Down, UI checks the Up/Down limit Switches and will notice the end of the moving process.





- UI Should manage the Water Metter Counter (Register 9) and Water Meter Setpoint (Register 15)
- During Filling up, UI checks the Water Metter Counter and will notice the end of the filling.

