

Design Services Available

Acts like AC wave because PD.6 only remains on long enough PD.5 to read on. Change value of charge resistor for differnt sensors.

Diod discharges sensor fast when PD.6 drops.

Use low forward Volt drop

Calibrate by reading counts at 33%, 76%, 100%

Turn PD.6 on and inc counter in tight loop until PD.5 reads as On

info@correctenergysolutions.com