LoopRunner | Product and care guide

looprunner-guide | Version 1 | Applies in: DE, FR
Effective 2026-10-09 | English | Fictional training publication
Product: PRODUCT-LOOPRUNNER

Trail classification

LoopRunner is a trail model with a synthetic upper and rubber sole. Black and green are its catalog colors. Use it within the published recreational trail scope; no climbing, ice-traction or crampon-compatibility specification is supplied.

Sole care after use

Remove stones and dried mud with a soft brush or blunt cleaning tool. Keep sharp objects away from the rubber and seams. Clean the underside before the upper to avoid transferring dirt back onto the shoe.

Upper cleaning and drying

Wipe the synthetic panels with a damp cloth and mild soap. Avoid solvents, high-pressure water, machine washing and soaking. Open the tongue and dry the pair naturally in a ventilated room rather than on a radiator.

Before another outing

Check for sole separation and worn areas before use. This guide does not specify a waterproof membrane or guaranteed grip on wet rock. Try fit with the intended socks and consider the actual terrain and weather when choosing footwear.