MetroFlex Runner | Textile care guide

metroflex-care | Version 2 | Applies in: DE, FR
Effective 2026-10-09 | English | Fictional training publication
Product: PRODUCT-METROFLEX-RUNNER

Product construction

MetroFlex Runner has a textile upper and rubber sole. It is listed as a running style. Flexibility is a design description; the guide does not provide a quantified flexibility test or an injury-prevention claim.

Upper cleaning

Hand clean surface marks with a soft cloth and a small amount of mild soap. Test the cleaning solution on an inconspicuous area first. Do not immerse the assembled shoe or put it in a washing machine. Avoid stiff brushes on the textile upper.

Drying and storage

After cleaning, reshape the shoe lightly and air dry in a ventilated place. Do not place it on a heater or use a tumble dryer. Store only after it is dry; prolonged storage in a damp gym bag can retain moisture.

Fit questions

No published width measurement or model-specific size-conversion chart is available. A request such as "I am between two sizes" cannot be resolved from the material alone. Compare with the selling market's size guidance and check both feet during indoor try-on; this guide does not authorize a guaranteed fit recommendation.