	Specia	ROUTING:			3/35	Date		Caps	Snap	Coppe	Brazir	Flar		Ord	
	Special Notes / Instructions				38	Emp. Name	Mach. No.	Caps/Plugs	Snap Rings	Copper Tubing Flare Tubes	Brazing Rings	Flare Nuts		Order Otv	order No.
	ictions					Prod Hrs.		Do not req	Located on	Located on	Located on	Six digit no	Disting	4	
 Maintenance Tooling Setup FAIR Training Meeting 	Down Time Codes				10	Total Pcs.		Do not require traceability.	Located on the bag followed by "Lot Number."	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	10	401847
	odes					Cum	Setup Hrs.		ed by "Lo	l, starting	directly a	box labe	lity Num		
Submitted						Cum. Total			t Number	with the	bove the	el under b	bers		
Time Of Day						Down Time	Cycle Time		י וו	letter "M."	word "heat."	ox quantity.		devices, LLC	control
Approved Yes / No						Down Time Code					5.77			LLC	
Mtrl Check												•			
Rev Letter	First Part In		3			Notes	Pcs./Hr								Con
Inspector	t Inspection Record		SS										J-RING	01 2 1/4	Component(s)
				9			Thru- put/8hrs			T		0	>	T	near
Notes												3010100	Z Z	No(s)	near Lot/ Traceability
		0				Scrap							1		JIIILY
						Scrap Code									