BAZING DE			Specia	ROUTING:								1/7	Date			Cap	Snaj	Flare	Coppe	Brazii	Flar		Ord	Ord	Pa
USUCISE NOITO! IUUSE SINIZIVES			Special Notes / Instructions									SB	Emp. Name		Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.
OBD			ıctions					1					Prod Hrs.	Allegation		Do not req	Located on	Use their w	Located on	Located on	Six digit no	Disting		39	-70TT
	4 FAIR 5 Training 6 Meeting	 Maintenance Tooling Setup 	Down Time Codes									بو	Total Pcs.			Do not require traceability.	the bag follow	ork order num	the spool labe	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	12	396223	CC-4/T-/T-70TT
		Codes										Cum	Hrs.	Setup Hrs.	×	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	directly al	e box labe	blity Numl				
		Date Part Submitted										Cum. Total	No. of the last						bove the v	el under b	bers	devices, LLC		control	
		Time Of Day	17 6 3 18										Down Time	lime	Cycle		box label.	letter "M."	word "heat."	ox quantity.					
		Approved Yes / No											Down Time Code											LLC	
		Mtrl Check																			_		_		
			First Part In											Pcs./Hr	Pcs./Hr								110	Con	
		Inspector	Inspection Record										Notes								C35	C-RING	1102-17-1/4	Component(s)	·
						S.	11/1	1 1						put/8hrs	Thru-							7	Z	2	Heat Lot/
		Notes			b			3					Scrap			2					NIA	AIA	てヘカ	No(s)	Heat Lot/ I raceability
				-	1				-	\prod							_								
L													Scrap Code												