NORMAL CHECKLIST

Dec-2022

COCKPIT PREPARATION

A/C ACCEPTANCE ..... COMPLETED (BOTH)
FUEL QUANTITY ..... __KG/BALANCED
SEAT BELTS ..... ON
ADIRS ..... NAV
BARO REF ..... QNH__(BOTH)

BEFORE START

PARKING BRAKE ..... ON
T.O DATA ..... CONFIRMED (BOTH)
WINDOWS ..... CLOSED (BOTH)
PED ..... FLIGHT MODE (BOTH)
DOORS ..... CLOSED & ARMED
BEACON ..... ON

AFTER START

ANTI ICE ..... AS RQRD
ECAM STATUS ..... CHECKED
PITCH TRIM ..... ____%
RUDDER TRIM ..... NEUTRAL

TAXI

FLIGHT CONTROL ..... CHECKED (BOTH)
FLAPS SETTING ..... CONF___(BOTH)
FMA ..... READ (PF)
CHECKED (PM)
RADAR & PRED W/S ..... ON
ECAM MEMO ..... TO NO BLUE
EFB ..... AS RQRD (BOTH)

LINE-UP

CABIN ..... SECURED FOR TAKEOFF
T.O RWY ..... ___(BOTH)
TCAS ..... TA/RA
PACKS 1 & 2 ..... OFF

<<DEPARTURE CHANGE>>

RWY & SID ..... ____
FLAPS SETTING ..... CONF___(BOTH)
T.O DATA ..... CONFIRMED (BOTH)
FCU ALT ..... __

APPROACH

BARO REF ..... QNH__(BOTH)
SEAT BELTS ..... ON
MINIMUM ..... ___
AUTO BRAKE ..... AS RQRD
EFB ..... AS RQRD (BOTH)

LANDING

CABIN ..... SECURED FOR LDG
GO AROUND ALT ..... ___FT SET
ECAM MEMO ..... LDG NO BLUE
- *LDG GEAR DN*
- *SIGNS ON*
- *SPLRS ARM*
- *FLAPS SET*

PARKING

RADAR & PRED W/S ..... OFF
PARKING BRAKE ..... ON
ENGINES ..... OFF
EXT LIGHTS ..... OFF
FUEL PUMPS ..... AS RQRD
Y ELEC PUMP ..... OFF
PED ..... AS RQRD

SECURING THE AIRCRAFT

ADIRS ..... OFF
OXYGEN ..... OFF
EMER EXIT LT ..... OFF
EFBs ..... AS RQRD
BATTERIES ..... OFF

EMERGENCY LANDING
ALL ENG FAILURE

Apply the following if not able to maintain altitude after the loss of thrust near the ground.

DITCHING

APU ..... START
LANDING GEAR ..... UP
FLAPS LEVER 2
VAPP ..... DETERMINE

GW	40 t	50 t	60 t	70 t	80 t	90 t	95 t
VAPP	150 kt	150 kt	163 kt	173 kt	183 kt	193 kt	198 kt

DITCHING pb ..... ON

At 500 ft AGL or below:
BRACE FOR IMPACT ..... ORDER
For flare:
TOUCH DOWN AT MIN V/S
TARGET PITCH ATT 11°

At touchdown:
ALL ENG MASTERS ..... OFF
APU MASTER SW ..... OFF
EMER EVAC PROC ..... APPLY

FORCED LANDING

APU ..... START

FLAPS LEVER 2
VAPP ..... DETERMINE

SPLRS ..... ARM
At 1000 ft AGL at the latest:
LANDING GEAR ..... DOWN by GRVTY
At 500 ft AGL or below:
BRACE FOR IMPACT ..... ORDER
For flare:
TOUCH DOWN AT MIN V/S

At touchdown:
ALL ENG MASTERS ..... OFF
APU MASTER SW ..... OFF
EMER EVAC PROC ..... APPLY

EMER EVAC

AIRCRAFT/PARKING BRK ..... STOP/ON
ATC (VHF 1) ..... NOTIFY
CABIN CREW (PA) ..... ALERT
ΔP (only if MAN CAB PR has been used) ..... CHECK ZERO

- **If ΔP not at zero:**
  CAB PR MODE SEL ..... MAN
  V/S CTRL ..... FULL UP

ALL ENG MASTERS ..... OFF
ALL FIRE pb (ENGs & APU) ..... PUSH
ALL AGENTS (ENGs & APU) ..... AS RQRD

■ **If evacuation required:**
EVACUATION ..... INITIATE

■ **If evacuation not required:**
CABIN CREW AND PASSENGERS (PA) ..... NOTIFY