ME461 Laboratory Assignment 3 (Two Week Lab)

Hardware Interrupts, ADC (Analog to Digital Converter) and Sampling

Goals for this Lab Assignment:

- 1. Create a hardware interrupt (HWI) function associated with the conversion of an ADC sequence.
- 2. Understand sampling of a signal at a discrete interval
- 3. Demonstrate signal aliasing
- 4. Sample an audio signal sensed by a microphone
- 5. Design and Implement a Finite Impulse Response (FIR) low-pass filter and band-pass filter.

Reading before Lab

- 1. Read through this entire lab.
- 2. Find the full chapter 11 discussing the F28379D's ADC peripheral in the TMS320F28379D Technical Reference Guide just in case you need some extra detail. Also in this document, read through sections 3.4 through 3.4.5 which discuss Hardware Interrupt events on the F28379D. Table 3-2 is important when setting up Hardware Interrupts (HWI) so I have created a separate file with that table only.
- I have created a condensed version of the ADC peripheral that should explain the majority of the topics
 we need for this lab. <u>ADC Condensed Technical Reference Guide</u> These included sections and register
 descriptions, should give you an introduction to the ADC peripheral.
- 4. The EPWM5 peripheral, in this lab, will be used to signal the ADC when to convert instead of driving a duty cycle varying square wave. EPWM Condensed Technical Reference Guide.

Laboratory Exercises

Exercise 1: Using the ADC

For demonstrating more about the hardware interrupt (HWI), we will take advantage of the fact that each of the TMS320F28379D processor's ADC peripherals can generate an interrupt when its sequence of samples have been converted and stored in the results registers of the ADC peripheral. When the ADC conversion is complete, the F28379D will automatically stop the code it is currently processing and jump to the interrupt service routine (ISR) specified for the ADC. On completion of the ISR code, the program counter (PC) will automatically jump back to the code that was interrupted and resume processing.

There are four ADC peripherals in the F28379D, ADCA, ADCB, ADCC and ADCD. For this first exercise we will use ADCD and its channels ADCINDO, ADCIND1. ADCD is chosen here due to the location of its output pins on the

ME461, Lab 3 Page 1 of 12

F28379D Launchpad (Red Board). We will use the additional ADC peripherals in the next exercises and future labs.

Input pins, or channels, ADCIND0 and ADCIND1 are brought through a multiplexer inside the F28379D processor into the ADCD peripheral. The ADCD peripheral can only sample one of these voltage input pins at a time. So the multiplexer allows the ADCD sequencer to sample one channel and then when finished the sequencer can change the multiplexer so that the next channel can be converted. The sequencer can schedule up to 16 conversions each trigger. We are only going to setup two conversions, ADCIND0 and ADCIND1.

We will initialize ADCD to perform 12 bit ADC conversions. The range of input voltage for this ADC is 0 volts to 3.0 volts. So a 12 bit result equaling 0(decimal) indicates that 0.0 volts is on the ADC input pin. The maximum value of a 12 bit ADC result, 4095, indicates that 3.0 volts is on the ADC input pin. Hence, there is a linear interpolation between 0 and 4095 covering all the voltages from 0.0 to 3.0 volts with steps of 3.0V/4096 = .73mv. We will command ADCD to sample channels ADCIND0 and ADCIND1 in sequence. We will setup Start of Conversion 0 (SOC0) to convert ADCIND0 and SOC1 to covert ADCIND1. When SOC1 is finished converting the input voltage to its corresponding 12 bit value, hardware interrupt ADCD1 will be flagged for execution. You will write the hardware interrupt function that is called when ADCD1 is flagged. The conversion results will be stored in registers AdcdResultRegs.ADCRESULT0 and AdcdResultRegs.ADCRESULT1.

Your first task will be to build an application that samples ADC channels ADCINDO and ADCIND1 echoes these voltage values to the F28379D's DACA and DACB voltage outputs. There are quite a number of things to setup so I am giving you most of the code. You will need refer to the register descriptions to fill in the blanks. I also give you some commented out code that will help you in future exercises and labs to setup the other ADC peripherals.

1. We would like to command the ADCD peripheral to sample ADCIND0 and ADCIND1 every 1ms. There are a few ways to accomplish this, but for this lab we are going to use EPWM5 as just a timer (no duty cycle output) to trigger the ADCD conversion sequence. In main() add the following code and fill in the ???? blanks by studing the EPWM reference. Don't forget to copy EALLOW and EDIS.

EALLOW;

EPwm5Regs.ETSEL.bit.SOCAEN = 0; // Disable SOC on A group

EPwm5Regs.TBCTL.bit.CTRMODE = 3; // freeze counter

EPwm5Regs.ETSEL.bit.SOCASEL = ???; // Select Event when counter equal to PRD

EPwm5Regs.ETPS.bit.SOCAPRD = ???; // Generate pulse on 1st event ("pulse" is the same as "trigger")

EPwm5Regs.TBCTR = 0x0; // Clear counter

EPwm5Regs.TBPHS.bit.TBPHS = 0x0000; // Phase is 0

EPwm5Regs.TBCTL.bit.PHSEN = 0; // Disable phase loading

EPwm5Regs.TBCTL.bit.CLKDIV = 0; // divide by 1 50Mhz Clock

ME461, Lab 3 Page 2 of 12

```
EPwm5Regs.TBPRD = ???; // Set Period to 1ms sample. Input clock is 50MHz. // Notice here that we are not setting CMPA or CMPB because we are not using the PWM signal EPwm5Regs.ETSEL.bit.SOCAEN = 1; //enable SOCA EPwm5Regs.TBCTL.bit.CTRMODE = ???; //unfreeze, and enter up count mode EDIS;
```

2. Next we would like to setup ADCD so that it uses 2 of its 16 SOCs (Start of Conversions). These SOCs are used by the ADC sequencer to sample the ADC channels in any desired order and if necessary assign priority to certain SOCs. It can be very confusing for the first time user of this peripheral, but if we stick to the basics it is pretty straightforward. We are going to trigger SOC0 and SOC1 with the same EPWM PRD time event. When triggered, SOC0 has the higher priority so it will sample/convert its channel first and when complete SOC1 will sample/convert its channel. We will assign channel ADCIND0 to SOC0 and channel ADCIND1 to SOC1. These below initializations also setup ADCD to flag an interrupt when SOC1 is finished converting. This makes sense since we first want SOC0 to convert channel ADCIND0 and then the SOC1 to convert channel ADCIND1. This is the default order for the round robin sequencer. Some of the given code I found in an ADC example and it retrieves the default calibration values for the ADCD in the F28379D's read only memory (ROM). Add the following to main() filling in the appropriate blanks (???). Comment below should be very helpful.

EALLOW;

```
//write configurations for all ADCs ADCA, ADCB, ADCC, ADCD
AdcaRegs.ADCCTL2.bit.PRESCALE = 6; //set ADCCLK divider to /4
AdcbRegs.ADCCTL2.bit.PRESCALE = 6; //set ADCCLK divider to /4
AdccRegs.ADCCTL2.bit.PRESCALE = 6; //set ADCCLK divider to /4
AdcdRegs.ADCCTL2.bit.PRESCALE = 6; //set ADCCLK divider to /4
AdcSetMode(ADC ADCA, ADC RESOLUTION 12BIT, ADC SIGNALMODE SINGLE); //read calibration settings
AdcSetMode(ADC ADCB, ADC RESOLUTION 12BIT, ADC SIGNALMODE SINGLE); //read calibration settings
AdcSetMode(ADC ADCC, ADC RESOLUTION 12BIT, ADC SIGNALMODE SINGLE); //read calibration settings
AdcSetMode(ADC ADCD, ADC RESOLUTION 12BIT, ADC SIGNALMODE SINGLE); //read calibration settings
//Set pulse positions to late
AdcaRegs.ADCCTL1.bit.INTPULSEPOS = 1;
AdcbRegs.ADCCTL1.bit.INTPULSEPOS = 1;
AdccRegs.ADCCTL1.bit.INTPULSEPOS = 1;
AdcdRegs.ADCCTL1.bit.INTPULSEPOS = 1;
//power up the ADCs
AdcaRegs.ADCCTL1.bit.ADCPWDNZ = 1;
AdcbRegs.ADCCTL1.bit.ADCPWDNZ = 1;
AdccRegs.ADCCTL1.bit.ADCPWDNZ = 1;
AdcdRegs.ADCCTL1.bit.ADCPWDNZ = 1;
//delay for 1ms to allow ADC time to power up
DELAY_US(1000);
//Select the channels to convert and end of conversion flag
//Many statements commented out, To be used when using ADCA or ADCB
```

ME461, Lab 3 Page 3 of 12

```
//ADCA
//AdcaRegs.ADCSOC0CTL.bit.CHSEL = ???; //SOC0 will convert Channel you choose Does not have to be A0
//AdcaRegs.ADCSOC0CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcaRegs.ADCSOCOCTL.bit.TRIGSEL = ???;// EPWM5 ADCSOCA or another trigger you choose will trigger SOCO
//AdcaRegs.ADCSOC1CTL.bit.CHSEL = ???; //SOC1 will convert Channel you choose Does not have to be A1
//AdcaRegs.ADCSOC1CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcaRegs.ADCSOC1CTL.bit.TRIGSEL = ???;// EPWM5 ADCSOCA or another trigger you choose will trigger SOC1
//AdcaRegs.ADCINTSEL1N2.bit.INT1SEL = ???; //set to last SOC that is converted and it will set INT1 flag ADCA1
//AdcaRegs.ADCINTSEL1N2.bit.INT1E = 1; //enable INT1 flag
//AdcaRegs.ADCINTFLGCLR.bit.ADCINT1 = 1; //make sure INT1 flag is cleared
//ADCB
//AdcbRegs.ADCSOCOCTL.bit.CHSEL = ???; //SOCO will convert Channel you choose Does not have to be BO
//AdcbRegs.ADCSOC0CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcbRegs.ADCSOC0CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA or another trigger you choose will trigger SOC0
//AdcbRegs.ADCSOC1CTL.bit.CHSEL = ???; //SOC1 will convert Channel you choose Does not have to be B1
//AdcbRegs.ADCSOC1CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcbRegs.ADCSOC1CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA or another trigger you choose will trigger SOC1
//AdcbRegs.ADCSOC2CTL.bit.CHSEL = ???; //SOC2 will convert Channel you choose Does not have to be B2
//AdcbRegs.ADCSOC2CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcbRegs.ADCSOC2CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA or another trigger you choose will trigger SOC2
//AdcbRegs.ADCSOC3CTL.bit.CHSEL = ???; //SOC3 will convert Channel you choose Does not have to be B3
//AdcbRegs.ADCSOC3CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcbRegs.ADCSOC3CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA or another trigger you choose will trigger SOC3
//AdcbRegs.ADCINTSEL1N2.bit.INT1SEL = ???; //set to last SOC that is converted and it will set INT1 flag ADCB1
//AdcbRegs.ADCINTSEL1N2.bit.INT1E = 1; //enable INT1 flag
//AdcbRegs.ADCINTFLGCLR.bit.ADCINT1 = 1; //make sure INT1 flag is cleared
AdcdRegs.ADCSOCOCTL.bit.CHSEL = ???; // set SOC0 to convert pin D0
AdcdRegs.ADCSOCOCTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
AdcdRegs.ADCSOCOCTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA will trigger SOCO
AdcdRegs.ADCSOC1CTL.bit.CHSEL = ???; //set SOC1 to convert pin D1
AdcdRegs.ADCSOC1CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
AdcdRegs.ADCSOC1CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA will trigger SOC1
//AdcdRegs.ADCSOC2CTL.bit.CHSEL = ???; //set SOC2 to convert pin D2
//AdcdRegs.ADCSOC2CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcdRegs.ADCSOC2CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA will trigger SOC2
//AdcdRegs.ADCSOC3CTL.bit.CHSEL = ???; //set SOC3 to convert pin D3
//AdcdRegs.ADCSOC3CTL.bit.ACQPS = 14; //sample window is acqps + 1 SYSCLK cycles = 75ns
//AdcdRegs.ADCSOC3CTL.bit.TRIGSEL = ???; // EPWM5 ADCSOCA will trigger SOC3
AdcdRegs.ADCINTSEL1N2.bit.INT1SEL = ???; //set to SOC1, the last converted, and it will set INT1 flag ADCD1
AdcdRegs.ADCINTSEL1N2.bit.INT1E = 1; //enable INT1 flag
AdcdRegs.ADCINTFLGCLR.bit.ADCINT1 = 1; //make sure INT1 flag is cleared
EDIS;
```

ME461, Lab 3 Page 4 of 12

3. The initializations for DACA and DACB output are much simpler then the ADC. When setup as DAC outputs pins ADCINAO and ADCINA1 are DACA and DACB respectively. See Pinmux Table for pin location of DACA and DACB. In main() initialize the DACs with these lines of code:

```
// Enable DACA and DACB outputs
EALLOW;
DacaRegs.DACOUTEN.bit.DACOUTEN = 1;//enable dacA output-->uses ADCINAO
DacaRegs.DACCTL.bit.LOADMODE = 0;//load on next sysclk
DacaRegs.DACCTL.bit.DACREFSEL = 1;//use ADC VREF as reference voltage

DacbRegs.DACOUTEN.bit.DACOUTEN = 1;//enable dacB output-->uses ADCINA1
DacbRegs.DACCTL.bit.LOADMODE = 0;//load on next sysclk
DacbRegs.DACCTL.bit.DACREFSEL = 1;//use ADC VREF as reference voltage
EDIS;
```

While we are thinking of the DAC outputs, let's quick write to DAC output functions setDACA(float volt), setDACB(float volt). These take a float parameter that is a voltage value between 0.0V to 3.0V. The DAC register is 16 bits but only the bottom 12 bits are used since it is a 12 bit DAC. Therefore the DAC register is looking for a value between 0 and 4095, where 0 is 0.0V and 4095 is 3.0V. Copy these functions somewhere above main() and fill in the scaling.

```
//This function sets DACA to the voltage between 0V and 3V passed to this function.
//If outside 0V to 3V the output is saturated at 0V to 3V
//Example code
//float myu = 2.25;
//setDACA(myu); // DACA will now output 2.25 Volts
void setDACA(float dacouta0) {
    if (dacouta0 > 3.0) dacouta0 = 3.0;
    if (dacouta0 < 0.0) dacouta0 = 0.0;

    DacaRegs.DACVALS.bit.DACVALS = ???; // perform scaling of 0-3 to 0-4095
}

void setDACB(float dacouta1) {
    if (dacouta1 > 3.0) dacouta1 = 3.0;
    if (dacouta1 < 0.0) dacouta1 = 0.0;

DacbRegs.DACVALS.bit.DACVALS = ???; // perform scaling of 0-3 to 0-4095
```

4. Add your ADCD1 hardware interrupt function. A shell function definition is given below. *Note: The naming can get confusing here. There are ADCD inputs channels labeled ADCINDO, ADCIND1, ADCIND2, ADCIND3, etc and there are also four ADCD interrupts labeled ADCD1, ADCD2, ADCD3 and ADCD4.*Above in item 2 we setup ADCD1 interrupt to be call when two channels ADCIND0 and ADCIND1 are

ME461, Lab 3 Page 5 of 12

finished converting. You will be adding most of the remainder of your code for this exercise inside this ADCD1 hardware interrupt function. Perform the following steps:

- Create your interrupt function as a global function with "void" parameters and of type
 "__interrupt void" for example __interrupt void ADCD_ISR(void) { See shell below
- Put a predefinition of your ISR function at the top of your C file in the same area as the predefinitions of the CPU Timer ISRs.
- Now inside main() find the PieVectTable assignments. This is how you tell the F28379d processor to call your defined functions when certain interrupt events occur. Looking at Table 3-2 in the F28379d Technical Reference find ADCD1. You should see that it is PIE interrupt 1.6. Since TI labels this interrupt ADCD1, there is a PieVectTable field named ADCD1_INT. So inside the EALLOW and EDIS statement assign PieVectTable.ADCD1_INT to the memory address location of your ISR function. For example &ADCD ISR.
- Next step is to enable the PIE interrupt 1.6 that the F28379D associated with ADCD1. A little further down in the main() code, find the section of code of "IER |=" statements. This code is enabling the base interrupt for the multiple PIE interrupts. Since ADCD1 is a part of interrupt INT1, INT1 needs to be enabled. Well, Timer 0's interrupt is also a part of interrupt 1. So the code we need is already there "IER |= M_INT1;". You do though need to enable the 6th interrupt source of interrupt 1. Below the "IER |=" statements you should see the enabling of TINT0 which is PIEIER1.bit.INTx7. Do the same line of code but enable PIE interrupt 1.6.
- Now with everything setup to generate the ADCD1 interrupt, put code in your ADCD1 interrupt function to read the value of the ADCIND0 and ADCIND1 channels and echo their value to the DACA and DACB output channels. ADCIND0 and ADCIND1 are setup to convert the input voltage on their corresponding pin to a 12 bit integer. The range of the ADC inputs can be from 0.0V to 3.0V. So the 12 bit conversion value which has a value between 0 to 4095, linearly represents the input voltage 0.0V to 3.0V. The 12 bit conversion values are stored in the results registers, see below. Create two global int16_t results variables and two global float variables to store the scaled voltage values of ADCIND0 and ADCIND1. Once you have converted the ADCIND0 12 bit integer result value to voltage, pass that variable to the setDACA() function. Do the same thing with the ADCIND1 value to setDACB().
- Set UARTPrint = 1 every 100ms and change the code in the main() while loop so that your two ADC voltage values are printed to TeraTerm. Make sure to create your own int32_t count variable for this ADCD1 interrupt function. It is normally not a good idea to use a count variable from a different timer function.

ME461, Lab 3 Page 6 of 12

• As a final step, clear the interrupt source flag and the PIE peripheral so that processor will wait for the next interrupt flag before the ADC ISR is called again. The below code has many of these steps.

```
//adcd1 pie interrupt
__interrupt void ADCD_ISR (void)
{
   adcd0result = AdcdResultRegs.ADCRESULT0;
   adcd1result = AdcdResultRegs.ADCRESULT1;

   // Here covert ADCIND0, ADCIND1 to volts

   // Here write values to DAC channels

   // Print ADCIND0 and ADCIND1's voltage value to TeraTerm every 100ms

   AdcdRegs.ADCINTFLGCLR.bit.ADCINT1 = 1; //clear interrupt flag
   PieCtrlRegs.PIEACK.all = PIEACK_GROUP1;
}
```

5. Using this echo program, you can show the effects of sampling and signal aliasing. Have your TA show you how to connect the appropriate signals to your F28379D Launchpad board. Using both the PinMux table and the F28379D Launchpad schematic, connect the ADCINDO input to the function generator at your bench. Input a sine wave with amplitude 2.5 volts peak to peak and an offset of 1.5 volts. MAKE SURE to put the function generator in "High Z" output. Watch the DAC output on the oscilloscope. Vary the frequency of the input sine wave and demonstrate at what frequency the output begins aliasing. What do you notice about sampling of a sinewave at 10Hz, 100Hz, 250Hz, 500Hz, 900Hz and 990Hz? Demo to your TA.

Exercise 2: Discrete Filters

One big problem with analog signals is that electrical noise can be present in the signal. If the noise is large it can cause the sensed signal to be very poor for control and other applications. One way to handle this noise is to implement filtering algorithms to filter the noisy signal. For this lab we are going to design our filters in Matlab using the FIR1 function. There are many other functions in Matlab to design filters but we will just focus on FIR1. Before we get into the Matlab FIR designs, I want to implement the simplest FIR filter. A simple averaging filter. See the below code implementing a 5 tap averaging filter.

ME461, Lab 3 Page 7 of 12

```
//xk is the current ADC reading, xk 1 is the ADC reading one millisecond ago, xk 2 two milliseconds ago, etc
float xk = 0;
float xk 1 = 0;
float xk_2 = 0;
float xk = 0;
float xk_4 = 0;
//yk is the filtered value
float yk = 0;
//b is the filter coefficients
float b[5] = \{0.2,0.2,0.2,0.2,0.2\}; // 0.2 is 1/5<sup>th</sup> therefore a 5 point average
//adcd1 pie interrupt
interrupt void ADCD ISR (void)
    adcd0result = AdcdResultRegs.ADCRESULT0;
    adcd1result = AdcdResultRegs.ADCRESULT1;
    // Here covert ADCIND0, ADCIND1 to volts
    xk = ADCIND0 voltage reading;
    yk = b[0]*xk + b[1]*xk_1 + b[2]*xk_2 + b[3]*xk_3 + b[4]*xk_4;
    //Save past states before exiting from the function so that next sample they are the older state
    xk 4 = xk 3;
    xk 3 = xk 2;
    xk 2 = xk 1;
    xk 1 = xk;
    // Here write yk to DACA channel
    // Print ADCIND0 and ADCIND1's voltage value to TeraTerm every 100ms
    AdcdRegs.ADCINTFLGCLR.bit.ADCINT1 = 1; //clear interrupt flag
    PieCtrlRegs.PIEACK.all = PIEACK_GROUP1;
}
```

Implement this code/filter. With this filter running what happens when you increase the frequency of the of the input sine wave from the function generator? Also answer the question why the filter equations above would not have worked properly if the "Save Past States" statements would have been written in this order:

```
xk_1 = xk;
xk_2 = xk_1;
xk_3 = xk_2;
xk_4 = xk_3;
```

Show Your TA

Now let's use Matlab to design a bit better low-pass filter using the FIR1 function. In Matlab type

ME461, Lab 3 Page 8 of 12

b = fir1(4,.1) This designs a 4th order FIR (Finite Impulse Response) low-pass filter with cutoff frequency .1 of the Nyquist frequency. Remember that the Nyquist frequency is half the sample frequency. So here the sample frequency is 1000Hz so Nyquist is 500Hz. Therefore the cutoff frequency of this filter is 50Hz. So if we apply to this filter input frequencies from the function generator greater than 50 Hz the output amplitude will be attenuated (reduced) when compared to the input amplitude. To see how much attenuation you can plot the bode plot using the Matlab function "freqz(b)". In this bode plot the x axis is frequency scale such that 1 is Nyquist frequency. Implement this filter. Since this filter is the same order as your average filter already implemented, all you have to do is change the b coefficients. To copy the b coefficients to your C code use the function arraytoCformat in Matlab. This function is already on the PCs in the lab. If you would like to use it on your own PC download it here. Type arraytoCformat(b') and the coefficients will be printed out in a C array statement. Copy this into your C file to use instead of the 5 0.2 coefficients. Run this code and see if you think this filter works better than the average filter. **Show your TA.**

Now what if I ask you design a 21st order FIR filter with 75 Hz cutoff frequency? Or what if I ask for a 100th order filter? You would not want to type in all those past states xk_100, xk_99, xk_98, xk_97, etc. Instead, if your past states were an array, you could just change the size of the array and maybe a for loop length and your filter code would work after you copy the new b array from Matlab. So change your filter code so that the xk states are part of an array. First do this with your 4th order filter. When that is working implement a 21st order low-pass FIR filter with 75 Hz cutoff frequency. How does the 21st order filter compare to the 4th order filter? **Show your TA.**

Exercise 3: Sample the Microphone's signal and Demonstrate how Filtering Effects the Audio Signal Setup ADCB to sample the microphone's audio signal. ADCINB4 is connected to the audio signal from the microphone board. The microphone's output voltage ranges from approximately 0.5V to 2.5V so it is inside the ADC range of 0V to 3.0V. Setup ADCB very similar to ADCD in exercise 1 but here you will only need SOCO since there is only one ADC channel. You will have to find out the interrupt number for ADCB1 and enable it similar to how you enabled the ADCD1 interrupt. In order that the ADCD1 interrupt is not called for this exercise comment out the line of code from exercise 1 and 2 where you enabled interrupt 1.6. Sample the microphone at first every 0.25 milliseconds and echo the ADC voltage reading to DACA every sample. Demo to your TA. Using what you learned in Exercise 2 and that you are sampling at 4000Hz, design and implement a 31st order low-pass filter with cutoff frequency of 500Hz that filters the microphone signal. Send the filtered value to DACA to observe the output of the filter. Using your Cell phone, find an app that can generate tones. While playing a 1000Hz tone, place you phone close to the microphone. Observe what the filtered output looks like on the Oscilloscope. Try some other tones. Demo to your TA.

ME461, Lab 3 Page 9 of 12

Experiment with increasing the sample rate of your ISR sampling and filtering the audio signal with the same 31st order low pass filter. To see how fast the F28379D processor can sample and filter the microphone, we are going to use the logic analyzer to measure the time your code takes to process inside the ADCB1 interrupt function. To do this let's use LED2's pin GPIO52. Look through your code and make sure you are not turning off, on or toggling GPIO52. We are going to connect GPIO52 to the logic analyzers D0 input. To time the processing of your ADCB, when you first come into your interrupt function SET GPIO52. Then the last thing you do in your interrupt function before you exit is CLEAR GPIO52. Then measure the pulse width on the scope to see how long your code keeps you inside the interrupt function. Stay with the 31st order low-pass filter and first increase your sampling rate to 10KHz. Measure on the scope how long you are in the ISR. Then see how fast you can increase the sample frequency without skipping samples. **Demo to your TA.**

Change your sample rate to 50% of the fastest sample rate you found. Now switch your filter to a band-pass filter that only allows a certain range of frequencies through. Can you design a filter that can identify when a 800 Hz tone is played in the microphone? You may need to change the order of the FIR filter to create a better band-pass filter. **Demo to your TA.**

Take home Exercise: Joystick

Setup ADCA to sample the two rotation potentiometers of the small joystick. ADCINA2 is connected to one potentiometer and ADCINA3 is connected to the other potentiometer. As you move the joystick the voltage into the two ADC channels changes between 0 at 3.3V. (That's a bit of a problem because the ADC channels only go up to 3.0V but it should not be a big problem.) Setup ADCA very similar to ADCD in exercise 1. Sample the Joystick voltages every 1ms and filter the sample ADC readings with a 9th order FIR filter with 50Hz cutoff frequency. (Use Matlab's FIR1 function to design the filter.) Every 100ms print the filtered values of both rotations to Tera Term and demonstrate the voltages changing as you move the joystick.

Lab Check Off:

- 1. Demonstrate your sampled signal and signal aliasing.
- 2. Demonstrate your implemented 4th order averaging filter.
- 3. Demonstrate your implemented 4th order 50Hz cutoff filter.
- 4. Demonstrate your implemented 21st order 75Hz cutoff filter.
- 5. Demonstrate your Microphone signal echoed to DACA every .25 ms.
- 6. Demonstrate your Microphone signal filtering at a fast sample rate.
- 7. Demonstrate your Microphone signal filtered with a band-pass filter passing 800Hz.

Additional Questions

ME461, Lab 3 Page 10 of 12

- 1. Another useful filter design function in Matlab is "butter", which designs a Butterworth filter. It works very similar to "fir1" but designs an Infinite Impulse Response (IIR) filter. IIR filters use the past filtered states along with the previous sampled states. Write the C code that implements a second order IIR filter which has the discrete transfer function $\frac{b_0+b_1z^{-1}+b_2z^{-2}}{a_0+a_1z^{-1}+a_2z^{-2}}=\frac{y}{x}$. Have the coefficients of the numerator and denominator stored in two float arrays a[] and b[]. Make sure to write the code that saves the past states in the filter equation to get ready for the next sample period where the filter equations will be calculated again.
- 2. Compare this block of code, which was the code given in Exercise 2 for the 5 point FIR average filter

```
xk = ADCIND0 voltage reading;
yk = 0.2*xk + 0.2*xk_1 + 0.2*xk_2 + 0.2*xk_3 + 0.2*xk_4;
//Save past states before exiting from the function so that next sample they are the older state
xk_4 = xk_3;
xk_3 = xk_2;
xk_1 = xk_1;
xk_1 = xk;
with this code that implements a 5 point IIR average filter

xk = ADCIND0 voltage reading;
yk = 0.2*xk + 0.2*yk_1 + 0.2*yk_2 + 0.2*yk_3 + 0.2*yk_4;
//Save past states before exiting from the function so that next sample they are the older state
yk_4 = yk_3;
yk_3 = yk_2;
yk_2 = yk_1;
yk_1 = yk;
```

Why do I call this an IIR average filter? Show that the transfer function of the FIR average filter is tfFIR = tf([.2.2.2.2.2],[1000];

Show that the transfer function of the IIR average filter is tfIIR = tf(.2,[1 -.2 -.2 -.2 -.2],.001); Use the "bode" command in Matlab to compare the two filters bode(tfFIR,tfIIR). Which filter noticeably starts filtering lower frequencies sooner?

3. Go back to the code you developed for exercise 1 that just reads ADCIND0 and ADCIND1 and echoes their values to DACA and DACB. Change the code to do a different kind of averaging filter. Kind of a "burst of samples" filter. (This code does not have to be compiled. If there are small type Os I will not take off points.) Instead of only setting up SOC0 to sample ADCIND0 and SOC1 to sample ADCIND1 when triggered by EPWM5, change the code so that all SOCs, 0 through 15, are used. Have all even SOCs sample ADCIND0 and all odd SOCs sample ADCIND1. Each SOC should still be triggered by EPWM5 which times out each 1ms. With this modification, each .001 seconds ADCIND0 will be told to convert 8 times and ADCIND1 will be told to convert 8 ntimes. In the interrupt service routine for

ME461, Lab 3 Page 11 of 12

ADCD1 take the average of the eight readings for both channels to create a filtered sample of ADCIND0 and ADCIND1. Just include the code for the ADCD setup and ADCD1 ISR.

ME461, Lab 3 Page 12 of 12