

Troubleshooting Bluetooth Connection

AX16Pro Laptop

Technical documentation sample

Version	1.0
Date	August 2026
Platform	Windows 11
Device	ACEMAGIC AX16Pro Laptop

Purpose

This guide documents the troubleshooting steps used to restore Bluetooth functionality on an AX16Pro laptop running Windows 11. Windows 11 may not automatically install the correct Bluetooth driver for this model. This guide explains how to identify and install the correct driver.

Environment

Component	Configuration
Laptop	AX16Pro
Operating System	Windows 11
Bluetooth Adapter	Realtek Bluetooth Adapter

Symptoms

The AX16Pro laptop was experiencing a loss of Bluetooth functionality. Bluetooth devices could not be connected or used, and the Bluetooth hardware was not functioning as expected in Windows 11.

Device Manager was used to identify the affected hardware and determine whether the issue was related to the Bluetooth device or its installed driver.

Initial Checks

The following checks were performed to determine whether Bluetooth was disabled, unavailable, or experiencing a driver-related issue:

1. Opened **Device Manager** in Windows 11.
2. Located the system hardware entries related to Bluetooth and wireless connectivity.
3. Checked the Bluetooth device status for errors or missing hardware.

4. Confirmed that the Bluetooth hardware was associated with a **Realtek** wireless adapter.
5. Reviewed the available driver information to determine whether an appropriate Bluetooth driver was installed.

Driver Identification

The Bluetooth hardware was identified as a Realtek 8852BE wireless adapter. The installed driver was reviewed to determine whether Windows had assigned the correct driver to the hardware.

When the correct driver was not installed, the Bluetooth driver was obtained from the ACEMAGIC driver download page and installed using the files included in the downloaded package.

Troubleshooting Procedure

1. Run Windows Update and Troubleshooter

- Press the **Windows key + I** to open Settings.
- Select **Bluetooth & devices**.
- Try to connect a device, then select **troubleshooting**.
- Follow the steps prompted by the troubleshooter.

Note: If this fails, or these steps have already been completed, proceed to step 2.

2. Identify the Bluetooth adapter

- Press the **Windows key + X** to bring up the Quick Link menu.
- Select **Device Manager**.
- Select the **arrow** next to **Bluetooth** to expand the list of installed Bluetooth devices.
- Locate the Bluetooth adapter. If it is listed as **Generic Bluetooth Adapter**, the correct driver may need to be installed.

3. Acquire the correct driver

ACEMAGIC, the manufacturer of the AX16Pro laptop, provides drivers specific to its laptop models.

- Go to acemagic.com/pages/drivers-downloads
- Scroll down until you find the **AX16Pro Laptop**.
- Select **download**.
- Locate the downloaded **ZIP file**.
- **Right-click the ZIP file**.
- Select **Extract All**.
- Choose where to extract the files and select **Extract**.
- **Open** the extracted folder to locate the Bluetooth files.
- Select the folder named **6_8852BE**.
- Select the folder named **BT**.
- Ignore the folder named drivers and select **Install**.

4. Verify the correct driver is installed

Press the **Windows key + X** to bring up the Quick Link menu.

Select Device Manager.

- Select the **arrow** next to the **Bluetooth** icon to expand the list of installed Bluetooth devices.
- Confirm that the Bluetooth adapter is now listed as **Realtek Bluetooth Adapter**.

5. Connect a Bluetooth Device

- Make sure the device you are pairing with has Bluetooth enabled and is ready to pair.
- Click on the **notification area** on the bottom right of the screen.

Note: The notification area is located at the bottom-right of the taskbar and contains the Wi-Fi, sound, and battery icons.

- Select the **arrow** next to the Bluetooth icon to select **Manage Bluetooth devices**.
- Select your device to pair with the laptop.

6. Additional troubleshooting

Problem: Other Bluetooth devices cannot find the laptop.

Resolution: Allow Bluetooth devices to find this PC.

- Select the **notification area**, then select the **arrow** next to the Bluetooth icon.
- At the bottom of that window, select **More Bluetooth settings**.
- Select **View more devices**.
- Scroll down to **Related settings**.
- Select **More Bluetooth settings**.
- In the window that appears, make sure the box next to **Allow Bluetooth devices to find this PC** is checked. If it is not checked, select the checkbox.

Results

Installing the correct Realtek Bluetooth driver restored Bluetooth functionality on the AX16Pro laptop. After the driver was installed, the laptop was able to detect and connect to Bluetooth devices.