

Remote I/O Installation Procedure

Model Harbor IO-16 | Revision 1.0

Overview

The Harbor IO-16 mounts on a grounded DIN rail inside a rated enclosure.

Keep signal wiring separated from switching conductors throughout the cabinet.

DANGER: condition=cabinet is energized; consequence=fatal shock; avoidance=apply lockout

Installation task

- 1. Lock out cabinet power.
- 2. Mount the coupler.
- 3. Land and label field wiring.

Item	Requirement	Verification
DIN rail	Grounded	Continuity test
Clearance	25 mm	Visual check