

Network Troubleshooting Handbook

Model Relay NX-6 | Revision 1.0

Overview

The Relay NX-6 exposes a diagnostic status page on the isolated service network.

Test physical link state before changing addressing or transport settings.

CAUTION: condition=settings are changed; consequence=lost access; avoidance=export configuration

Connection troubleshooting

- 1. Inspect link indicators.
- 2. Ping the configured gateway.
- 3. Review bounded retry logs.

Symptom	Likely cause	Check
No link	Cable fault	Continuity
Timeout	Route missing	Gateway