E NO: 4 Solub 2 Longique a

Setup and configure a LAN Using Switch Ethernot Cabel in your labor

A Local was retwork refers to a retwork that connects devices within alimited area sweet as office, shoot

The enobles users to show data
resources including data printer &
internet access. LAN connects devices
to promote collaboration and transfer
informations between users, such as
computers, printers, servers and switches

How to sot up LDN

Heb 1. Plan & Dasy N an appropriate network topology taking into account network requirements & equipment beation.

8, 16 07 24 ports which is sufficient for network of those sizes. 24 ethornot

Step 3: Assign IP adobress to your PC

F) Log on to the dient com

(i) Click Notwork & internet Connections.

isi) Right clich Local does convedion (Dhorrd

Gro to properties -> Soled Internet Protocol (TCP IIP vy)

Click on proportion -> Select use the following.

1 b address

Step 4: Configure network switch

Connect computer toswitch

Step 3: Select folder - go to proportion -> click Sharing tab -> 8 have it with every one

Step 6: Try to access the shared Solder from other computers

IP Config

Node 1 IPV4 Address 10.1.1.1

Node 2 IPV4 Address 10.1.1.2

Outcome

The fib sont through click nun; [1)10.1.12 I wer [IRE (] is sent successfully.

