#### **Unit-I**

## Basic computer Organization

D.Venkata Vara Prasad
Professor
Dept. of Computer Science & Engg.
SSNCE



## Objectivies

- What is CA?
- Why CA?
- The Big Picture
- Performance



## CA...

What is a computer?

A *Computer* is a machine which solves problems for people written as programs.

It is a Electronic data processing machine which takes data as input processes it, performs necessary calculations, stores the results and outputs the results as when required.

What is a Program?

A *Program* is a sequence of statements/steps stating how to perform a task. For each step an arithmetic and logical operation is done. For each operation a different set of control signals is needed – i.e. an instruction.

An *instruction* can be machine language instructions or assembly language instructions or even high level language instructions.

#### What is Hardware?

- A *hardware* is something that is tangible.
- For e.g. CPU, Memory, I/O devices, Bus etc.

## What is Software?

- A software is a collection of programs.
- S/W system S/w & Appl s/w
- System s/w-
  - Ser of pgm designed to control the operation and extend the capability of computer system
  - compilers, linkers, loaders, assemblers
- Appl s/w -
  - It is a set of pgm designed to solve a specific problem
  - Banking s/w, payroll s/w

## What is firmware?

• A *firmware* is software embedded in hardware during manufacture. E.g. home appliances, etc

## What is CO?

- It deals with how features are implemented.
- Hidden from Programmer
- Information flow between components Example:
  - 1. Control signals
  - 2. Memory technology
  - 3. Interfaces
- It basically discuss how h/w components operates and how they are connected to form computer system.

## **Need for Computers**

- Automatic
- Speed
- Accuracy
- Diligence
- Versatility


## What is "Computer Architecture"

Computer Architecture = Instruction Set Architecture + Machine Organization

# What is Computer Architecture...

- is concerned with the structure and behavior of the computer as seen by the user/programmer. It includes attributes such as
- Instruction Formats
- Addressing Modes
- Instruction Sets
- I/O Mechanisms
- -- The number of bits used
- -- Techniques for Memory management
  For example, It is an architectural design issue whether the computer will
  have multiply instruction

# The Instruction Set: a Critical Interface



## Instruction Set Architectures

```
    Digital Alpha(v1, v3)

                                  1992-97
• HP PA-RISC
                                  (v1.1,
v2.0) 1986-96
Sun Sparc (v8, v9)
                                  1987-95
• SGI MIPS (MIPS I, II, III, IV, V) 1986-96
Intel(8086,80286,80386,
                                  1978-200x
 80486, Pentium, MMX, Pentium pro,
 Itanium...)
```

## Organization

- Capabilities & Performance
  - Characteristics of Principal Functional Units
  - (e.g., Registers, ALU, Shifters, Logic Units, ...)


## Organization

#### Logic Designer's View


**ISA Level** 

**FUs & Interconnect** 

- Ways in which these components are interconnected
- Information flows between components
- Logic and means by which such information flow is controlled.
- Choreography of FUs to realize the ISA
- Register Transfer Level (RTL)
   Description



## Forces on Computer Architecture



## Why do Computer Architecture?

- It's exciting!
- It impacts every other aspect of electrical engineering and computer science

## What does a CA Course Contain?

#### **Computer Architecture and Engineering**

Instruction Set Design

Interfaces

Compiler/System View

"Building Architect"

**Computer Organization** 

**Hardware Components** 

Logic Designer's View

"Construction Engineer"

## How to Approach CA?


- Components:
  - input (mouse, keyboard)
  - output (display, printer)
  - memory (disk drives, DRAM, SRAM, CD)
  - processor
  - network
- Primary focus: the processor (datapath and control)
  - implemented using millions of transistors
  - Impossible to understand by looking at each transistor

## Objective


After completing this Session you will be able to understand:


- ALU
- Control unit
- Memory
- •I/O

## **Basic Architecture**



## **Memory Organization**







larger, slower, cheaper

(Numbers are for a 21264 at 700MHz)


#### System Bus



## A Simplified Control Unit



## Internal organization of CU



# Generations of Computers

## First Generation (1945-54)

- Single CPU
- Accumulator based.
- Fixed point Execution
- All the operations.
- PC
- ALP and MLP
- Ex: ENIAC, Princeton IAS, IBM 701

## II Generation(1955-64)

- Index Register
- Fixed point and Floating point.
- Multiplexed Memory
- Batch Processing
- Subroutine and Libraries.
- IOP
- RTL

## II Generation (Contd..)

HLL such as FORTRAN, COBOL, ALGOL

• EX: IBM7090, UNIVAC LARC

## III Generation (1965-74)

- Pipelining
- Cache memory
- Virtual Memory
- Multiprogramming
- Time sharing
- Ex: IBM 360/370, CDC 6600/7600,TI ASC DE PDP8

## IV Generation (1975-90)

- Parallel Computers
- Shared Memory and Distributed Memory.
- Multiprocessing O.S (MACH)
- Ex:IBM3090,BBN TC 2000, VAX 9000
   CRAY X-MP

### V-Generation

- MPP
- Scalable
- Latency Tolerant
- Terra flops
- Heterogeneous Processing.
- Ex: KABRU, FUJITSU, PARAGON

## Addressing Modes

#### Addressing modes


Addressing mode	Example instruction	Meaning	When used
Register	Add R4,R3	Regs [R4] ←Regs [R4] + Regs [R3]	When a value is in a register.
Immediate	Add R4,#3	Regs [R4] ←Regs [R4] +3	For constants.
Displacement	Add R4,100(R1)	Regs[R4]←Regs[R4] + Mem[100+Regs[R1]]	Accessing local variables (+ simulates register indirect, direct addressing modes)
Register indirect	Add R4,(R1)	Regs [R4] ←Regs [R4] + Mem[Regs [R1]]	Accessing using a pointer or a computed address.
Indexed	Add R3,(R1 + R2)	Regs [R3] ←Regs [R3] +Mem [Regs [R1] +Regs [R2]]	Sometimes useful in array addressing: R1 = base of array; R2 = index amount.
Direct or absolute	Add R1, (1001)	Regs [R1] ← Regs [R1] + Mem[1001]	Sometimes useful for access- ing static data; address con- stant may need to be large.
Memory indirect	Add R1,⊕(R3)	Regs[R1]←Regs[R1] + Mem[Mem[Regs[R3]]]	If R3 is the address of a pointer $p$ , then mode yields $*p$ .

Autoincrement	Add R1,(R2)+	Regs [R1] ← Regs [R1] + Mem [Regs [R2]] Regs [R2] ← Regs [R2]+d	Useful for stepping through ar- rays within a loop. R2 points to start of array; each reference increments R2 by size of an element, d.
Autodecrement	Add R1,-(R2)	Regs [R2] ←Regs [R2] -d Regs [R1] ←Regs [R1] + Mem[Regs [R2]]	Same use as autoincrement. Autodecrement/increment can also act as push/pop to imple- ment a stack.
Scaled	Add R1,100(R2)[R3]	Regs [R1] ← Regs [R1] + Mem[100+Regs[R2] + Regs[R3]*d]	Used to index arrays. May be applied to any indexed addressing mode in some computers.

# Instruction formats at a glance

- Four address format
- Three address format
- Two address format
- Single address format
- Zero address format

#### **Instruction Set Architectures**



# Examples

Stack	Accum	ulator	Registe (registe	r er-memory)	Registe (load-s	
Push A	Load	A	Load	R1,A	Load	R1,A
Push B	Add	В	Add	R3,R1,B	Load	R2, B
Add	Store	C	Store	R3,C	Add	R3,R1,R2
Pop C					Store	R3,C

# **Instruction Types**

- A computer must have instructions capable of performing three types of operations.
- Data transfers instructions: Transfers information data from one location to another with out changing the binary information contents

Mnemonic	Meaning
LD	Transfers data from memory to processor register
ST	Transfers data from processor register to Memory
MOV between	Transfers data from one register to another Register it has also been used to transfer data cpu reg and memory (or) between
XCH	Two memory locations. Used to swap the data between two registers (or) between reg and memory vice versa.
IN OUT	Data transfers between the processor regis and input or output terminal.
PUSH POP	Transfers data between processor register and memory stack
	LD ST MOV between XCH IN OUT PUSH

• Data Manipulation Instructions: These are the instructions that perform arithmetic, logical and shift operations.

#### **Arithmetic operations:**

Name	Mnemonic	Meaning
Increment	INC	Increment the contents of a register
Decrement	DEC	Decrement the contents of a register
ADD	ADD	Add the contents of two registers (or) Contents of a register and memory.
Subtraction	SUB	Subtract the contents of two registers (or) Contents of a register and memory.
Multiply	MUL	Multiply the contents of two registers (or) Contents of a register and memory.
Divide	Div	Divide the contents of two registers (or) Contents of a register and memory.
Add with carry	ADDC	Add the contents of two registers with carry (or)Contents of a reg and memory with carry
Subtract with carry borrow.	SUBB	Sub the contents of two registers with borrow (or)Contents of a reg and memory with borrow
Negate	NEG	Perform 2' complementation on the given number

# **Logical Operations**

Name	Mnemonic	Meaning
Clear	CLR	Clear the contents of a register or Memory location
Complement	COM	Complement the contents of a register.
AND	AND	Perform logical AND operation
OR	OR	Perform logical OR operation
<b>Exclusive OR</b>	XOR	Perform logical XOR operation
Clear carry	CLRC	Clear the carry flag
Set carry	SETC	Set the carry flag.
Complement Carry	COMC	Complement the carry flag
Enable Interrupt	EI	Set the interrupt flag
Disable Interrupt	DI	Disable interrupt flag

# Shift operations

Name Mnemonics

Logical Shift Right SHR

Logical Shift Left SHL

Arithmetic Shift Left SHLA

Arithmetic Shift Right SHRA

Rotate Right ROR

Rotate Left ROL

Rotate Right Thru Carry RORC

Rotate Left Thru Carry ROLC

# **Program Control Instructions**

Name Mnemonics

Branch BR

Jump JMP

Skip


CALL

Return RET

Compare (By Subtraction) CMP

Test (By AND ing) TST

# Memory Operand Addressing



# Memory Operand Addressing...

	B31-b24	b23-b16	b15-b8	b7-b0
Big Endian	0	1	2	3
Little Endian	3	2	1	0

### Little Endian

0	b7-b0
1	b15-b8
2	b23-b16
3	b31-b24

# Big Endian

0	b31-b24
1	b23-b16
2	b15-b8
3	b7-b0

Ex: Intel series Ex: Motorola series

## Buses

- All the Functional units must be connected
- Different type of connection for different type of unit
  - Memory
  - Input/Output
  - CPU

# **Memory Connection**

- Receives and sends data
- Receives addresses (of locations)
- Receives control signals
  - Read
  - Write
  - Timing

# Input/Output Connection(1)

- Similar to memory from computer's viewpoint
- Output
  - Receive data from computer
  - Send data to peripheral
- Input
  - Receive data from peripheral
  - Send data to computer

# Input/Output Connection(2)

- Receive control signals from computer
- Send control signals to peripherals
  - e.g. spin disk
- Receive addresses from computer
  - e.g. port number to identify peripheral
- Send interrupt signals (control)

## **CPU Connection**

- Reads instruction and data
- Writes out data (after processing)
- Sends control signals to other units
- Receives (& acts on) interrupts

## Performance

- Measure, Report, and Summarize
- Make intelligent choices
- See through the marketing hype
- Key to understanding underlying organizational motivation

# Computer Performance: TIME, TIME, TIME

#### Response Time (latency)

- How long does it take for my job to run?
- How long does it take to execute a job?
- How long must I wait for the database query?

#### Throughput

- How many jobs can the machine run at once?
- What is the average execution rate?
- How much work is getting done?

## **Execution Time**

#### Elapsed Time

- counts everything (disk and memory accesses, I/O , etc.)
- a useful number, but often not good for comparison purposes

#### CPU time

- doesn't count I/O or time spent running other programs
- can be broken up into system time, and user time
- Our focus: user CPU time
  - time spent executing the lines of code that are "in" our program

# Book's Definition of Performance

- For some program running on machine X,
   Performance<sub>x</sub> = 1 / Execution time<sub>x</sub>
- "X is n times faster than Y"

   <u>Performance\_X</u>

   Performance\_Y = n

#### Problem:

- machine A runs a program in 20 seconds
- machine B runs the same program in 25 seconds

- Execution time = no. of clock cycles \* cycle time
- Execution time = no. of clock cycles
   Clock rate

#### But

no of clock cycles = Instruction count \* Average Cycles per Instruction

Execution time = I.C \* CPI \* Cycle time = I.C \* CPI clock rate

MOV AX,90

• MOV BX,50

ADD AX,BX

• STA AX,4500

• HLT

→ 2 Cycles

→ 2 Cycles

→ 1 Cycle

→ 3 Cycles

→ 1 Cycle

• CPI = 9/5 = 1.8

- Instead of reporting execution time in seconds, we often use cycles
- Execution time = I.C \* CPI \* Cycle time

```
<u>Seconds</u> = <u>instruction</u> * <u>cycles</u> * <u>seconds</u>
Program Program instruction cycles
```

- I.C => Instrn count (Dynamic Vs Static)
  - Dynamic I.C useful in performance (timing)
  - Static I.C useful in code size.

- Execution Time = I.C \* CPI \* Cycle Time
  - I.C → depends on ISA and Compiler tech
  - CPI → depends on ISA and organization
  - C.T → depends on organization and technology

 CPI – Avg Cycles Per Instruction(CPI) computed from the instruction mix.

ALU L/S Cond Uncond Jmp Jmp

Freq	40	25	20	15	CPI
cycles	4	5	3	2	

## Amdahl's Law

Execution Time After Improvement =

Execution Time Unaffected + Execution Time Affected Amount of Improvement

### Amdahl's Law

Speedup due to enhancement E:


Suppose that enhancement E accelerates a fraction F of the task by a factor S, and the remainder of the task is unaffected

# Amdahl's Law

ExTime<sub>new</sub> = ExTime<sub>old</sub> x 
$$(1 - Fraction_{enhanced}) + Fraction_{enhanced}$$
 Speedup<sub>enhanced</sub>

Speedup<sub>overall</sub> = 
$$\frac{\text{ExTime}_{\text{old}}}{\text{ExTime}_{\text{new}}} = \frac{1}{(1 - \text{Fraction}_{\text{enhanced}}) + \frac{1}{\text{Fraction}_{\text{enhanced}}}}$$
Speedup<sub>enhanced</sub>

# RISC Vs CISC




RISC	CISC
Reduced Instruction Set Computer	Complex Instruction set computer
Less number of instructions (64-100)	More number of instructions. (100-250)
Fixed length instruction formats (32 bits)	Variable length instruction formats (32 bits)
Limited addressing modes (3-5)	More addressing modes (12-24)

RISC	CISC
More no. of general purpose registers (32-192)	Limited no. of general purpose registers (8-20)
It employs H/w control organization.	It employs micro-program control organization. Recent architectures Employ h/w tech
It does not uses control memory	It uses control memory
Memory manipulation instructions are available	No memory manipulation instructions are available. Memory access is limited to simple LOAD/STORE instructions

RISC	CISC
Split caches were used	Unified cache was used. Now a days split caches were used
Clock speed (50-150Mhz in 1992)	Clock speed (33-50Mhz in 1992)
SPARC,DLX,MIPS architectures	Intel 80x86, Motorola MC68000 series

# Instruction Types of MIPS




Encodes: Loads and stores of bytes, words, half-words All immediates (rd <- rsl op immediate)


Conditional branch instructions (rs1 is register, rd unused)

Jump register, Jump and link register (rd = 0, rs = destination, immediate = 0)

# Instruction Types of MIPS (cont..)



## Instruction Types of MIPS (cont..)




#### 5-segment MIPS pipeline

- Instruction fetch cycle (IF)
- Instruction decode/register fetch (ID)
- Execution/Effective address cycle (EX)
- Memory access/branch completion (MEM)
- Write-back cycle (WB)

# Pipeline char diag

Instr Num	1	2	3	4	5	6	7	8	9
instr i	IF	ID	EX	MEM	WB				
instr i+1		IF	ID	EX	МЕМ	WB			
instr i+2			IF	ID	EX	MEM	WB		
instr i+3				IF	ID	EX	MEM	WB	
instr i+4					IF	ID	EX	MEM	WB

#### **MIPS Pipeline processor**



## Instruction Fetch Cycle

```
IR <- MEM[PC]
NPC <- PC +4
```

#### Instruction decode/register fetch (ID)

```
A <- Regs[IR6..10]
B <- Regs[IR11..15]
Imm <- ((IR16)16##IR16..31)
```

#### Execution/Effective address cycle (EX)

>Memory reference:

```
ALUOutput <- A +Imm
```

> Register-Register ALU instruction:

**▶** Register- Immediate ALU instruction:

```
ALUOutput <- A op Imm
```

> Branch:

```
ALUOutput <- NPC + Imm
Cond <- ( A op 0 )
```

# Memory access/branch completion cycle (MEM)

#### **Memory reference:**

LMD <- Mem[ALUOutput] or Mem[ALUOutput] <- B

#### **Branch:**

```
if (cond) PC <- ALUOutput
else PC <- NPC
```

# Write-back cycle (WB)

➤ Register-Register ALU instruction:

Regs[IR16..20] <- ALUOutput Register

> Immediate ALU instruction:

Regs[IR11..15] <- ALUOutput

> Load instruction:

Regs[IR11..15] <- LMD

#### Questions

- A memory unit with a capacity of 65,536 words of 25 bits each. It is used in conjunction with a general-purpose computer. The instruction code is divided into four parts an indirect mode bit, opcode, two bits that specify a processor register and an address part.
- what is the maximum number of operation that can be in the computer if the instruction is stored in one memory word.
- Draw the instruction word format indicating the number of bits and the function of each part.
- How many processor registers are there in the computer and how many bits in each. How many bits are there in MBR,MAR and PC

#### Questions

 what is the difference between a direct and indirect addressed instruction? How many reference are needed for each type of instruction if the instruction is in memory and to bring an operand in to a processor register.

Thank you