Connecting Dory (Receiver) to Raspberry Pi 4

B603 Lab

Indian Institute of Technology, Hyderabad.

November 23, 2021



- I Install PuTTY: sudo apt-get install -y putty
- 2 Open Putty from the terminal using the command: putty

Open a terminal on RPi4 and type the command:

- Isusb -t
- dmesg | grep tty (From here check the Rx Dory is connected to which port of RPi 4)
- Isusb /dev/tty* (Checking all the ports)



In the PuTTy configuration,

- Select the 'Serial' option.
- Baud rate/speed = 115200.
- Open.





Figure: PUTTY Configuration



Make the transmitter Dory in 'Fly' mode.

```
/dev/ttyUSB0 - PuTTY
                                                                                                        Y A X
SSI= -28, freq error = +15
C>>N608M158; 1424 1544 1008 1454 1010 1141
PWM_duty581
SSI= -28, freq error = +17
C>>NG08M159: 1424 1543 1009 1453 1010 1141
NM_dutu581
SSI= -28, freg error = -8
 >>N608M160: 1424 1544 1008 1453 1008 1143
PWM_duty581
RSSI= -28, freq error = +5
C>>N608M161: 1424 1545 1008 1453 1010 1142
PWM dutu581
RSSI= -28, freq error = +9
C>>N608M162: 1424 1545 1008 1453 1008 1143
PWM_dutu581
```

Figure: Serial Output of PUTTY for Rx. DORY

