Controlling UGV using Flysky Transmitter

B603 Lab

Indian Institute of Technology, Hyderabad.

November 23, 2021



Wiring Diagram

Wiring Diagram

■ Wiring diagram 1: Connection between Motor driver and ESP32

https://github.com/AnilMondedla/esp32/blob/main/ IDE/Toycar_with_Flysky/Figures/wiring.jpg

2 Wiring diagram 2: Connection between Flysky receiver and ESP32

Flysky-Rx pin	ESP32 pin
Channel 2	Pin-14
Channel 4	Pin-15
GND	GND
Vin	5v



Binding Tx. and Rx.

- Check the reference number of the receiver and transmitter. If they are same, then no need of binding.
- If the reference numbers are not same then binding of Rx and Tx is needed.



Binding Tx. and Rx.



Figure: Flysky Receiver




Figure: Flysky Receiver

Binding Tx. and Rx.

- Short the GND and CHANNEL pin of B/VCC of the receiver.
- Connect Vin pin with 5V pin of ESP32 and GND pin to GND pin of ESP32.
- Press the bind key of the transmitter.



Code

Flash the code from arduino IDE to ESP32. https://github.com/AnilMondedla/esp32/tree/main/ IDE/Toycar_with_Flysky/Codes

