



Peak Petroleum Industries Nigeria LTD
and
Equator Exploration Nigeria LTD

Offshore Nigeria Block OML 122

Bilabri D4
Addendum 1 to Well Plan REV 1
Setting 20" x 13-3/8" Surface Casing at
800m RKB

Drilling Unit
Semisubmersible Bulford Dolphin



Contents

- 1 Change in Setting Depth of Surface Casing
- 2 Surface Casing Cement Summary
- 3 Bilabri D2 - BHI LWD Log in 17-1/2" Hole Section

Signature Approvals:

Written By: Wali Adedotun Date: 09-10-2006
Wali Adedotun
Junior Drilling Engineer – Beta Development Team

Reviewed By: Robert Montgomery Date: 9 Nov 2006
Robert Montgomery
Drilling Project Manager – Beta Development Team

Approved By: Glyn Evans Date: 9 Nov 06
Glyn Evans
Project Director – Beta Development Team

Approved By: Billy Rant Date: 9 Nov 2006
for Dr. Kenneth Seymour
Project Adviser – Beta Development Team

Approved By: Billy Rant Date: 9 Nov 2006
Tony Gray or Bobby Roundtree
Drilling Superintendent – Beta Development Team



1. Change in Setting Depth of 20" x 13-3/8" Surface Casing

Discussion:

The 13-3/8" setting depth on Bilabri D4 will be +/-800m RKB (depending on the casing tally) due to the prognosed top of massive sand at 844m RKB.

The 17-1/2" hole will be drilled riserless to +/-815m RKB to give a 15m rathole below the 13-3/8" shoe.

2. Surface Casing Cementing Summary

20" x 13-3/8" Surface Casing @ 800m RKB

Casing Description: 20", 169#/ft, X-56, Tencom STD-R x 13-3/8", 68#/ft, K-55, BTC

Setting Depth: 800m (629m below mudline)

Top of Cement: Lead – Mudline
Tail – 150m above 13-3/8" shoe

Cement Weight: Lead - 12.0 ppg
Tail – 15.6 ppg

Cement Yield: Lead – 2.49 cu ft/sx
Tail - 1.20 cu ft/sx

Open Hole Excess: 100%

Cementing Details:

Cement with 5" drill pipe inner string 40m above 13-3/8" float collar

Run (2) joint shoe track

Do not run Bow Type Centralizers

Displace TOC to 20m above 13-3/8" float collar with 10.5 ppg WBM

Displace 10.5 ppg WBM out of 17-1/2" x 13-3/8" annulus before pumping spacer

Use 50 bbls of Seawater Spacer before pumping Lead Cement

Paint 13-3/8" shoe joints to aid in ROV observation

Paint and stripe 20" HPWHH to aid ROV observation

Use a drill pipe wiper dart to displace cement thru the 5" drill pipe cement stinger

Use 10.5 ppg water base mud to displace cement

BJ Cement Lab tests will be sent to rig before cement job



3. Bilabri D2 – BHI LWD Log in 17-1/2" Hole Section

Bilabri D2 – BHI LWD Log in 17-1/2" Hole Section

