Ccsds Downsampler Generator

Autocoder User Guide

1 Description

The purpose of this generator is to provide the user a way to define the packets that they would like downsampled. The generator takes a YAML model file as an input from which it constructs an Ada specification file that contains a list as the input parameter for initialization in the component. The component is required to know the Apid of the desired packets to be downsampled as well as the filtering factor to downsample the packets. The generator will also create data products of the filter factor for each of the specified Apids in the list.

Note the example shown in this documentation is used in the unit test of this component so that the reader of this document can see it being used in context. Please refer to the unit test code for more details on how this generator can be used.

2 Schema

The following pykwalify schema is used to validate the input YAML model. Model files must be named in the form <code>assembly_name.ccsds_downsampler_filters.yaml</code>. The <code>assembly_name</code> is the assembly which these packets will be downsampled in, and the rest of the model file name must remain as shown. Generally this file is created in the same directory or near to the assembly model file. The schema is commented to show what each of the available YAML keys are and what they accomplish. Even without knowing the specifics of pykwalify schemas, you should be able to gleam some knowledge from the file below.

```
# This schema describes the yaml format for the ccsds downsampler list of
    → filter factors with the associated APID.
    type: map
3
    mapping:
      description:
5
        type: str
6
        required: False
      # List of data products to include in the suite.
8
      downsampled_packets:
        seq:
10
           - type: map
11
            mapping:
12
               # APID of the packet that we are setting a filter factor for
13
               apid:
14
                 type: int
15
                 required: True
16
                 Filter factor of the packet
17
               filter_factor:
18
                 type: int
19
                 required: True
20
               # Name of the packet.
21
               packet_name:
22
                 type: str
23
```

```
required: False
24
                 Description if desired
25
               description:
26
                 type: str
27
                 required: False
28
         # A ccsds downsampler must have at least one packet to downsample.
29
         range:
30
31
          min:
         required: True
```

3 Example Input

The following shows an example input YAML model that is used in the unit testing for the down-sampler component. The example attempts to use all the variations of the optional inputs so that the user can see how they can use the options to generate their own desired input. Generally this file is created in the same directory or near to the assembly model file. This example adheres to the schema shown in the previous section, and is commented to give clarification.

```
description: Data products for the ccsds downsampler component.
2
    downsampled_packets:
3
      - apid: 100
        filter_factor: 0
        packet_name: First_Packet
        description: The first filter packet
      - apid: 200
8
        filter_factor: 3
9
        packet_name: Second_Packet
10
        description: The second filter packet
11
        apid: 300
12
        filter_factor: 1
13
        description: The unnamed filter packet
14
        apid: 400
15
        filter_factor: 4
16
        packet_name: Last_Packet
17
        apid: 500
18
        filter_factor: 2
19
```

As can be seen, specifying a packet to downsample simply consists of listing the Apid for that packet and the corresponding filter factor. There is also the capability to include a name which will be used as the name of the generated data product. If no name is specified, the generator will use a autogenerated name using the Apid.

4 Example Output

The example input shown in the previous section produces the following Ada output. The Downsample_List variable should be passed into the Ccsds Downsampler component's Init procedure during assembly initialization.

The main job of the generator in this case was to verify the input YAML for validity and then to translate the data to an Ada data structure for use by the component. The generator will also create data products as was mentioned before in this document

```
-- This file was autogenerated from
2
        /vagrant/adamant/src/components/ccsds_downsampler/test/test_assembly/test_d
    \  \, \rightarrow \  \, ownsample\_list.ccsds\_downsampler\_filters.yaml \ on \ 2022-04-01
3
4
    -- Copyright: The University of Colorado, Laboratory for Atmospheric and Space
    \hookrightarrow Physics (LASP)
6
    with Ccsds_Downsampler_Types; use Ccsds_Downsampler_Types;
8
   -- Data products for the ccsds downsampler component.
10
   package Test_Downsample_List is
11
      -- Size of the initial list of the downsampler
12
     Downsample_List_Size_In_Bytes : constant Natural := 20;
13
      -- The initial list for the downsampler
      Downsample_List : aliased Ccsds_Downsample_Packet_List := (
        -- First_Packet
16
        -- The first filter packet
17
        0 => (
18
         Apid => 100,
19
          Filter_Factor => 0
20
21
         -- Second_Packet
22
        -- The second filter packet
23
        1 => (
         Apid => 200,
         Filter_Factor => 3
26
27
        -- Apid_300
28
        -- The unnamed filter packet
29
        2 => (
30
         Apid \Rightarrow 300,
31
         Filter_Factor => 1
32
33
        ) ,
        -- Last_Packet
34
        3 => (
         Apid => 400,
          Filter_Factor => 4
37
38
        ) ,
        -- Apid_500
39
        4 => (
40
          Apid => 500,
41
          Filter_Factor => 2
42
43
        )
44
      );
      -- Access for the downsample list
      Downsample_List_Access : Ccsds_Downsample_Packet_List_Access :=
47
       → Downsample_List'Access;
48
    end Test_Downsample_List;
49
```