

Home Sewing Machine PARTS REFERENCE LIST

MODEL: XL2600/XL2610/XL2620/XL2650H

XL3500/XL3500T/XL3510/XL3520

BM2600/BM3500/XL3510T


L25/L35/L15/XL2620SE

CONTENTS

(1)	PRINCIPAL PARTS2
(2)	UPPER SHAFT / NEEDLE BAR, PRESSER MECHANISM4
(3)	FEED / FEED ADJUSTMENT MECHANISM 6
(4)	ZIGZAG / PATTERN SELECTION MECHANISM 8
(5)	BOBBIN WINDER / THREAD GUIDE MECHANISM 10
(6)	LAMP MECHANISM / MOTOR UNIT 12
(7)	ATTACHMENTS / PRINTED MATTER / PACKING MATERIALS14


(1) PRINCIPAL PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XC4846021	THREAD GUIDE ASSY			XC8979028	STITCH PATTERN SHEET (XL3510)	
2	085411416	TAPTITE BIND M4 x 14	1000003780		XC8979029	STITCH PATTERN SHEET (XL3520)	
3	188058121	SPOOL PIN			XC8979032	STITCH PATTERN SHEET (L35)	
4	XA0628021	SPOOL PIN SPRING			XC8979040	STITCH PATTERN SHEET (L15)	1000006061
5	XA8851121	SPOOL PIN STAND	050073		XC8979041	STITCH PATTERN SHEET (XL2620SE)	1000007330
6	XC4481121	BOBBIN PRESSER		15	XC4077021	BASE PLATE RUBBER	
7	XZ5031001	TAPTITE PAN P (S/P W) 3 x 12	060058	16	X53625121	UPPER COVER THREAD GUIDE	
8	138337022	RUBBER CUSHION A	050098	17	XA7769021	CUSHION	
9	026350235	WASHER, PLAIN M 3.5		18	XZ5049001	GIZA TITE (S/P W) 5X18	1000003021
10	083361216	TAPTITE, PAN B M3.5 x 12		19	XC6304021	GIZA TITE (S/P W) 3 x 25	
11	XC4077051	BASE PLATE RUBBER		20	XC4854021	FACE PLATE	
12	XC5261021	RING	1000001559	21	XC4855021	CUTTER COVER ASSY	
13	XC8977021	FRONT COVER ASSY	1000004242	22	X80321021	NT LOWER THREAD CUTTER	
		(XL2600:U.S.A., CAN, TWN)		23	138384021	RETAINING RING,CS5	
	XC8977027	FRONT COVER ASSY (BM2600)		24	XZ5031001	TAPTITE PAN B (S/P W) 3 x 12	060058
	XC8977033	FRONT COVER ASSY		25	XC6057020	GUARD PLATE	
		(XL2600:OTHER)		26	XA3337022	TAPTITE,CUP P M4 x 20	
	XC8977025	FRONT COVER ASSY (XL2610)		27	XC4857021	BASE COVER	
	XC8977026	FRONT COVER ASSY (XL2620)		28	084310815	TAPTITE, FLAT B M3 x 8	
	XC8977031	FRONT COVER ASSY (L25)		29	XC4858021	ACCESSORY TABLE	
	XC8977023	FRONT COVER ASSY		30	XC8981121	NEEDLE PLATE B ASSY	1000006517
		(XL3500:U.S.A., XL3500T)				(XL26**, XL35**, L15)	
	XC8977030	FRONT COVER ASSY (BM3500)			XC9849221	NEEDLE PLATE B ASSY	1000006517
	XC8977034	FRONT COVER ASSY (XL3500:OTHER)				(BM2600, BM3500, L25, L35)	
	XC8977028	FRONT COVER ASSY (XL3510)		31	XC4860121	NEEDLE PLATE B (XL26**, XL35**, L15)	1000006517
	XC8977029	FRONT COVER ASSY (XL3520)			XC3521121	NEEDLE PLATE B	1000006517
	XC8977032	FRONT COVER ASSY (L35)				(BM2600, BM3500, L25, L35)	
	XC8977039	FRONT COVER ASSY (XL2650H)	ADD	32	XC7371021	SLIDE BUTTON	
	XC8977037	FRONT COVER ASSY (XL3510T)	ADD	33	XC2367021	CUTTER COVER	
	XC8977040	FRONT COVER ASSY (L15)	1000006061			(BM2600, BM3500, L25, L35)	
	XC8977041	FRONT COVER ASSY (XL2620SE)	1000007330	34	XC2368021	SPRING PLATE	
14	XC8979021	STITCH PATTERN SHEET	1000004242	35	X80321021	NT LOWER THREAD CUTTER	
		(XL2600:U.S.A., CAN, TWN)				(BM2600, BM3500, L25, L35)	
	XC8979027	STITCH PATTERN SHEET (BM2600)		36	XD1648021	NEEDLE PLATE COVER SUPPLY ASSY	050259
	XC8979033	STITCH PATTERN SHEET		37	085411416	TAPTITE BIND B M4X14	
		(XL2600:OTHER)					
	XC8979025	STITCH PATTERN SHEET (XL2610)			XD0269021	HARD CASE ASSY (XL2650H)	ADD
	XC8979026	STITCH PATTERN SHEET (XL2620)			125440020	CASE FELT (XL2650H)	ADD
	XC8979031	STITCH PATTERN SHEET (L25)			XD0271021	MODEL MARK (XL2650H)	ADD
	XC8979023	STITCH PATTERN SHEET			XD0281020	UNDER CASE POLYSTYRENE (XL2650H)	ADD
		(XL3500:U.S.A., XL3500T)			X60439121	BAG,630X630T(XL2650H)	ADD
	XC8979030	STITCH PATTERN SHEET (BM3500)					
	XC8979034	STITCH PATTERN SHEET					
		(XL3500:OTHER)					




(2) UPPER SHAFT / NEEDLE BAR, PRESSER MECHANISM

2 X 3 0 4 0 5 X 6 X 7 X	(C3529021 014400432 012500532 (C4868020 (C3496021 (C4869021	SET SCREW, SOCKET (CP) M4 x 4 SET SCREW, SOCKET (FT) M5 x 5 UPPER SHAFT BEARING PRESSER	1000006160	40		PRESSER BAR (U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	1000004242
2 X 3 0 4 0 5 X 6 X 7 X	(C3529021 014400432 012500532 (C4868020 (C3496021 (C4869021	PULLEY SET SCREW, SOCKET (CP) M4 x 4 SET SCREW, SOCKET (FT) M5 x 5 UPPER SHAFT BEARING PRESSER	1000006160		VC4000021		
3 0 4 0 5 X 6 X 7 X	014400432 012500532 (C4868020 (C3496021 (C4869021	SET SCREW, SOCKET (CP) M4 x 4 SET SCREW, SOCKET (FT) M5 x 5 UPPER SHAFT BEARING PRESSER			VC4000031		
4 0 5 X 6 X 7 X	012500532 (C4868020 (C3496021 (C4869021 (C8984021	SET SCREW, SOCKET (FT) M5 x 5 UPPER SHAFT BEARING PRESSER			AC4090021	PRESSER BAR	
5 X 6 X 7 X	(C4868020 (C3496021 (C4869021 (C8984021	UPPER SHAFT BEARING PRESSER		41	XC4899121	PRESSER BAR CLAMP	050261
6 X	(C3496021 (C4869021 (C8984021			42	XC7207021	SCREW STUD M5	050037
7 X	(C4869021 (C8984021			43	XC4900021	SPRING	
-	(C8984021	GIZA TITE 5 x 16		44	XC3015031	PRESSER FEED HOLDER ASSY	1000003188
8 X		T BELT 420-5GT-6		45	132730122	TIGHTENING SCREW 3.57	
	14400806	TENSION PULLEY ASSY	1000003729	46	XC4901021	ZIGZAG PRESSER FOOT	060010
9 0.	771100000	SCREW, PAN (S/P WASHER) M4 x 8	1000003729	47	XC4902021	PRESSER FOOT LIFTER	
	<u> </u>	NEEDLE BAR, PRESSER MECHANISM		48	048040343	RETAINING RING, E4	1000001452
10 X	(E1295101	NEEDLE-PRESSER MODULE	1000004242	49	XC4903020	THREAD RELEASE LEVER	
		(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)		50	XC4904121	SPRING	
X	(E1746001	NEEDLE-PRESSER MODULE	060189	51	146200021	RETAINING RING, CS4	
11 X	(C4875221	BASE HOLDER ASSY	050255	52	XC6564020	THREAD POSITIONING PLATE	1000004242
12 X	(C6559021	NEEDLE HOLDER ASSY	1000004242			(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
		(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)		53	060260406	SCREW, BIND M2.6 x 4	
13 X	(C4880121	NEEDLE HOLDER SUB ASSY	060048			(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
14 0	18300636	BOLT, SOCKET M3 x 6		54	XC6566121	NEEDLE THREADING LEVER	1000004242
15 0	052300606	SCREW, PAN (S/P WASHER) M3 x 6				(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
16 X	(C2423021	NEEDLE BAR		55	0A5260606	SCREW,PAN(S/P WASHER)M2.6 x 6	
17 X	(C2424021	NEEDLE BAR THREAD GUIDE				(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
18 X	< 53053052	SCREW SM2.38		56	XA0445251	THREADER HOOK ASSEMBLY	1000004242
19 X	C2426020	NEEDLE THREAD PLATE				(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
20 X	(C2427051	NEEDLE BLOCK		57	037200516	TAPPING SCREW, PAN V M2 x 5	1000004242
21 X	C8563031	NEEDLE CLAMP SCREW	1000002936			(U.S.A., CAN, TWN, BM****, L25, L35, XL2620SE)	
22 X	(C4884021	NEEDLE HOLDER SHAFT		58	XC7525121	NEEDLE HOLDER STOPPER	
23 X	K56851021	LOCK NUT		59	XC4961021	GIZA TITE 5 x 20	
24 X	(C4885021	SPRING		60	XC4905121	ADJUSTING SCREW	060047
25 X	(C6562131	NEEDLE BAR CRANK ROD ASSY	1000004242	61	060302506	SCREW BIND M3X25	050143
26 1	132051022	SCREW, FLAT SM3.57-40 x 7 L		62	XC6056120	PLATE SPRING	060029
27 0)12400432	SET SCREW, SOCKET (FT) M4 x 4		63	XC4906020	ADJUSTING PLATE	
28 X	(C4888021	ZIGZAG ADJUST PLATE ASSY		64	085411416	TAPTITE, BIND B M4 x 14	
29 0	A5300806	SCREW, PAN (S/P WASHER) M3 x 8		65	XC4907021	LABEL	
30 X	(C4963020	NEEDLE BAR SUPPORTER ARM		66	052300606	SCREW, PAN (S/P WASHER) M3 x 6	050080
31 X	(C4891021	NEEDLE SHAFT HOLDER ASSY					
32 0	048020343	RETAINING RING, E2	1000001452	67	X53330020	WASHER	1000000655
33 0	18300636	BOLT, SOCKET M3 x 6					
34 X	(C4894021	STOPPER					
35 X	(C4895021	SHAFT					
36 X	(Z5030001	WASHER,SPRING	060059				
37 0	048050343	RETAINING RING, E5	1000001452				
38 X	(C8564031	THREAD TAKE-UP LEVER					
39 X	(C4897020	THREAD TAKE-UP LEVER LINK					




(3) FEED / FEED ADJUSTMENT MECHANISM

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
		FEED MECHANISM		35	XC6551021	SCREW, PAN (S/P WASHER) M4 x 22	
1	XE0093001	FEED MODULE (XL****, L15)		36	014400432	SET SCREW, SOCKET (CP) M4 x 4	
	XE0094001	FEED MODULE		37	XE3649001	INNER ROTARY HOOK BRACKET ASSY	1000004976
		(BM****, COMFORT 10, 15, 25, L25, L25, KOR, CHN)		38	052300606	SCREW, PAN (S/P WASHER) M3 x 6	
2	XC4909121	BASE PLATE ASSY	1000006200	39	XC4941021	LOWER SHAFT ASSY	
3	XC4914021	FEED ARM SUPPORTER		40	XC4943021	TIMING PULLEY D	
4	XC4915221	FEED DOG	1000006200	41	014500532	SET SCREW, SOCKET (CP) M5 x 5	
5	060300616	SCREW, BIND M3 x 6		42	X52664020	LOWER SHAFT BUSHING	
6	XZ5022101	FEED BAR ASSY	1000006200	43	X51383020	WASHER,THRUST	
7	120454021	RETAINING RING,CS3		44	048060346	RETAINING RING, E6	
8	XC4923020	HORIZOTAL FEED SHAFT		45	137768121	SET SCREW COLLAR	
9	048050346	RETAINING RING, E5		46	XC4944021	BUSHING PRESSER B	
10	130676121	SET SCREW COLLAR		47	085310615	TAPTITE, BIND B M3 x 6	
11	X50546020	WASHER,THRUST		48	025040332	WASHER, PLAIN L 4	
12	XC4924021	FEED ARM ASSY		49	146200021	RETAINING RING, CS4	
13	XC4927021	FEED SUPPORTING PLATE		50	X56655021	RETAINING RING: CSTW-3.5	
14	XC4928120	FEED SUPPORTING PLATE B	1000000733	51	060400816	SCREW, BIND M4 x 8	
15	137999020	POLYESTER SLIDER		52	XC6364021	SPRING	
16	XC4929020	FEED ADJUSTER		53	XC4948020	BUSHING PRESSER A	
17	XC4930121	FEED ADJUSTING SHAFT		54	XC3496021	GIZA TITE 5 x 16	
18	047201242	PIN, SPRING ROLL AW2		55	XC8993221	INNER ROTARY HOOK ASSY	1000004338
19	XC4931021	SPRING		56	X52800120	BOBBIN	
20	XZ5024001	VERTICAL ADJUSTER SCREW ASSY		57	XC3805021	GIZA TITE 5 x 16	
21	XC2546021	M5 NUT		58	XC8990121	NEEDLE PLATE A ASSY	
22	XC4935021	SPRING		59	XC4946221	NEEDLE PLATE A	
23	XC4936020	VERTICAL FEED SHAFT		60	XC8991120	STOPPER PLATE	
24	XC2551020	VERTICAL LEVER		61	XC8992121	F GEAR STOPPER PLATE	
25	048030346	RETAINING RING, E3		62	XD0196021	SCREW, BIND M2.6 x 3	
26	XC8987021	OUTER ROTARY HOOK ASSY		63	XD0060021	STOPPER PLATE B	
		(XL****, L15)		64	060300416	SCREW BIND M3X4	
	XD0115021	OUTER ROTARY HOOK ASSY		65	XD0059021	STOPPER PLATE L	
		(BM****, COMFORT 10, 15, 25, L25, L25, XL2620, KOR)		66	X50487051	SCREW M4	
27	XC0063021	MAGNET (XL****, L15)			T	FEED ADJUSTMENT MECHANISM	T
	XC0063051	MAGNET		67	XC4949020	FEED CONNECTING HOLDER	
		(BM****, COMFORT 10, 15, 25, L25, L25, XL2620, KOR)		68	XC9951021	FEED CONNECTING LEVER A	
28	XC8989020	WASHER (XL****, L15)		69	XC9952021	FEED CONNECTING LEVER B ASSY	
29	XD1943021	OUTER ROTARY HOOK SHAFT		70	XA1620021	ADJUSTING SCREW	
30	X53183021	WASHER (XL****, L15)		71	X56960021	NUT 4	
31	137805022	SPACER		72	060401416	SCREW, BIND M4 x 14	
		(BM****, COMFORT 10, 15, 25, L25, L25, XL2620, KOR)		73	021400205	NUT, 2 M4	
32	137976021	WASHER 6		74	XC3496021	GIZA TITE 5 x 16	
		(BM****, COMFORT 10, 15, 25, L25, L25, XL2620, KOR)		75	XC5062021	SPRING	
33	XC4937020	SHAFT SUPPORTER		76	048040346	RETAINING RING E4	
34	XC4938020	COLLAR					




(4) ZIGZAG / PATTERN SELECTION MECHANISM


No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
		ZIGZAG MECHANISM		40	048030343	RETAINING RING E3	1000001452
1	XC8996120	ZIGZAG LEVER A	050266	41	XC5029021	SPRING	
2	XC8998020	ZIGZAG LEVER B		42	060300616	SCREW BIND M3X6	
3	XC8999021	ZIGZAG LINK ROLLER SHAFT		43	X59905021	SPRING	
4	0A4400806	SCREW PAN (S/P WASHER) M4X8		44	XC3805021	GIZA TITE 5 x 16	
5	048030343	RETAINING RING E3	1000001452	45	XC5035020	SPACER	
6	048040343	RETAINING RING, E4	1000001452	46	XC5036020	WASHER	
7	XA4200021	SPRING		47	XC9064021	FEED DIAL	
8	137713020	POLYESTER SLIDER				(XL26**, BM2600, L25, COMFORT25,	
9	048025343	RETAINING RING E2.5	1000001452		XC9218221	FEED DIAL	050142
10	X50559020	ZIGZAG ADJUSTING NUT				(XL35**, BM3500, L35)	
11	062300806	SCREW PAN M3X8		48	048060343	RETAINING RING E6	1000001452
12	XC9002021	Z DIAL HOLDER ASSY		49	XC9074021	SELECTING DIAL	
13	XC9004021	Z DIAL		50	XC9075021	DECORATION PLATE	1000004242
14	048040343	RETAINING RING E4	1000001452			(XL2600:U.S.A. CAN, TWN)	
15	X56839021	NOTCHED SPRING			XC9075027	DECORATION PLATE (BM2600)	
16	085310615	TAPTITE BIND B M3X6			XC9075033	DECORATION PLATE (XL2600:OTHER)	
17	XC9006021	Z DIAL PIN			XC9075025	DECORATION PLATE (XL2610)	
18	XD1680021	Z DIAL CONNECTING ROD ASSY	050266		XC9075026	DECORATION PLATE (XL2620)	
19	048025343	RETAINING RING E2.5	1000001452		XC9075031	DECORATION PLATE (L25)	
20	XC3496021	GIZA TITE 5X16			XC9075023	DECORATION PLATE	
21	XC9008121	ZIGZAG LINK ASSY	DEL 050202			(XL3500:U.S.A., XL3500T)	
22	048050343	RETAINING RING E5	1000001452		XC9075030	DECORATION PLATE (BM3500)	
23	XC9011021	SPRING	DEL 050202		XC9075034	DECORATION PLATE (XL3500:OTHER)	
24	XC9012020	SPRING HOLDER			XC9075028	DECORATION PLATE (XL3510)	
		PATTERN SELECTION MECHANISM	•		XC9075029	DECORATION PLATE (XL3520)	
25	XC9013021	SELECTING UNIT ASSEMBLY			XC9075032	DECORATION PLATE (L35)	
		(XL26**, BM2600, L25, COMFORT25, L15)			XC9075049	DECORATION PLATE (XL2650H)	ADD
	XC9209321	SELECTING UNIT ASSEMBLY	060041		XC9075037	DECORATION PLATE (XL3510T)	ADD
		(XL35**, BM3500, L35)			XC9075051	DECORATION PLATE (L15)	1000006061
26	XC4976021	BH ADJUSTING KNOB			XC9075052	DECORATION PLATE (XL2620SE)	1000007330
27	X59928021	SPRING WASHER		51	XC9077021	ZIGZAG LINK CONNECTING ROD	
28	048080343	RETAINING RING, E8	1000001452	52	048030343	RETAINING RING E3	1000001452
29	048060343	RETAINING RING, E6	1000001452	53	XZ5019021	ZIGZAG LINK UNIT	050202
30	XC4989021	ADJUSTING NUT		54	085411015	TAPTITE BIND B M4X10	
31	062300806	SCREW PAN M3X8		55	XC5028021	REVERSE SEWING BUTTON	
32	XC4994021	ADJUSTING NUT		56	XD0037220	WASHER 9	060012
33	062301205	SCREW PAN M3X12		57	XD0038120	WASHER 10	050211
	XC9033021			58	XA1911021	SPRING	050150
35	XC9034021	BH FEED LEVER A ASSEMBLY		59	XC8984021	TENSION PULLEY ASSY	1000003729
		BH FEED LEVER B ASSEMBLY		60	0A4400806	SCREW, PAN (S/P WASHER) M4 x 8	1000003729
	XC9039021						
38	XC5092021	SPRING					
39	XC9228021	SPRING (XL35**, BM3500, L35)					
		, , , , , , , , , , , , , , , , , , , ,			1	l	



(5) BOBBIN WINDER / THREAD GUIDE MECHANISM


No.	CODE	NAME	REMARKS
		BOBBIN WINDER MECHANISM	1
1	XC5041221	BOBBIN WINDER ASSY	050170
2	XC4076020	RUBBER RING	
3	XC1894020	SPRING	
4	048050343	RETAINING RING, E5	1000001452
5	XC5045020	BOBBIN WINDER SPRING	
6	XC5046020	CORD STOPPER	
7	XC3496021	GIZA TITE 5 x 16	
8	085511616	TAPTITE BIND B M5X16	DEL 060082
		THREAD GUIDE MECHANISM	
9	XC5047022	THREAD GUIDE ASSY A	050112
10	XC5048021	THREAD TENSION HOLDER ASSY	
11	XA0083121	TENSION DISC A	1000006407
12	XA0084121	TENSION DISC B	1000006407
13	XC5051020	THREAD RELEASE PLATE	
14	X55842021	SPRING	
15	137881021	TENSION DISC WASHER	
16	XC5053021	THREAD TENSION ADJUSTING SCREW	
17	XC5054021	THREAD TENSION PLATE	
18	109763023	WASHER	
19	XC9234021	TENSION DIAL SHAFT	060043
20	X56839021	NOTCHED SPRING	
21	062300416	SCREW, PAN M3 x 4	
22	XC5055021	THREAD TENSION DIAL	
23	XE2780101	THREAD GUIDE ASSY B	1000005353
24	XC5060121	THREAD TAKE-UP HOLDER B	050177
25	XC6957121	THREAD TAKE UP SPRING	1000005353
26	XC2648121	THREAD CATCHING SPRING CASE	1000003151
27	0A4301806	SCREW, PAN (S/P WASHE) M3 x 18	
28	XC5059020	THREAD GUIDE WIRE	
29	085411416	TAPTITE, BIND B M4 x 14	






(6) LAMP MECHANISM / MOTOR UNIT

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
		LAMP MECHANISM	,	25	XC4955121	MOTOR FIXED PLATE	060087
1	XC5992021	LAMP ASSY,E12C #026 (U.S.A., CAN, TWN)	1000004242	26	XA3004021	BOLT,(S/P WASHER) M5 x 12	
	XC9132021	LAMP ASSY,E14K #186		27	138172021	SCREW, PAN (S/P WASHER) M4 x 10	050187
2	X53061020	SEW-LIGHT BULB (U.S.A., CAN, TWN)	1000004242				
	205336020	SEW-LIGHT BULB L-4					
3	XC5065020	LAMP HOLDER 120V (U.S.A., CAN, TWN)	1000004242				
4	060400616	SCREW, BIND M4 x 6 (U.S.A., CAN,	1000004242				
5	060302016	SCREW, BIND M3 x 20 (U.S.A., CAN, TWN)	1000004242				
6	X53169020	BAND					
7	XA0286021	WIRE CLIP					
8	XC5243021	CORD CLAMP:NK-5N					
9	085411416	TAPTITE, BIND B M4 x 14					
10	085311215	TAPTITE, BIND B M3 x 12	1000004242				
		(Except for U.S.A., CAN, TWN)					
11	XC9079020	CORD GUIDE PLATE					
12	XC4972021	CORD CLAMP					
		MOTOR UNIT	•				
13	XC3806121	TIMING BELT 372-2GT-6					
14	XC3496021	GIZA TITE 5 x 16					
15	XA8786021	3P SOCKET BODY					
16	XA8787021	3P SOCKET COVER					
17	021400205	NUT, 2 M4					
18	052403006	SCREW, PAN (S/P WASHER) M4 x 30					
19	214808020	CONNECTOR:#3					
20	XC5232021	POWER SWITCH ASSY					
21	XC9954021	MOTOR SUPPLY ASSY 120V	1000004242				
		(U.S.A., CAN, TWN)					
	XC9955021	MOTOR SUPPLY ASSY 230V					
	XD0713021	MOTOR SUPPLY ASSY 240V	050069				
	XE1034001	MOTOR SUPPLY ASSY, 220V/50HZ	060085				
	XE1042001	MOTOR SUPPLY ASSY, 220V/60HZ (KOREA)	060085				
22	XD0870321	MOTOR HOLDER FDM120V	1000004242				
		(U.S.A., CAN, TWN)					
	XD0871421	MOTOR HOLDER FDM230V	1000006415				
23	XC3803020	MOTOR FAN					
24	XC7359021	FOOT CONTROLLER:KD-1902	1000001764				
		(U.S.A., CAN)					
	XC7456321	FOOT CONTROLLER:KD-2902UK	1000001764				
	XC7438321	FOOT CONTROLLER:KD-2902	1000001764				
		(OTHER)					
	XD0105021	FOOT CONTROLLER:KD-2902 CHN	1000001764				
	XE0629001	FOOT CONTROLLER:KD-2902AUS	1000003856				
		(BM2600, XL2620:AUSTRALIA)					
	XD0852021	FOOT CONTROLLER:KD-2902KOREA	060085				
	XE3447001	FOOT CONTROLLER:KD-1902 TWN (TWN)	1000004242				




(7) ATTACHMENTS / PRINTED MATTER / PACKING MATERIALS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
		ATTACHMENTS		28	XD0103021	INSTRUCTION BOOK CHN	
1	X55467021	SCREW DRIVER			XC7453021	INSTRUCTION BOOK SPA	ADD
2	X59370021	ZIPPER FOOT			XC9972121	INSTRUCTION BOOK (Russian)	050195
3	X59369321	BUTTON HOLE FOOT ASSY			XE3369001	INSTRUCTION BOOK (TWN)	1000004242
4	XE2137001	BUTTON SEWING FOOT	1000001059	29	XD1866021	INSTRUCTION DVD PAL (U.K. IRE, HKG, AUS)	060155
5	X52800120	BOBBIN		30	XC0380021	WARRANTY CARD (U.S.A.)	
6	X57521021	NEEDLE PACKAGE (1 PCE)			UH3851001	WARRANTY CARD EUR	
7	129583021	NEEDLE SET (3PCS)			XC6402021	WARRANTY CARD UK	
8	130920021	EXTRA SPOOL PIN			XA6351221	WARRANTY CARD (ITALY)	050317
9	XC6063021	FEED DOG COVER			XD1328021	WARRANTY CARD CHINA	050203
10	XC4487021	ACCESSORY BAG			XE3332001	MASS WARRANTY CARD (BM2600:HKG)	1000003830
11	X59371021	NARROW HEMMER FOOT (U.S.A.,CAN, TWN)	1000004242		XE2005001	EEU WARRANTY CARD (EEU)	1000006811
12	X59372021	BLIND STITCH FOOT (U.S.A., CAN, TWN)	1000004242	31	XE2010001	WARRANTY CARD BROTHER CANADA	1000001038
13	XD1819021	QUILTING FOOT (XL3500T, XL3510T)	050309	32	130800021	BAG,220 x 310H	
	X59819021	QUILTER (XL3500T, XL3510T)	050152	33	XC8537021	QUICK REFERENCE GUIDE (U.S.A., CAN, TWN, XL2620SE)	1000004242
15	XE2785002	WALKING FOOT ASSY	1000002188		XC8327021	QUICK REFERENCE GUIDE (BM2600,3500,L25,35)	
		(XL3500T, XL3510T)			XC9110021	QUICK REFERENCE GUIDE (OTHER)	
16	XC9800021	S99 WIDE TABLE ASSY			XE3644001	QUICK REFERENCE GUIDE BM2600 (BM2600:HKG)	1000005705
		(XL3500T, XL3510T)		34	XC9286021	CONTACT SHEET (XL2600, XL3500T:CAN)	1000001810
17	XC9360021	FIXING PLATE A (XL3500T, XL3510T)		35	XC1885021	MANUAL (XL3500T:CAN, XL2600:TWN)	1000004242
18	XC9786021	FIXING PLATE S99 (XL3500T, XL3510T)		36	XA7201021	USER'S MANUAL (XL3500T:CAN, XL2600:TWN)	1000004242
19	XC4495021	TABLE FOOT (XL3500T, XL3510T)		37	XA2112022	DUST COVER ASSY (Except for U.S.A., CAN, TWN)	1000004242
20	XD1223021	ADJUSTING FOOT (XL3500T, XL3510T)	050196		XE2564001	INSERTION (CAN)	1000001792
21	021400206	NUT 2 M4 (XL3500T, XL3510T)			XE2196001	INSERTION	1000003188
22	087411416	TAPTITE CUP B M4X14			XE2895001	OPTIONAL 5YEAR WARRANTY CARD (U.K.)	1000004069
		(XL3500T, XL3510T)			XE3564001	INNOV-IS RANGE PROMOTION DVD	1000005046
23	X59853020	RUBBER CUSHION (XL3500T, XL3510T)			XE0924401	INSTRUCTION DVD ASSY RUS (RUS)	1000005780
24	XC9802021	INSTRUCTION MANUAL					
		(XL3500T, XL3510T)					
25	X61231021	BAG,400X500H (XL3500T, XL3510T)					
26	XC9361020	LE WIDE TABLE CARTON					
		(XL3500T, XL3510T)					
27	XC9362020	PAD (XL3500T, XL3510T)					
	X60838000	BAG, 70X110C (XL3500T, XL3510T)	050336				
<u> </u>		PRINTED MATTER					
28	XC8346021	INSTRUCTION BOOK (U.S.A.)					
	XC6771021	INSTRUCTION BOOK (English)					
	XC7252021	INSTRUCTION BOOK FRE					
	XC9157021	INSTRUCTION BOOK (German)					
	XC8248021	INSTRUCTION BOOK SWE					
	XC7344021	INSTRUCTION BOOK DUT					
	XC8030021	INSTRUCTION BOOK ITA					
	XC8113021	INSTRUCTION BOOK DEN					
	XC8276021	INSTRUCTION BOOK FIN					



(7) ATTACHMENTS / PRINTED MATTER / PACKING MATERIALS

No.	CODE	NAME	REMARKS
		PACKING MATERIALS	
38	XC5079042	COLOR CARTON (XL2600:U.S.A., CAN)	050260
		COLOR CARTON (XL2610:U.K.)	
	XC5079040	COLOR CARTON (XL3500:U.S.A.)	050260
	XC5079031	COLOR CARTON (XL3510:U.K.)	
		COLOR CARTON (BM3500:SIN)	
	XC5079034	CARTON (BM2600:SIN, AUS, HKG)	
	XC5152034	CARTON (BM2600)	
	XC5152030	CARTON (XL2600:OTHER)	
	XC5152033	CARTON (XL2620)	
	XC5079043	COLOR CARTON (XL2610:OTHER)	050260
	XC5152040	CARTON (XL2610:FRA)	
	XE3544001	CARTON (L25)	1000006418
	XC9804022	CARTON (XL3500T)	050260
	XC5152038	CARTON (BM3500)	
	XC5152031	CARTON (XL3500:OTHER)	
	XC5152037	CARTON (XL3520)	
	XC5079041	COLOR CARTON (XL3510:OTHER)	050260
	XC5152039	CARTON (XL3510:FRA)	
	XE3547001	CARTON (L35)	1000006418
	XE2009001	COLOR CARTON (XL2650H)	ADD
	XC9804023	COLOR CARTON (XL3510T)	ADD
	XE3428001	COLOR CARTON (XL2600:TWN)	1000004242
	XC5079038	COLOR CARTON (XL2620:AUS)	1000003856
	XE3828001	CARTON (L15)	1000006061
	XE3543001	CARTON (XL2600:RUS)	1000006418
	XE3546001	CARTON (XL3500:RUS)	1000006418
	XE3545001	CARTON (COMFORT 25)	1000006418
	XE4618001	COLOR CARTON (XL2620SE)	1000007330
39	XC5081320	S22SF ASSY	060067
40	X60439121	BAG,630 x 630T	
41	X57847021	PLUG LABEL (U.K.)	
42	LA6041001	SECURITY TAG (U.S.A.)	
43	XC5063020	PROTECTION CARTON	
	XD1536020	DIAL PAD D	050230
	XC9806020	PAD (XL3500T, XL3510T)	
	X57367021	BAG,135 x 150 (XL3500T, XL3510T)	050054
	X54243051	SEAM RIPPER (XL2600:GER)	050181
	X59476021	CLEANING BRUSH (XL2600:GER)	050181
	XE0924201	INSTRUCTION DVD ASSY RUS	060194
	XE1158101	BOOKLET	060168
	XE3392001	S99 PS FOAM PAD ASSY (XL2650H)	1000003855
	XE3393001	S99 HC PS FOAM PAD ASSY (XL2650H)	1000003855
	XZ5048001	` '	1000003855
	XD0242021	DVD STICKER (XL2620:AUS)	1000003856





XL2600/2610/2620/XL2650H/BM2600/L25 XL3500/3510/XL3510T/3520/BM3500/L35/L15/XL2620SE 21M04HF885S25/27