# **PARTS CATALOGUE FOR**

**LS-1217** 

LS-1317

LS-1417


LS-1217b

#### **CONTENTS**

(1)	PRINCIPAL PARTS	2
(2)	UPPER SHAFT AND NEEDLE BAR	4
(3)	FEED MECHANISM	6
(4)	PATTERN SELECTION, SHUTTLE HOOK AND UPPER TENSION	8
(5)	LAMP AND MOTOR	10
(6)	OTHER PARTS	12


## (1) PRINCIPAL PARTS

No.	CODE	PARTS NAME	REMARKS
1	XA7922021	Front cover	
2	0A0211850	Spring pin	
3		Upper cover thread guide	
4		Decoration plate (LS1217)	
		Decoration plate (LS1317)	ADD
		Decoration plate (LS1417)	ADD
5		TAPTITE, CUP P M4 x 20	040105
6	053400806	·	
7	XA7925021	Rear cover	
8	XA6106021	THREAD GUIDE ASSY	040161
9	0A5301006	Screw	
10	021300106	Nut	
11	188058151	Spool pin	
12	XA0628021	Spool pin spring	
13	XA8851021	Spool pin stand	
14	X59864221	BOBBIN PRESSER	040152
15	052301606	Screw	
16	X57891051	Rear cover reflector	
17	XA7926021	Hinged door	
18	X53638121	SPRING	CHG
19	XA7928021	Face plate	
20	XA7929021	Accessory table	
21	X58361021	RUBBER CUSHION	CHG
22	X56474051	Collar	
23	X57297051	Screw	
24	XA7932021	Base plate	
25	XA1805051	Rubber cushion A	
26	XA4687021	ADJUSTING SCREW ASSY	CHG
27	060400816	Screw	
28	XC4167021	CAUTION STICKER(LS1217)	ADD
		NEW SPEC (LS1217B)	
4	XC1430021	Decoration plate (Leopard pattern)	ADD
	XC1430022	Decoration plate (Zebra pattern)	ADD
	XC1430023	Decoration plate (Pink pattern)	ADD




## (2) UPPER SHAFT AND NEEDLE BAR

No.	CODE	PARTS NAME	REMARKS
1	XA0630521	Upper shaft assembly	
2	XA0637120		
3	XA0636020	Clutch spring	
4		Timing wheel	
5			
6	X54013051	Screw	
7	014400432		
8		Bushing presser	
9		TAPTITE, BIND S M4 x 10	040105
10		Balance wheel	1
11	XA2358121		
12		Needle bar thread guide	
13		Needle clamp	
14		Needle clamp screw	
15	012400432	•	
16		Needle bar supporter	
17		Needle bar supporter stud	
18	X54369021		
19	X56851051		
20		Needle bar supporter guide	
21		Needle bar crank rod assembly	
22		NEEDLE BAR CRANK	CHG
23	132051052		00
24		Zigzag needle plate	
25	X50487051	Screw	
26		TAPTITE, BIND S M4 x 10	040105
27		THREAD TAKE-UP ASSY	CHG
28		Thread take-up lever stud	00
29	048050346		
30	XA0649051		
31		PRESSER BAR	040158
32		Presser bar spring	111100
33		Presser bar guide bracket	
34	X52760021	SET SCREW, PAN M6 x 12	CHG
35		Presser foot lifter	
36		Presser foot lifter stud	
37		Zigzag presser foot assembly	DEL
-		ZIGZAG PRESSER FOOT	ADD
38	138134021	PRESSER FOOT HOLDER	ADD
39	132730122	TIGHTENING SCREW 3.57	CHG




### (3) FEED MECHANISM

No.	CODE	PARTS NAME	REMARKS	No.	CODE	PARTS NAME	REMARKS
1	XA0978051	Feed connecting rod		45	XA7961021	Feed dial cam	
2	XA0980021	Spring		46	X50532051	Stop plate	
3	XA0982020	Horizontal feed shaft					
4	XA0983151	Horizontal feed shaft arm					
5	021400205	Nut					
6	060401416	Screw					
7	X53330020	WASHER	CHG				
8	048050346	Stop ring					
9	XA0987021	Horizontal feed plate					
		Feed stand shaft					
11	XA3960021	Feed stand					
12	048030346	Stop ring					
13	146200051	Stop ring					
14	XA4430051	Feed dog					
15	060300416	Screw					
16	060400816	Screw					
17	XA3474021	Dust protect plate					
		Feed stand support					
	025040133						
20	XA1082051	Taper point Stud R					
	X57913051						
22	XA0991021	Spring					
23	X55472051	Taper point stud L assembly					
	XA4692021		CHG				
25	XA0649051	Screw					
26	X56613021	Spring					
27	XA3480021	Vertical feed arm					
28	XA3481021	Vertical feed adjuster					
29	X50559020	ZIGZAG ADJUSTING NUT	CHG				
30	062300806	Screw					
31	060400516	Screw					
32	XA0995151	Vertical feed shaft					
33	048060346	Stop ring					
34	XA0030021	FEED SQUARE BLOCK	CHG				
35	XA0996020	FEED REGULATOR	CHG				
36	XA0997020	FEED REGULATOR SHAFT	CHG				
37	X57908021	TAPTITE, BIND S M4 x 10	040105				
38	XA4675051	Spring					
39	XA9167021	Feed regulator plate					
40	XA1002050	Reverse sewing regulator shaft					
41	052300606	Screw					
42	XA7989021	Reverse sewing lever plate					
43	XA1004150	Reverse sewing shaft					
44	XA7960021	Reverse sewing lever					




#### (4) PATTERN SELECTION, SHUTTLE HOOK AND UPPER TENSION

No.	CODE	PARTS NAME	REMARKS	No.	CODE	PARTS NAME	REMARKS
1	XA4693151	Cam drive connecting rod A		43	XA7984021	Zigzag cam	
		assembly		44	XA1044021	Zigzag connecting rod spring	
2	XA1012251	Cam drive connecting rod B		45	XA7985021	Bobbin winder holder assembly	
3	XA1014021	Cam drive connecting rod C		46	XA1049021	Bobbin winder spindle assembly	
		assembly		47	X59939021	Bobbin winder spring	
4	XA1017120	Rack		48	XA7988021	Stitch length knob spring	
5	052300606	Screw				Upper tension control dial	
6	XA3439021	Spring		50	XA1055021	Upper tension control holder	
7	146200051					assembly	
8	048040346	Stop ring		51	XA1255121	Upper tension control dial plate	
9	060400816	Screw					
10	XA6909051	Toothed washer					
11	131976020	WASHER THRUST	CHG				
12	XA1019021	Rack plate spring					
13		SCREW 4 x 8	CHG				
14	X50559050	Nut					
15	062301006	Screw					
16	X52077151						
17	014400432	Screw					
18	X53330050	Washer					
19		Shuttle race assembly					
20		Shuttle hook					
21	XA1021051	Shuttle driver assembly					
		Driver shaft gear					
23		BOBBIN CASE ASSEMBLY	040130				
24	014400632	Screw					
25	X57313151	Rack stopper					
26		TAPTITE, BIND S M4 x 10	040105				
27		Rack stopper A					
28		Zigzag connecting rod					
		Zigzag base assembly					
		Needle position selector assembly					
	XA1036021						
	X57953051						
	X56960021		CHG				
		Zigzag adjuster connecting rod					
		Connecting rod pin					
	XA1040021						
38		Plain Washer					
<b>-</b>		Notched spring					
		Stitch width knob					
42							
	10100000	1.431101			I	l	



### (5) LAMP AND MOTOR

No.	CODE	PARTS NAME	REMARKS
1	XC0483021	Sew-light assembly (100-120V)	CHG
	XA1064021	Sew-light assembly (220-240V)	
2	X53061020	Sew-light bulb (100-120V)	
	205336020	Sew-light bulb (220-240V)	
3	X57984051	Screw (100-120V)	
	XA1623051	Screw (220-240V)	
4	X53169020	BAND	040105
5	XA1196051	Timing belt	
6	XA3004051	Screw	
7	XA8786021	3P socket body	
8	XA8787021	3P socket cover	
9	052403006	Screw	
10	021400205	Nut	
11	214808020	CONNECTOR:#3	CHG
12	XA1070021	PW switch assembly (100-120V)	
	XA1073021	PW switch assembly (220-240V)	
13	XA1071321	MOTOR : MM-BU1-9C	040112
	XA1429121	MOTOR: MM-251-51 (220V)	CHG
	XA1430121	MOTOR: MM-251-52 (230V)	CHG
14	XA1265120	Timing belt pulley A	
15	XA1266120	Timing belt pulley B	
16	XA7678021	CORD CRAMP	CHG
17	XA8290051	Screw	
18	138598021	SOCKET PIN	040105
19	XC6666021	FOOT CONTROLLER : FC-316-27-LF	CHG
	XA6422021	Foot controller (220-240V)	
	XA6412021	Foot controller (U.K.)	ADD



# (6) OTHER PARTS

No.	CODE	NAME	REMARKS
1	X55467051	Screw driver (M)	
	X55468051	Screw driver (S)	
2	128585051	Zipper foot	
3	125469251	Straight foot	
4	X54243001	Seam ripper	
5	XA5537051	Bobbin (with UPC)	
	XA5537052	Bobbin (without UPC)	
6	X55465021	OILER	040105
7	129583001	Needle set	
8	131096101	NEEDLE SET (1PCE)	CHG
9	130920021	EXTRA SPOOL PIN	CHG
10	XA3442151	Feed dog cover	
11	XC4487021	ACCESSORY BAG	CHG
12	194402111	INSTRUCTION BOOK (EXCEPT	CHG
		FOR FINNISH & ESTONIAN)	
	194402012	Instruction manual	ADD
		(Ger., Fre., Du., It)	
	194402014	Instruction manual (Nor., Swe)	ADD
	XC1931021	Instruction manual (Finnish)	ADD
	XC1932021	Instruction manual (Estonian)	ADD
13	XA2112021	Cover	
14	X60360041	COLOR CARTON	CHG
		(LS1217: Color, U.S.A.)	
	X60360045	Carton (LS1217, CHL/ARG)	CHG
	X61674023	Carton (LS1217: Europe)	ADD
	X61674031	Carton (LS1217:Europe without MC)	ADD
	X61674024	Carton (LS1317)	ADD
	X61674025	Carton (LS1417)	ADD
	X60360038	Carton (LS1217B: Color, U.S.A.)	CHG
15	X61390020	400SF ASSY	CHG
16	X60439121	BAG 630X630T	CHG
17	LA6041001	SECURITY TAG	ADD
18	130800021	BAG 220X310	ADD
	*MC;	Made in China	Г
15	X61390021	400SF ASSY (KOREA)	ADD
<u> </u>			
<u> </u>			

