PARTS CATALOGUE FOR


PE300S P1000

CONTENTS

(1)	PRINCIPAL PARTS	2
(2)	NEEDLE BAR, PRESSER BAR AND ZIGZAG	4
(3)	UPPER SHAFT, THREAD TAKE-UP LEVER, VERTICAL SHAFT AND BOBBIN WINDER	6
(4)	FEED MECHANISM AND ROTARY HOOK ASSY	8
(5)	NEEDLE THREADER	10
(6)	LAMP, MAIN PC BOARD ASSY AND MOTOR UNIT	12
(7)	EMBROIDERY UNIT	14
(8)	OTHER PARTS	16


(1) PRINCIPAL PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA5062051	Set plate A		45	026350235	Washer 3.5	
2	X57908051	Screw S4 × 10		46	083361216	Screw B3.5 × 10	
3	XA5063151	Set plate B		47	XA5082053	FRONT COVER	CHG
4	XA5541000	Handle guide			XA5082055	FRONT COVER (P1000)	ADD
5	060400616	Screw 4 × 6		48	087411416	Screw B4 × 14	
6	XA5542001	Handle assembly		49	060400816	Screw 4 × 8	
7	XA5067053	Rear cover		50	XA6549051	Face plate assy	
8	XA6692051	Spool stand bar		51	X51895051	FACE PLATE BUSH	ADD
9	XA5069051	Spool stand bar shaft		52	X80321001	NT thread cutter assembly	
10	XA5762051	Presser plate		53	138384051	Retaining ring CS5	
11	087300517	Screw 3 × 5		54	0A4400806	Screw 4 × 8 DA	
12	X59864251	BOBBIN PRESSER	040153	55	XA6551051	ARM COVER ASSY	CHG
13	052301606	Screw 3 × 16			XA6551053	ARM COVER ASSY (P1000)	ADD
14	021300205	NUT 2 M3	050171	56	XA5105051	Accessory case	
15	XA5070151	Spool guide assembly		57	X55260152	Spool cap C	
16	0A4300806	Screw 3 × 8		58	XA6038051	Front cover spacer A	
17	021300205	NUT 2 M3	050171	59	XA6039051	Front cover spacer B	
18	XA5072101	Thread guide plate assembly		60	XA6040051	Spring tape	
19	XA5076001	Thread guide plate		61	XA5517050	Rubber	
20	052300606	Screw 3 × 6		62	XA6567001	DECORATION PLATE	CHG
21	136681051	Screw B3 × 8				FOR PE-300S	
22	XA5077051	Slide lever					
23	XA5078051	Spring					
24	XA5079051	Slide lever shaft					
25	XA5525051	Washer					
26	130157051	Rubber cushion					
27	XZ0047051	Leaf spring					
28	087411416	Screw B4 × 14					
29	XA5083051	SV key top					
30	XA5084000	SV joint plate					
31	XA5092151	SS button					
32	XA5093051	Reverse sewing					
33	XA5094051	NP button					
34	XC0392051	Assy SSVR					
35	XA5085050	Thread guide wire					
36	XA5086201	Thread guide bar sub assy					
37	XC0394051	Assy UTHD					
38	XA5089151	Spring					
39	XA5090001	Thread cutting shutter					
40	XA5091001	Thread cutting shutter cover					
41	120454051	Retaining ring CS3					
42	XA5680050	Thread guard					
43	XA7890050	Front cover thread guard					
44	138337051	Rubber cushion A					




(2) NEEDLE BAR, PRESSER BAR AND ZIGZAG

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA5116151	Thread guide assembly		45	XA5215201	Zigzag connecting rod	
2	XA5129251	Needle bar assembly		46	XA5989000	Zigzag nut	
3	XA5132150	Needle bar thread guide		47	062300806	Screw 3 × 8	
4	014300332	Screw 3 × 3		48	XA5216251	Assy, PF switch	
5	XA5133251	Screw		49	062260516	Screw 2.6 × 5	
6	XA5134051	Needle bar block assy		50	XA5475051	Assy, Lead wire for Z pm	
7	014400432	Screw 4 × 4		51	XA6019101	Z gear arm assembly	
8	XA7670051	Positioning supporter		52	XA6022051	Spring	
9	012400432	Screw 4 × 4		53	048020346	Stop ring E2	
10	XA5779051	Pin					
11	014401232	Screw 4 × 12					
12	X56851051	Nut					
13	XA8540051	Spring					
14	XA5138151	H shaft holder sub assy					
15	XA5247051	Thread guide					
16	0A5300806	Screw 3 × 8 DB					
17	X57908051	Screw S4 × 10					
18	X51927050	Needle bar supporter arm					
19	048020346	Stop ring E2					
20	XA1854051	Threader hook assembly					
21	XC0413051	Needle plate assembly					
22	X80321001	NT thread cutter assembly					
23	XD1646051	NEEDLE PLATE COVER SUPPLY ASSY	050259				
24	X50487051	Screw M4					
25	XZ0046051	STOPPER	ADD				
26	XA5153051	Presser bar					
27	XA5154051	Presser bar bracket					
28	014401032	Screw M4 × 10					
29	XA5155051	Spring					
30	XA5156151	Presser foot lifter					
31	XA5157151	Stud for presser foot lifter					
32	XC3015051	PRESSER FEED HOLDER ASSY	CHG				
33	132730151	Screw 3.57					
34	X51953051	Zigzag presser foot					
35	XA5166051	BH switch base plate					
36	XA5158051	BH switch assembly					
37	060300616	Screw 3 × 6					
38	XA5206151	ZPM holder sub assembly					
		Z PULSE MOTOR	CHG				
40	060300416	Screw 3 × 4					
41	XA5212051	Release lever					
42	XA5213151	Spring					
-		Stop ring E2.5					
	XA6018000						
44	XA6018000	Z gear					




(3) UPPER SHAFT, THREAD TAKE-UP LEVER, VERTICAL SHAFT AND BOBBIN WINDER

No.	CODE	NAME	REMARKS
1		Upper shaft assembly	
2	XA5109151	, , ,	
3		Stop ring E6	
4		Upper shaft gear	
5		Screw 5 × 5	
6		LOWER SHAFT BUSHING	CHG
7		WASHER, THRUST	CHG
8		Stop ring E6	
9		Thread take-up counter weight	
10		Screw 5 × 5	
11		Bushing presser	
12		Screw S4 × 10	
		Thread take-up lever	
		Thread presser plate	
15	XA1387051		
16	XA7624051	Take-up lever shaft	
17		Stop ring E5	
18		Screw S4 × 16	
19		Needle bar crank assembly	
20	X55197050	Needle bar crank rod	
21	048040346	Stop ring E4	
22	XA4255151	Vertical shaft sub assy	
23	X51383050	WASHER, THRUST	CHG
24	137768151	Set screw collar	
25	014400432	Screw 4 × 4	
26	XA5221001	Vertical shaft pulley	
27	XA5222051	Timing shutter	
28	132421051	Bushing presser	
29	XA5223051	Bobbin winder plate A assembly	
30	XA5225051	Bobbin winder pulley assembly	
31	XA5230151	Bobbin winder spring plate	
32	XA6037001	Set plate	
33	XA5231251	Bobbin winder spring	
34	XA5232151	Assy, BW switch	
35	062260516	Screw 2.6 × 5	
36	060400816	Screw 4 × 8	
37	XA1866051	Washer, spring	




(4) FEED MECHANISM AND ROTARY HOOK ASSY

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA5167250		TALIII/AITA	_	XA6105000		TKEMI/AKKO
2		Z PULSE MOTOR	CHG	-	XA6263051		
3	XA5169251		0110	_		Supporting pulley assembly	
4		Initial rubber		47		Screw M4 × 6	
5	052300606			-	000400010	OCICW IVIT A C	
6		Screw S4 × 10					
		Assy lead wire for F PM					
8	XA5171101	•					
9	XA5172051						
<u> </u>	XA5172051						
	XA5174151						
12							
-	XA7270051						
		Horizontal feed shaft					
	X53027050						
-		Stop ring E4					
	014400632						
		Guide pin holder assembly					
		Up-down feed arm assembly					
	XA5184050						
21		Stop ring E3					
22	XA8873050						
-		•					
	XA5180051 XA5187050						
25	131976051						
_		Screw 4 × 30 DA					
		Drop holder sub assy					
28	X53027050						
_		Drop plate assembly					
	XA5192051 XA5195051	•					
		·					
	XA5196051	Drop knob shaft		\vdash			
		•		\vdash			
		Spring, plate		\vdash			
		Timing belt 150 XL 015		\vdash			
		Belt tension pulley assembly		\vdash			
		Upset 4 × 12 DB		-			
-		Outer rotary hook assembly		-			
		Inner rotary hook assembly	CHC	-			
		OUTER ROTERY HOOK SHAFT	CHG				
	XA2190050			\vdash			
	XA0361050		0110	\vdash			
42		INNER ROTARY HOOK	CHG	\vdash			
<u>_</u>		BRACKET ASSY		_			
43	060400816	Screw 4 × 8					




(5) **NEEDLE THREADER**

No.	CODE	NAME	REMARKS
1		Thread tension unit holder	
2		Thread tension bracket assembly	
3		Thread tension disk	
4	XA0084051	Thread tension disk	
5	XD0573051	WASHER	050052
6		Thread tension plate A	
7		Tension disk washer	
8	XA7640051	Spring	
9	137878051	Thread tension adjusting screw	
10	XA5239051	Thread tension plate assembly	
11		THREAD TENSION DIAL	CHG
		THREAD TENSION DIAL (P1000)	ADD
12	XZ0133050	· · ·	
13	137991051	Washer	
14	025040133	Washer 4	
15	048030346	Stop ring E3	
16		Screw 3 × 6	
17	X57908051	Screw S4 × 10	
18	XA5243051	Thread release plate B assy	
19	XA5246051	Spring	
20	060300816	Screw M3 × 8	
21	XA6026001	Cord guide plate	




(6) LAMP, MAIN PC BOARD ASSY AND MOTOR UNIT

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA5248051	Assy WB lamp		33	060400816	Screw 4 × 10	
2	X50228051	WB lamp		34	XA8318051	Lead clip for 120V	
3	085301415	Screw P3 × 14		35	X57908051	Screw S4 × 10 for 120V	
4	X81137051	MAIN PC BOARD ASSY 120	CHG	36	X81140001	Pin jack assy	
		(USA/CAN)		37	XC6651151	FOOT CONTROLLER : FC-313-81-LF	
	X81145051	MAIN PC BOARD ASSY 230	CHG		XD0496051	FOOT CONTROLLER : FC-313-LF-EU	050033
		(EUROPE)					
	X81163051	MAIN PC BOARD ASSY P-1000	CHG				
		(AUS)					
	X81201051	MAIN PC BOARD ASSY	CHG				
		(OTHERS)					
5	052300606	Screw 3 × 6					
6	X81138051	Power supply unit ASSY for 120V	CHG				
	X81139051	Power supply unit ASSY for 230V	ADD				
7	XA4871051	G fuse 3.15AA for 120V					
	XA1463051	G fuse 2AT for 230V	ADD				
	XA4872051	G fuse 3.15AB for 230V	ADD				
8	XA5373051	Power unit cover B					
9	XA5374051	Power unit cover C					
10	052403006	Screw 4 × 30					
11	XA5278051	Screw P4 × 14					
12	XC0386051	NP board assembly #2					
13	0A5301006	Screw 3 × 10DB					
14	XA5284151	Set plate C					
15	060300516	Screw 3 × 5					
16	XA5289151	Connector holder assembly					
17	X56302001	Connector 176496					
18	048025346	Stop ring E2.5					
19	XA5267051	Assy, lead wire for XY PM					
20	136681051	Screw B3 × 8					
21	X53169050	Band #2					
22	XC2001051	MOTOR ASSEMBLY : 120V	CHG				
	XC2004051	MOTOR ASSEMBLY : 230V	CHG				
23	XA5295051	MM pulley 2GT14					
24	130676151	Set screw collar					
25	014400632	Screw 4 × 6					
26	XA5296151	Motor holder					
27	0A4301005	Screw 3 × 10 DA					
28	138172051	Screw 4 × 10 DA					
29	XA5297151	Timing belt 258-2GT for 120V					
	XA7677051	Timing belt for 230V	ADD				
30	XA5298051	Pulley holder assembly					
31	XA5301051	Idol pulley					
32	048050346	Stop ring E5					



(7) EMBROIDERY UNIT

_	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA5302001	Main frame assembly		45	XA5348051	ES cover D spacer	
2	XA5306000	X gear		46	136681051	Screw B3 × 8	
3	048030346	Stop ring E3		47	XA5349050	Rock finger	
4	XA5307000	X driving gear		48	XA0814051	Pin G 4 × 20	
5	X53330050	Washer		49	XA2157051	Spring	
6	X58715051	Timing belt 40S2M400		50	XA5350051	Rock finger button	
7	048060346	Stop ring E6		51	X56302001	Connector 176496	
8	XA5308051	X tension pulley assembly		52	085411415	Screw B4 × 14	
9	XA6907051	Screw 4 × 8		53	X59853050	Rubber cushion	
10	XA5312051	X carriage supporter assembly		54	XA5352000	Cord presser	
11	XA5314050	Cord guide		55	XA6560051	ES UNIT COVER ASSY (USA/CAN)	CHG
12	XA5315051	Y pulse motor			XA6560052	ES UNIT COVER ASSY (OTHERS)	ADD
13	052300606	Screw 3 × 6			XA6560053	ES UNIT COVER ASSY (P1000)	ADD
14	XA5316051	X guide shaft		56	XA6564001	ES COVER SHEET	CHG
15	0A4400806	Screw 4 × 8			XA5685001	ES COVER SHEET (P1000)	ADD
16	XA5317150	X slider		57	XA6281000	Y presser plate	
17	XA5318100	X belt presser				Roller assembly	
18	XA5319100	X shutter		59	XA6334000	Shutter presser plate	
19	0A4300506	Screw 3 × 5 DA					
20	XC0417051	Assy, X initial sensor					
21	000020415	Screw M2 × 4					
22	XA5323051	X pulse motor					
23	XA5324181	X carriage assembly	CHG				
24	XA5328000	Y gear					
25	048020346	Stop ring E2					
26	XA5329000	Y driving gear pulley					
27	048060346	Stop ring E6					
28	XA5330051	Timing belt 40S2M316					
29	XA6151051	Y tension pulley assembly					
30	XA5338001	Y carriage					
31	XA5339101	Notched spring					
32	XA5340151	Y guide shaft					
33	103810052	Spring					
34	048040346	Stop ring E4					
35	XA5341000	Y shutter					
36	XA5342100	Y slider					
37	XA8390051	Screw 3 × 7					
38	XC0419051	Assy, Y initial sensor					
39	XA5346050	Cord holder					
40	060300416	Screw 3 × 4					
41	087411416	Screw B4 × 14					
42	XC2133051	Carriage cover					
43	XA5285053	ES cover U					
44	XA6024051	ES cover D assy					



(8) OTHER PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	X57789151	BH PRESSER FOOT	CHG		UH3851001	WARRANTY CARD EUR	ADD
2	XC3098051	OVERCASTING STITCH FOOT	CHG		XC6402051	WARRANTY CARD (U.K.)	ADD
		ASSY			XA6351251	WARRANTY CARD (ITA)	050317
3	X56409051	BLIND STITCH FOOT ASSY	CHG		181401172	INSERTION WARRANTY COUPON	ADD
4	103561002	ZIPPER FOOT	ADD		XA1392051	BACKING MATERIAL SHEET	ADD
5	X54243001	Seam ripper			XC7460051	ACCESSORY LEAFLET (P1000)	ADD
6	XA6627051	Needle set			XC7528001	G.LEAFLET 12	
7	130012053	Spool cap A			X81264051	G.LEAFLET NO.24	
8	XC4487051	ACCESSORY BAG	CHG		X81074001	G.LEAFLET DISNEY	
9	X59476051	Cleaning brush					
10	XA2005051	Needle plate fixing metal					
11	XA5357001	Embroidery foot assembly					
12	XC1807121	SCISSORS	050041				
13	XA5752001	Spool cap (small)					
14	XA5353101	ENBROIDERY FRAME S2M					
15	XA5590151	EMBROIDERY SHEET S2M ASSY					
16	XA3336051	Spool pin					
17	X57045051	Felt					
18	X59375151	Button fitting foot					
19	XA5523050	Net					
20	XA1391001	Backing material					
21	X61252053	CARTON (USA/CAN)	CHG				
	X61252054	CARTON (OTHERS)	CHG				
	X61252055	CARTON (P1000)	ADD				
	X61252054	CARTON (IRAQ)	ADD				
22	X61248051	POLYSTYRENE FORM PAD ASSY, 145	CHG				
	X61248052	POLYSTYRENE FORM PAD ASSY, 145	ADD				
		(KOREA)					
23	X61188150	PE sheet					
24	XA6565051	Caution sheet					
25	XA1291051	POWER SUPPLY CORD :	CHG				
		(KOREA)					
	XA0070151	POWER SUPPLY CORD	CHG				
	XC9548051	POWER SUPPLY CORD : SAA-LF	040186				
	X59354151	POWER SUPPLY CORD -BS	040124				
26	194147011	Instruction manual (English)					
	194147015	Instruction manual (French)					
	194147013	Instruction manual (German)	ADD				
	194147060	Instruction manual (Disney)					
	X61212051	HEAD COVER	ADD				
	XZ0107051	ES PAD D	ADD				
	130800051	BAG 220X310	ADD				
	X60679051	BAG 450X400H	ADD				
	XC0378051	WARRANTY CARD (U.S.A.)	ADD				

