Main control board firmware update steps:


1. As shown in the figure, copy the "ELEGOO_UPDATE_DIR" folder and its contents under the "elegoo_giga_firmware_APP-V2.3.2.2_UI-V1.1.3/APP_V2.3.2.2" path to the root directory of the USB flash drive:



2. Conduct the update on the touch screen.

Scenario 1: Control the screen normally after turning on the machine.

Operate [Settings]-[Info] on the touch screen, then click the update button in the upper right corner, and follow the prompts.



Scenario 2: The error page appears after restarting.

Click the exit button in the upper right corner, and then update according to the steps in scenario 1.

