

Huyang Boards

Chest Lights

2 Adressable LEDs 3 Soldercontacts on the backside (Data, Power and GND) LED 4x4mm



Head Eyes and Servos



Elco between 3.3v and Ground

7 PINS TO TFT DISPLAY FROM LEFT TO RIGHT:

RST, CS, DC, SDA, SCL, GND, VCC

CONNECTION TO MAINBOARD WITH 11 WIRES:


Power 3,3V Ground

Display Pin CS Left -> D0
Display Pin CS Right -> D8
Display Pin SCL -> D5
Display Pin SDA -> D7
Display Pin DC -> D4

(If split, then split here)

Servos Power 6V Head Left Servo Data Head Right Servo Data Monocle Servo Data

Chest Mainboard



CONNECTION TO ADAFRUIT SERVO SHIELD:

Ground ->
OE -> SCL -> D1
SDA -> D2

VCC -> 3.3V Power V+ -> 6V Power