$$V_s = 3V + \underbrace{R_1 = 1\Omega}_{R_2} \quad n_A$$

$$R_1 = 1\Omega \quad n_A$$

$$R_2 = 3\Omega \quad I_s = 1A$$