

LIPSCOMB UNIVERSITY
RAYMOND B. JONES
COLLEGE OF ENGINEERING

Lab05 Notes


- Use ReadyAVR's joystick to control the blink rate of the "BOOT" LED
- Modify Lab02 to:
  - Blink the "BOOT" LED (**PORTA.7**) at a rate of 1-15Hz, as governed by a value stored in R20.
  - Use ISRs to change the value of R20 in response to up/down movement of the joystick.
  - Show current blink rate as a 4-bit binary number using LEDs connected to **PORTC.3:0**. Only update these LEDs when the blink rate is changed (i.e. in the ISR).




Lab05 Notes



You must enable the internal pull-up resistors






NB: Joystick switches are physically connected to PORTB pins, <u>but those pins can't generate interrupts</u>. However, PORTD pins can, and they can be connected **externally** to PORTB pins allowing joystick movements to invoke ISRs (see next page for details).

LIPSCOMB UNIVERSITY
RAYMOND B. JONES
COLLEGE OF ENGINEERING

Lab05 Notes

- As shown on the previous page, the ReadyAVR joystick is connect to five ATmega128A pins:

PORTB.4
PORTB.3
PORTB.2
PORTB.1
PORTB.0




- Key points:
  - PORTB.1 and PORTB.3 cannot generate interrupts
  - However, PORTD.1 and PORTD.3 ***can*** generate interrupts, so externally connect (via jumpers) PB1⇔PD1 and PB3⇔PD3
  - Then program PD1 (down) and PD3 (up) to trigger ISRs
  - MAKE SURE BOTH SETS OF PINS ARE CONFIGURED AS INPUTS!


Lab05 Notes

- You will need to configure several port- and interrupt-related registers for this lab:
  - Set INT1, INT3 ISR vectors (to handle up/down)
  - DDRA: set pin 7 as an output (the “BOOT” LED)
  - DDRB: set pins 1 and 3 as inputs (up/down joystick)
  - DDRC: set pins 3:0 as outputs (blink rate LEDs)
  - DDRD: set pins 1 and 3 as inputs (to trigger ISRs)
  - PORTB: set internal pull-ups on pins 1 and 3
  - EICRA: set INT1 and INT3 to activate on RISING edge
  - EIMSK: allow INT1 and INT3 to generate interrupts
  - SREG: enable interrupts globally (set bit 7 via sei)
- Read the ATmega128A data sheet slowly, carefully, and for full understanding!

Switch Bounce

Simple active low
switch circuit









LIPSCOMB UNIVERSITY
RAYMOND B. JONES
COLLEGE OF ENGINEERING

RC Switch Debouncing

Simple active low switch circuit with RC debouncing





$$
\begin{aligned}
5\tau &= 5(R \times C) \\
&= 5(47k\Omega \times 100nF) \\
&= 5(4.7mS) \\
&= 23.5mS \approx \mathbf{25mS}
\end{aligned}
$$

*You can use the ATmega128A's internal pull-up resistor as R2, but you'll need to check the datasheet to discover it's value.